

# CRAWLER CRANE

SHOP  
MANUAL

**model**      **CK1200**  
**CKE1100**

**KOBELCO**

---

BOOK CODE : S5GK00004ZE01

<https://cranemanuals.com>

| Applicable Model | Applicable Machine | Date of issue | Remarks |
|------------------|--------------------|---------------|---------|
| CK1200           | From GK04-03001    | 2006.03       |         |
| CKE1100          | From GK04-03002    | 2006.03       |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |
|                  |                    |               |         |

## TABLE OF CONTENTS

---

### SAFETY

#### 1. SPECIFICATION

|                                                |      |
|------------------------------------------------|------|
| 1.1 SPECIFICATION.....                         | 1-3  |
| 1.1.1 PERFORMANCE.....                         | 1-3  |
| 1.1.2 OUTSIDE DIMENSIONS.....                  | 1-4  |
| 1.1.3 DIMENSIONS AND WEIGHT OF EACH PARTS..... | 1-6  |
| 1.1.4 STABILITY IN SWINGING AND TRAVELING..... | 1-12 |

#### 2. MAINTENANCE STANDARDS

##### TEST PROCEDURES

|                                                    |      |
|----------------------------------------------------|------|
| 2.1 MAINTENANCE STANDARD.....                      | 2-3  |
| 2.1.1 PIN, BUSHING, SPRING, LINING AND SHEAVE..... | 2-3  |
| 2.1.2 PROPEL DEVICE.....                           | 2-10 |
| 2.1.3 PROPEL BRAKE PLATE.....                      | 2-16 |
| 2.2 PERFORMANCE STANDARD AND TEST PROCEDURE.....   | 2-17 |
| 2.2.1 OPERATING SPEED.....                         | 2-17 |
| 2.2.2 POINT AND METHOD OF MEASURING PRESSURE.....  | 2-18 |
| 2.2.3 SLEWING RING.....                            | 2-23 |

#### 3. GENERAL WORK STANDARD

|                                                    |      |
|----------------------------------------------------|------|
| 3.1 TIGHTENING TORQUE OF CAPSCREWS AND NUTS.....   | 3-3  |
| 3.1.1 METRIC COARSE THREADS.....                   | 3-3  |
| 3.1.2 METRIC FINE THREADS.....                     | 3-3  |
| 3.1.3 COARSE THREDS UNC.....                       | 3-4  |
| 3.1.4 FINE THREADS UNF.....                        | 3-4  |
| 3.1.5 TIGHTENING TORQUE OF HYDRAULIC FITTINGS..... | 3-5  |
| 3.2 STANDARD PARTS.....                            | 3-7  |
| 3.2.1 BOLT.....                                    | 3-7  |
| 3.2.2 O-RING.....                                  | 3-8  |
| 3.2.3 BACK-UP RING.....                            | 3-9  |
| 3.2.4 BITE FITTING.....                            | 3-10 |
| 3.3 CONVERSION TABLE.....                          | 3-12 |
| 3.3.1 UNIT CONVERSION.....                         | 3-12 |
| 3.3.2 MILLIMETER : INCH CONVERSION TABLE.....      | 3-13 |
| 3.3.3 METER-FOOT CONVERSION TABLE.....             | 3-15 |
| 3.3.4 GRADIENT CONVERSION TABLE.....               | 3-16 |
| 3.4 TABLE OF UNIT WEIGHT.....                      | 3-17 |

#### 4. POWER TRAIN

## TABLE OF CONTENTS

---

|                            |                                                               |      |
|----------------------------|---------------------------------------------------------------|------|
| 4.1                        | INTRODUCTION.....                                             | 4-3  |
| 4.2                        | ENGINE.....                                                   | 4-5  |
| 4.2.1                      | INTRODUCTION.....                                             | 4-5  |
| 4.2.2                      | REMOVAL.....                                                  | 4-5  |
| 4.2.3                      | REPAIR AND MAINTENANCE.....                                   | 4-6  |
| 4.2.4                      | RE-INSTALLATION.....                                          | 4-7  |
| 4.3                        | PUMP DRIVE ASSEMBLY.....                                      | 4-10 |
| 4.3.1                      | INTRODUCTION.....                                             | 4-10 |
| 4.3.2                      | REMOVAL.....                                                  | 4-10 |
| 4.3.3                      | DISASSEMBLING THE POWER DIVIDER.....                          | 4-12 |
| 4.3.4                      | CHECK AND REPAIR OF THE POWER DIVIDER.....                    | 4-13 |
| 4.3.5                      | ASSEMBLING THE POWER DIVIDER.....                             | 4-14 |
| 4.3.6                      | RE-INSTALLATION.....                                          | 4-15 |
| <b>5. HYDRAULIC SYSTEM</b> |                                                               |      |
| 5.1                        | LOCATION OF MAIN HYDRAULIC COMPONENTS.....                    | 5-3  |
| 5.2                        | HYDRAULIC CIRCUITS AND COMPONENTS.....                        | 5-4  |
| 5.2.1                      | HYDRAULIC CIRCUIT.....                                        | 5-4  |
| 5.2.2                      | COMPONENT SPECIFICATIONS.....                                 | 5-8  |
| 5.2.3                      | LOCATION OF HYDRAULIC COMPONENTS.....                         | 5-12 |
| 5.3                        | HYDRAULIC SYSTEM.....                                         | 5-22 |
| 5.3.1                      | PREFACE.....                                                  | 5-22 |
| 5.3.2                      | OUTLINE.....                                                  | 5-22 |
| 5.3.3                      | OIL FLOW FROM No 1 and No 2 PUMPS.....                        | 5-23 |
| 5.3.4                      | OIL FLOW FROM No 3 AND No.4 PUMPS.....                        | 5-25 |
| 5.3.5                      | OIL FLOW FROM No 5 PUMPS (Control Pumps).....                 | 5-27 |
| 5.3.6                      | OIL FLOW FROM No.6 PUMP (For Auxiliary Actuator Circuit)..... | 5-30 |
| 5.4                        | VALVES.....                                                   | 5-33 |
| <b>6. HOIST SYSTEM</b>     |                                                               |      |
| 6.1                        | APPARATUS AND LOCATION OF COMPONENTS.....                     | 6-3  |
| 6.2                        | CONSTRUCTION AND FUNCTION.....                                | 6-4  |
| 6.2.1                      | HYDRAULIC SCHEMATIC.....                                      | 6-4  |
| 6.2.2                      | LIFTING A LOAD.....                                           | 6-6  |
| 6.2.3                      | HOLDING A RAISED LOAD.....                                    | 6-8  |
| 6.2.4                      | LOWERING A LOAD (POWERED LOWERING).....                       | 6-10 |
| 6.2.5                      | FREE FALL OPERATION.....                                      | 6-12 |
| 6.2.6                      | FREE FALL ACCELERATION.....                                   | 6-16 |
| 6.3                        | DRUM LOCK.....                                                | 6-18 |

## TABLE OF CONTENTS

|                             |                                                          |      |
|-----------------------------|----------------------------------------------------------|------|
| 6.3.1                       | ASSEMBLY DRAWING                                         | 6-18 |
| 6.3.2                       | ADJUSTMENT OF DRUM LOCK                                  | 6-19 |
| 6.4                         | WINCH ASSEMBLY                                           | 6-20 |
| 6.4.1                       | WINCH INSTAL                                             | 6-20 |
| 6.4.2                       | WINCH ASSEMBLY / REDUCTION UNIT WITHOUT FREE FALL (STD.) | 6-21 |
| 6.4.3                       | WINCH ASSEMBLY WITH FREE FALL (OPT.)                     | 6-23 |
| 6.5                         | BRAKE PEDAL                                              | 6-24 |
| 6.5.1                       | ASSEMBLY DRAWING                                         | 6-24 |
| 6.5.2                       | ADJUSTING THE BRAKE PEDAL                                | 6-26 |
| 6.6                         | BLEEDING AIR FROM BRAKE CIRCUIT                          | 6-27 |
| <b>7. BOOM HOIST SYSTEM</b> |                                                          |      |
| 7.1                         | APPARATUS AND LOCATION OF COMPONENTS                     | 7-3  |
| 7.2                         | CONSTRUCTION AND FUNCTION                                | 7-5  |
| 7.2.1                       | HYDRAULIC SCHEMATIC                                      | 7-5  |
| 7.2.2                       | RAISING THE BOOM                                         | 7-6  |
| 7.2.3                       | NEUTRAL<br>(MAINTAINING THE BOOM POSITION)               | 7-8  |
| 7.2.4                       | LOWERING THE BOOM                                        | 7-10 |
| 7.3                         | BOOM DRUM LOCK                                           | 7-12 |
| 7.3.1                       | ASSEMBLY DRAWING                                         | 7-12 |
| 7.3.2                       | ADJUSTING THE BOOM DRUM LOCK                             | 7-13 |
| 7.4                         | DRUM AND REDUCTION UNIT                                  | 7-14 |
| 7.4.1                       | BOOM WINCH ASSEMBLY                                      | 7-14 |
| 7.4.2                       | BOOM DRUM AND REDUCTION UNIT ASSEMBLY                    | 7-16 |
| <b>8. SWING SYSTEM</b>      |                                                          |      |
| 8.1                         | APPARATUS AND LOCATION OF COMPONENTS                     | 8-3  |
| 8.2                         | CONSTRUCTION AND FUNCTION                                | 8-4  |
| 8.2.1                       | HYDRAULIC SCHEMATIC                                      | 8-4  |
| 8.2.2                       | SWING                                                    | 8-6  |
| 8.2.3                       | STOPPING                                                 | 8-9  |
| 8.3                         | SWING REDUCTION UNIT                                     | 8-12 |
| 8.4                         | SWING BEARING                                            | 8-14 |
| 8.5                         | SWING LOCK                                               | 8-16 |
| <b>9. PROPEL SYSTEM</b>     |                                                          |      |
| 9.1                         | LOCATION OF THE MAJOR COMPONENTS                         | 9-3  |
| 9.2                         | CONSTRUCTION AND FUNCTION                                | 9-4  |

## TABLE OF CONTENTS

|                               |                                                                           |        |
|-------------------------------|---------------------------------------------------------------------------|--------|
| 9.2.1                         | HYDRAULIC SCHEMATIC.....                                                  | 9-4    |
| 9.2.2                         | PROPELLING (RIGHT SIDE FORWARD).....                                      | 9-6    |
| 9.2.3                         | STOPPING.....                                                             | 9-8    |
| 9.3                           | PROPEL REDUCTION UNIT.....                                                | 9-10   |
| 9.3.1                         | MOTOR AND REDUCTION UNIT.....                                             | 9-11   |
| 9.4                           | ADJUSTMENT.....                                                           | 9-13   |
| <b>10. ELECTRIC SYSTEM</b>    |                                                                           |        |
| 10.1                          | ELECTRICAL WIRING SCHEMATIC.....                                          | 10-3   |
| 10.2                          | CONNECTOR LIST.....                                                       | 10-14  |
| 10.3                          | ARRANGEMENT OF ELECTRICAL PART.....                                       | 10-66  |
| 10.3.1                        | ELECTRICAL PART OF CAB.....                                               | 10-66  |
| 10.3.2                        | ELECTRICAL PART OF RIGHT DECK.....                                        | 10-70  |
| 10.3.3                        | ELECTRICAL PART OF FLOOR PLATE & LEFT SIDE STAND PANEL.....               | 10-78  |
| 10.3.4                        | ELECTRICAL PART OF REVOLVING FRAME.....                                   | 10-83  |
| 10.3.5                        | ELECTRICAL PART OF LEFT DECK.....                                         | 10-86  |
| 10.3.6                        | ELECTRICAL PART OF LEFT GUARD.....                                        | 10-93  |
| 10.4                          | ELECTRICAL PART.....                                                      | 10-94  |
| 10.4.1                        | FUSE BOX (GG73E00004F1).....                                              | 10-94  |
| 10.4.2                        | WIPER CONTROL UNIT (2480U306).....                                        | 10-96  |
| 10.4.3                        | SWING FLASHER UNIT (2480U306).....                                        | 10-97  |
| 10.4.4                        | PRESSURE SWITCH (CONTROL PRESSURE CUT & FREE FALL)<br>(GG52S00006P1)..... | 10-98  |
| 10.4.5                        | PRESSURE SENSOR.....                                                      | 10-99  |
| 10.4.6                        | RELAY BOX (GG24E00024F1).....                                             | 10-101 |
| 10.4.6.1                      | ARRANGEMENT OF CONNECTOR.....                                             | 10-101 |
| 10.4.6.2                      | RELAY BOX SCHEMATIC.....                                                  | 10-103 |
| 10.4.7                        | LEFT SIDE STAND PANEL.....                                                | 10-106 |
| 10.5                          | TROUBLESHOOTING OF EXHAUST GAS THIRD REGULATION ENGINE.....               | 10-110 |
| 10.5.1                        | FAILURE DIAGNOSIS FUNCTION.....                                           | 10-110 |
| 10.5.2                        | HOW TO CHECK THE FAILURE CONTENTS.....                                    | 10-111 |
| 10.5.3                        | CHECKING BLOWN-OFF DIAGNOSIS LAMPS.....                                   | 10-116 |
| 10.5.4                        | ENGINE ECU.....                                                           | 10-117 |
| <b>11. LOAD SAFETY DEVICE</b> |                                                                           |        |
| 11.1                          | PART NAMES AND FUNCTIONS.....                                             | 11-3   |
| 11.1.1                        | FRONT VIEW.....                                                           | 11-3   |
| 11.1.2                        | CONFIGURATION OF SCREENS.....                                             | 11-8   |
| 11.1.3                        | DATA TRANSMISSION BETWEEN CONTROLLER AND CARDS.....                       | 11-13  |
| 11.1.4                        | DETAILS OF INDICATORS ON MAIN DISPLAY SCREEN.....                         | 11-15  |

## TABLE OF CONTENTS

|                                                                                                                                                          |       |
|----------------------------------------------------------------------------------------------------------------------------------------------------------|-------|
| 11.1.5 REAR VIEW.....                                                                                                                                    | 11-19 |
| 11.1.6 ITEMS REQUIRED TO BE EXECUTED FOR REPLACEMENT OF CONTROLLER<br>OR DATA CARD AND INSTRUCTIONS<br>(In a similar manner to upgrade of program) ..... | 11-24 |
| 11.2 PREPARATION FOR USE.....                                                                                                                            | 11-25 |
| 11.3 TURN THE POWER ON .....                                                                                                                             | 11-26 |
| 11.4 UPGRADING PROGRAMS.....                                                                                                                             | 11-27 |
| 11.4.1 PROCEDURES .....                                                                                                                                  | 11-27 |
| 11.4.2 UPGRADING OF INDICATION PROGRAMS .....                                                                                                            | 11-29 |
| 11.4.3 UPGRADING OF CONTROL PROGRAMS .....                                                                                                               | 11-32 |
| 11.5 STATUS CHECK.....                                                                                                                                   | 11-34 |
| 11.5.1 SIGNAL CHECK.....                                                                                                                                 | 11-35 |
| 11.5.2 OPERATION PROGRESS .....                                                                                                                          | 11-37 |
| 11.5.3 COMMUNICATION DATA.....                                                                                                                           | 11-40 |
| 11.5.4 INDICATION OF ADJUSTMENT VALUE .....                                                                                                              | 11-41 |
| 11.5.4.1 ANGLE SENSOR ADJUSTMENT VALUE.....                                                                                                              | 11-42 |
| 11.5.4.2 LOAD CELL ZERO POINT ADJUSTMENT VALUE .....                                                                                                     | 11-43 |
| 11.5.4.3 ADJUSTMENT VALUE OF LOAD CELL FOR LINE-PULL .....                                                                                               | 11-44 |
| 11.5.4.4 RESULT OF MANUFACTURE ADJUSTMENTS<br>"NO LOAD" AND "SOME LOAD".....                                                                             | 11-45 |
| 11.5.4.5 RESULT OF LOAD ADJUSTMENTS "NO LOAD" AND "SOME LOAD" ..                                                                                         | 11-46 |
| 11.5.4.6 ADJUSTMENT VALUE OF WORKING RADIUS.....                                                                                                         | 11-47 |
| 11.5.4.7 ALTERATION OF ADJUSTED VALUE.....                                                                                                               | 11-48 |
| 11.5.4.8 DELETION OF ADJUSTED VALUE .....                                                                                                                | 11-49 |
| 11.5.5 LOAD RECORD .....                                                                                                                                 | 11-50 |
| 11.5.6 TROUBLE RECORD .....                                                                                                                              | 11-53 |
| 11.5.7 CHOICE OF LANGUAGE (CKE SERIES ONLY).....                                                                                                         | 11-55 |
| 11.5.8 LOAD RECORD (LOAD RECORD IN THE MAIN MENU) .....                                                                                                  | 11-56 |
| 11.6 ADJUSTMENTS.....                                                                                                                                    | 11-57 |
| 11.6.1 REMOVING THE INNER PANEL .....                                                                                                                    | 11-57 |
| 11.6.2 ADJUSTMENT.....                                                                                                                                   | 11-58 |
| 11.6.2.1 ANGLE SENSOR ADJUSTMENT .....                                                                                                                   | 11-61 |
| 11.6.2.2 LOAD CELL ZERO POINT ADJUSTMENT .....                                                                                                           | 11-65 |
| 11.6.2.3 LOAD-LESS ADJUSTMENT & SOME LOAD ADJUSTMENT.....                                                                                                | 11-67 |
| 11.6.2.4 LVL ADJUSTMENT (LVL SETTING) .....                                                                                                              | 11-73 |
| 11.6.2.5 RADIUS ADJUSTMENT .....                                                                                                                         | 11-76 |
| 11.6.3 LOAD ADJUSTMENT.....                                                                                                                              | 11-78 |
| 11.6.4 ADJUSTMENT DATA COPY (INITIALIZATION) .....                                                                                                       | 11-80 |
| 11.6.4.1 READING OF THE ADJUSTMENT DATA.....                                                                                                             | 11-82 |
| 11.6.4.2 WRITING OF ADJUSTMENT DATA.....                                                                                                                 | 11-84 |
| 11.6.4.3 INITIALIZATION OF ADJUSTMENT DATA.....                                                                                                          | 11-85 |
| 11.6.5 VERSION CHECK.....                                                                                                                                | 11-86 |
| 11.7 ERROR CODE (ABNORMALITY DETECTION) AND COUNTERMEASURES....                                                                                          | 11-87 |

## TABLE OF CONTENTS

|                                                              |        |
|--------------------------------------------------------------|--------|
| 11.8 CONTROL OUTPUT .....                                    | 11-89  |
| 11.9 RELEASES .....                                          | 11-101 |
| 11.9.1 RELEASE FUNCTION .....                                | 11-101 |
| 11.9.1.1 CRANE RELEASE CHART .....                           | 11-101 |
| 11.9.1.2 ALARM SOUND .....                                   | 11-107 |
| 11.9.1.3 EXTERNAL INDICATOR LAMPS IN RELEASE CONDITION ..... | 11-108 |
| 11.10 MECHANICAL SPECIFICATION .....                         | 11-109 |
| 11.10.1 ENVIRONMENTAL PERFORMANCE PARAMETERS .....           | 11-109 |
| 11.10.2 LOAD CELL (CRANE) .....                              | 11-110 |
| 11.10.3 ANGLE SENSOR .....                                   | 11-111 |
| 11.10.4 CONTROLLER .....                                     | 11-112 |
| 11.10.4.1 MODEL NAME .....                                   | 11-112 |
| 11.10.4.2 SYSTEM INPUT/OUTPUT .....                          | 11-112 |
| 11.10.4.3 MONITOR DISPLAY .....                              | 11-114 |
| 11.10.4.4 OPERATION SWITCH .....                             | 11-114 |
| 11.10.4.5 INTERNAL PROCESSING SYSTEM .....                   | 11-114 |
| 11.10.4.6 MEMORY .....                                       | 11-114 |
| 11.10.4.7 EXTERNAL STORAGE ELEMENT .....                     | 11-115 |
| 11.10.4.8 OTHERS .....                                       | 11-115 |
| 11.11 EXTERNAL DIMENSIONS .....                              | 11-116 |
| 11.12 ELECTRIC SCHEMATIC DIAGRAM .....                       | 11-117 |
| 11.12.1 CRANE TYPE .....                                     | 11-117 |
| 11.12.2 LUFFING TYPE .....                                   | 11-118 |
| 11.13 CONTROLLER MALFUNCTION EMERGENCY MEASURES .....        | 11-119 |
| 11.14 LOAD SAFETY DEVICE CHECK PROCEDURES .....              | 11-120 |
| <b>12. GAUGE CLUSTER</b>                                     |        |
| 12.1 CONFIGURATION OF DISPLAY .....                          | 12-3   |
| 12.2 PRIORITY .....                                          | 12-4   |
| 12.3 STATUS DISPLAY .....                                    | 12-6   |
| 12.4 FAULT LOG DISPLAY .....                                 | 12-16  |
| <b>13. TOTAL CONTROLLER</b>                                  |        |
| 13.1 ARRANGEMENT OF TOTAL CONTROLLER .....                   | 13-3   |
| 13.2 COMPOSITION OF SYSTEM .....                             | 13-4   |
| 13.2.1 OUTPUT RELATION TO CONTROLLER .....                   | 13-5   |
| 13.3 FUNCTION OF TOTAL CONTROLLER .....                      | 13-6   |
| 13.4 TOTAL CONTROLLER (HARDWARE) .....                       | 13-31  |
| 13.4.1 OUTLINE .....                                         | 13-31  |
| 13.4.2 SPECIFICATIONS OF TOTAL CONTROLLER OUTPUT .....       | 13-32  |
| 13.4.3 DETAILS OF TOTAL CONTROLLER CONNECTOR .....           | 13-36  |
| 13.4.4 ARRANGEMENT OF TOTAL CONTROLLER CONNECTOR PIN .....   | 13-37  |



## TABLE OF CONTENTS

---

|                                                                      |              |
|----------------------------------------------------------------------|--------------|
| 13.4.5 PROPORTIONAL SOLENOID VALVE MEASURING POSITION . . . . .      | 13-44        |
| <b>13.5 ADJUSTMENT OF TOTAL CONTROLLER</b> . . . . .                 | <b>13-45</b> |
| 13.5.1 NECESSITY OF ADJUSTMENT . . . . .                             | 13-45        |
| 13.5.2 ADJUSTMENT PROCEDURES OF TOTAL CONTROLLER . . . . .           | 13-45        |
| 13.5.2.1 OPTION SETTING . . . . .                                    | 13-45        |
| 13.5.2.2 ADJUSTMENT OF HAND THROTTLE AND FOOT THROTTLE . . . . .     | 13-47        |
| 13.5.2.3 ENGINE SPEED ADJUSTMENT . . . . .                           | 13-48        |
| 13.5.2.4 WHEN ADJUSTMENT OF TOTAL CONTROLLER IS IMPOSSIBLE . . . . . | 13-49        |
| 13.5.2.5 INITIAL ADJUSTMENT OF LIFTING HEIGHT GAUGE . . . . .        | 13-50        |
| <br>                                                                 |              |
| <b>14. AIR CONDITIONER</b>                                           |              |
| 14.1 OPERATION ITEMS . . . . .                                       | 14-3         |
| 14.2 SAFETY MONITOR FUNCTIONS . . . . .                              | 14-4         |
| 14.3 DISASSEMBLY AND ASSEMBLY PROCEDURE . . . . .                    | 14-7         |
| 14.3.1 SPECIAL CONSIDERATIONS DURING REPLACEMENT . . . . .           | 14-7         |
| 14.3.2 INTERIOR UNIT . . . . .                                       | 14-9         |
| 14.3.2.1 CASE DISASSEMBLY . . . . .                                  | 14-9         |
| 14.3.2.2 THERMOSTAT REPLACEMENT . . . . .                            | 14-12        |
| 14.3.2.3 EVAPORATOR OR EXPANSION VALVE REPLACEMENT . . . . .         | 14-13        |
| 14.3.2.4 HEATER CORE REPLACEMENT . . . . .                           | 14-14        |
| 14.3.2.5 INTAKE DUMPER ACTUATOR REPLACEMENT . . . . .                | 14-15        |
| 14.3.2.6 WATER VALVE ACTUATOR OR WATER VALVE REPLACEMENT . . . . .   | 14-16        |
| 14.3.2.7 MODE ACTUATOR REPLACEMENT . . . . .                         | 14-17        |
| 14.3.2.8 BLOWER MOTOR ASSEMBLY REPLACEMENT . . . . .                 | 14-17        |
| 14.4 OPERATIONAL PRECAUTIONS . . . . .                               | 14-18        |
| 14.5 INSPECTION AND MAINTENANCE . . . . .                            | 14-19        |
| 14.5.1 INSPECTION/MAINTENANCE LIST . . . . .                         | 14-19        |
| 14.5.2 INSPECTION/MAINTENANCE PROCEDURES . . . . .                   | 14-19        |
| 14.6 ELECTRIC SYSTEM SCHEMATIC . . . . .                             | 14-23        |

## TABLE OF CONTENTS

---

---

# **SAFETY**

This section explains "Explanation of Warning Description", "Warning Labels" and "General safety"

### EXPLANATION OF WARNING DESCRIPTION

This manual indicates the contents of warnings concerned in safety with the following three stages according to the degree of personal harm and material damage.


Since the very important matters for safety are described, understand the contents sufficiently and observe them without fail.



Warning to avoid dangerous condition resulting in instantaneous death or serious personal injury.



Warning to avoid dangerous condition which has possibility of death or serious personal injury.



Warning to avoid dangerous condition which has possibility to cause slight or medium injury or damage of the machine and equipments.

This manual describes safety warnings sufficiently, but dangerous conditions which are impossible to be anticipated are considered.

Therefore, take measures for safety not only regarding the machine, but also including the working environment

### EXPLANATION OF WARNING LABELS

Since the warning labels are installed in the machine and indicated with the three stages in the same way as the warning description, confirm the positions and contents all warning labels first.

Put them to the practical use to secure safety when operating, checking and performing maintenance.

#### • HANDLING OF WARNING LABELS

1. When the warning label is damaged or stained, order it to the designated service shop.
2. Do not remove the warning labels.
3. When the surface of the warning label is soiled and difficult to be seen, wipe it cleanly.

**⚠ DANGER**  
**NEVER FORGET TO ENGAGE**  
**GANTRY CONNECT OR PINS**  
 TO AVOID FALLING OF BEAMS, GANTRY  
 CONNECTION PINS MUST BE ENGAGED  
 WHEN GANTRY IS AT HIGH POSITION.  
 ALSO, LOWER PARTS OF TENSION BEAMS  
 MUST BE CONNECTED TO REVOLVING FRAME  
 OR CONNECTION WITH GANTRY AT  
 LOW POSITION.


FP20T01043P1

**⚠ DANGER**  
 When lock air is not installed,  
 do not stand under center.

JJ20T01097P1

**⚠ CAUTION**  
 Moving parts

JJ20T01093P1



**⚠ CAUTION**  
 Stay out from  
 crane swing area

JJ20T01095P1

**⚠ DANGER**  
 DEATH OR INJURY MAY RESULT IF  
 MACHINE, LOAD, OR LEAD LINE TOUCHES  
 OR COMES CLOSE TO ELECTRICAL LINES.  
 ALWAYS MAINTAIN A CLEARANCE OF  
 AT LEAST 10 FEET (3 METERS)  
 BETWEEN THE CRANE OR THE LOAD  
 BEING HANDLED AND POWER LINES.  
 UNLAWFUL TO PLACE ANY PART OF  
 THIS MACHINE OR LOAD WITHIN 10 FEET  
 (3 METERS) OF HIGH VOLTAGE LINES OF  
 50,000 VOLTS OR LESS.  
 GREATER CLEARANCES ARE REQUIRED  
 FOR HIGHER VOLTAGES. SEE YOUR LOCAL  
 STATE AND FEDERAL REGULATIONS.  
 ALWAYS NOTIFY ELECTRIC COMPANY IF  
 THERE ARE ELECTRICAL LINES IN THE AREA  
 WHERE MACHINE WILL BE WORKING.


SU2010112/P1

**ACCUMULATOR**  
 2-WHEELING GAS PRESS. REF.  
 5.4 x 3.7 Mpa  
 GSE 438 Kg/cm<sup>2</sup>

GG20T01079P1

**⚠ WARNING**  
**AVOID EXPLOSION WHEN**  
**HANDLING ACCUMULATOR**  
 THIS CASE IS CHARGED WITH  
 HIGH PRESSURE HYDRAULIC OIL.  
 NEVER ATTEMPT TO WELD, CUT-OUT,  
 PUT ON FIRE, NOR DISASSEMBLE  
 THE CASE TO AVOID EXPLOSION


FP20T01042P1



DETAIL C  
 (ACCUMULATOR)

**⚠ CAUTION**  
Moving parts.

**⚠ CAUTION**  
Only to see when machine is stopped.



VIEW A


**⚠ WARNING**

YALPING ON GUARDS MAY CAUSE STUMBLING AT PROJECTED ITEMS AND SLIPPING ON OIL, WATER, OR GREASE.  
PROTECTOR SHOULD BE EMPLOYED WHEN WORKING FOR MAINTENANCE JOB TO AVOID TRIPPING OVER AND FALLING DOWN FROM THE MACHINE.

**⚠ CAUTION**  
Do not crush. Important: part inside.

FP207C1351P1

FP207C064P1




**WARNING**

Slips or hot coolant can cause injury or fires.

Never touch or open red area cap when coolant is hot and under pressure.

Before doing any radiator cap work, wear engine coolant safety glasses and a face shield. Never touch skin or clothing.

YN20T01010P1



VIEW L

**CAUTION**

Only to open when engine is stopped.

..20T01058P1

**DANGER**

When lock pin is not installed, do not stand under jib.

JJ20T01097P1

**DANGER**

NEVER FORGET TO ENGAGE GASTRY CONNECTION PINS


TO AVOID FALLING OF BOOMS, GASTRY CONNECTION PINS MUST BE ENGAGED WHEN GASTRY IS AT HIGH POSITION. ALL LOWER PARTS OF BOOM MUST BE CONNECTED TO REVOLVING FRAME OR COUNTERWEIGHT WHEN GASTRY IS AT LOW POSITION.

FP20T01045P1

**CAUTION**

Moving parts.

JJ20T01095P1



**DANGER**

DEATH OR INJURY MAY RESULT IF WAGON, LOAD, OR LOAD LINE TOUCHES OR COMES CLOSE TO ELECTRICAL LINES. ALWAYS MAINTAIN A CLEARANCE OF AT LEAST 10 FEET (3 METERS) BETWEEN THE CRANE OR THE LOAD BEING HANDLED AND POWERLINES.

UNLAWFUL TO PLACE ANY PART OF THE WAGON OR LOAD WITHIN 10 FEET (3 METERS) OF HIGH VOLTAGE LINES OF 50,000 VOLTS OR LESS. GREATER CLEARANCES ARE REQUIRED FOR HIGHER VOLTAGES. SEE YOUR LOCAL STATE AND FEDERAL REGULATIONS.

ALWAYS NOTIFY ELECTRIC COMPANY IF THERE ARE ELECTRICAL LINES IN THE AREA WHERE MACHINE WILL BE WORKING.

GG20T01177P1

**CAUTION**


Stay out from crane while it's on.

JJ20T01095P1

**DANGER**

STAY AWAY FROM MACHINE IF CLOSE TO POWER LINES. MACHINE, LOAD AND GROUND MAY BECOME ELECTRIFIED AND DEADLY.

GG20T01178P1



**WARNING**

Rotating parts can cause personal injury.  
Keep hands from the bell when engine is running.  
Stop engine before any work.

YX2CTD1003P1


DETAIL M

**CAUTION**

**CAUTION**  
FOR HIGH TEMPERATURE

AS ENGINES AND MUFFLERS  
MAY BE HEATED TO HIGH  
TEMPERATURES, DO NOT  
DIRECTLY TOUCH THEM BY HAND

FP2DT01043P1




DETAIL N

(VIEW FROM INNER OF DOOR)

**DANGER**

KEEP CLEAR OF  
SWING AREA

YA201C1003P2



**CAUTION**

Stay out from  
clearance area.


JJ2CTD1095P1

**LINK OR BAR CONNECTORS**

WITHOUT COUNTERWEIGHT WITH COUNTERWEIGHT

SAFETY POINT


GG2CTD1175P1




VIEW P

VIEW Q






YN20T01017PI



YN20T01001PI




DETAIL R




FP20T01050PI



FUEL TANK




FP20T01045PI



SECT ON U-U



FP20T01040PI


VIEW S  
(HYD. OIL TANK)

**⚠ DANGER**  
**AND TIPPING DUE**  
**WHEN CRANERS ARE RETRACTED**  
 MACHINES IN RETRACTED POSITION  
 HAVE LESS STABILITY AND MAY CAUSE  
 TIPPING OVER WHEN SWINGED TO 270°  
 COMPLETE 360° ON COMB-Y AND 450°  
 ON CRANES. SEE MANUAL.



FP201G1048P1

**⚠ CAUTION**  
**READ BEFORE OPERATION**  
 OPERATOR MANUAL SHOULD BE READ  
 AND UNDERSTOOD BEFORE GETTING ON  
 DAILY MAINTENANCE SHOULD ALWAYS  
 BE OBSERVED. ALSO, CRUISE AND NOTES  
 IN RATING PLATE MUST BE OBSERVED  
 BEFORE OPERATION.



FP201G1047P1

**⚠ DANGER**  
**DO NOT LIFT** IF CRANERS RETRACTED  
 FITTING CRANERS TO PROPER POSITION WITH  
 LIFTING  
 PLATFORMS IS NOT BE MAY CAUSE TIPPING OVER  
 AND TO CAUSE OF STABILIZER.



GE20101197P1

INSIDE VIEW (L/H)

**⚠ CAUTION**  
 WHEN LOCKING THE BRAKE PEDAL  
 STEP ON THE PEDAL FULLY TO LOCK  
 THE PAVEL AT THE BOTTOM POSITION.

2432T5113

**⚠ CAUTION**  
 THIS MACHINE CONTAINS ALLOY AND  
 HEAT TREATED STEELS. DO NOT WELD  
 OR APPLY HEAT WITHOUT CHECKING  
 WITH YOUR AUTHORIZED DEALER.  
 UNAUTHORIZED MODIFICATIONS  
 MAY WEAKEN THE MACHINE.

2432T4671

**⚠ DANGER**


**DEATH OR INJURY MAY RESULT IF:**  
 MACHINE LOAD, OR LOAD LINE TOUCHES  
 OR COMES CLOSE TO ELECTRICAL LINES.  
 ALWAYS MAINTAIN A CLEARANCE OF  
 AT LEAST 15 FEET (4.5 METERS)  
 BETWEEN THE CRANE OR THE LOAD  
 BEING HANDLED AND POWER LINES.

**UNLAWFUL TO PLACE ANY PART OF**  
 THIS MACHINE OR LOAD WITHIN 10 FEET  
 (3 METERS) OF HIGH VOLTAGE LINES OF  
 50 000 VOLTS OR LESS.

GREATER CLEARANCES ARE REQUIRED  
 FOR HIGHER VOLTAGES. SEE YOUR LOCAL,  
 STATE AND FEDERAL REGULATIONS.

**ALWAYS NOTIFY ELECTRIC COMPANY IF**  
 THERE ARE ELECTRIC LINES IN THE AREA  
 WHERE MACHINE WILL BE WORKING.

GE20101127P1



INSIDE VIEW (R/H)

**⚠ CAUTION**  
 DO NOT LIFT PEOPLE WITH THIS CRANE.  
 FAILURE TO DO SO MAY CAUSE  
 SERIOUS INJURY.

2432T4658

**⚠ DANGER**

**STAY AWAY FROM MACHINE**  
**IF CLOSE TO POWER LINES.**  
**MACHINE, LOAD AND GROUND MAY**  
**BECOME ELECTRIFIED AND DEADLY.**

GE20101128P1



## SAFETY

---

### PRECAUTIONS FOR INSPECTION AND MAINTENANCE

1. Service and maintenance must be performed only by authorized personnel who are qualified in compliance with a relevant law or regulation.
2. Regular maintenance or inspection should be quickly performed after shutting down the machine and ensuring safety to personnel and equipment.  
Post an "INSPECTION IN PROGRESS. DO NOT START." warning sign on a readily visible location.

### GENERAL SAFETY PRECAUTIONS

1. Wear safety shoes, helmets and clothing suitable for the job. Also use protective goggles, mask, gloves, etc., as required.
2. To ensure safe and correct maintenance, carefully study this SHOP MANUAL and get fully familiar with the instructions in it.
3. Place the machine in a safe place. Always maintain safe clearance around the machine.
4. Before starting crane operation, hold a safety meeting. Also, make agreement on standardized hand signals.
5. When inspecting or handling the battery or oil, do not use exposed flame nearby.  
To avoid fire accident, only use explosion-proof lighting equipment.
6. Start an inspection or maintenance work only after shutting down the engine.
7. Certain machine components remain hot immediately after the engine is shut down. Do not touch them.
8. Before removing the radiator cap, wait until the coolant water gets sufficiently cool. Next, carefully loosen the cap and release radiator pressure, and then remove the cap.
9. Before inspecting or maintaining an electrical system on the machine, power off the machine by, for example, disconnecting the battery cables.
10. When working at a high lift area, always wear a safety belt.
11. When leaving the operator's cab for an inspection or maintenance work, post an "INSPECTION IN PROGRESS. DO NOT START." warning sign on a readily visible location. Also, lock the cab for security.
12. Before starting a cleaning or lubrication work on the machine, always shut down the engine.
13. While adjusting tire pressure, be absolutely careful about rupture of a tire, flying of wheel part.
14. Use genuine KOBELCO replacement parts and oils only.
15. Always keep the oil containers clean. Protect them against ingress of dust or moisture. Also, fill clean, fresh oils only.
16. Once a maintenance work is complete, clean the machine.  
Protect grease nipples, breathers, and oil level gauges against ingress of dust.
17. Always keep the subjects of regular inspection clean to allow problems such as oil leakage, crack, looseness, etc., to be readily detected.
18. During car washing, do not allow high pressure steam to be directly applied to electrical components and connectors.
19. After removing O-rings, oil seals, gaskets, etc., clean the mounting seats. Then, install fresh O-rings, oil seals, gaskets, etc. Also, remember to thinly apply oil to the seal faces of these parts before installation.
20. Before disconnecting pressurized piping, release the inside pressure.
21. CAUTIONs for repair work with welding: Turn OFF the key switch, disconnect the negative terminal on battery to power off the electrical circuit; provide grounding within 1 meter from a weld area; in advance, remove electronic components (for example, controller) to prevent possible damage.
22. Dispose industrial wastes according to a relevant law or regulation.
23. Extremely careful during an inspection or maintenance work under the carrier. Remember the possibility of being crushed.  
When jacking up the machine for an inspection or maintenance work, place blocks below it to prevent accidental falling.
24. Provide positive ventilation when refilling oils or fuel, rinsing parts, or starting the engine.

- 
- 25 To remove a heavy component (20 kg or heavier), use a crane, etc. Always keep safety in mind.
  - 26 Illegal or unauthorized, or otherwise nonconforming modification is strictly inhibited.
  - 27 Do not allow oil or dust to deposit around the engine. Otherwise, fire accident can result.
  - 28 Store removed attachments and components safely so that they do not drop or fall down.
  - 29 Always use correct tools that have been well maintained.
  - 30 To prevent personnel from being caught by a running fan, belt, shaft or the like, shut down the engine before starting an inspection or maintenance work.
  - 31 Battery, acid and oils are harmful to human health. If touching any of these materials, immediately wash it away.
  - 32 Make sure to use the light oil for fuel.



---

# 1. SPECIFICATION





## 1.1 SPECIFICATION

### 1.1.1 PERFORMANCE

#### CK1200

| Type                                                                                                                  | Crawler mounted, fully revolving                   |                                             |
|-----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------|---------------------------------------------|
| Max lifting capacity                                                                                                  | Standard boom                                      | 138,800 kg x 3.65 m (240,000 lbs x 12 feet) |
| Max boom length                                                                                                       | Standard boom                                      | 70.1 m (230 ft)                             |
| Max boom + Jib length                                                                                                 | 61.0 m boom + 21.3 m jib (200 ft boom + 70 ft jib) |                                             |
| Basic boom length                                                                                                     | Standard boom                                      | 15.2 m (50 ft)                              |
| Working weight (Including upper and lower machine, counter-weights, carbody weights, 50 ft standard boom, hook block) | Approximately 99,000 kg (218,000 lbs)              |                                             |
| Average ground pressure                                                                                               | Approximately 92.9 kPa (13.5 psi)                  |                                             |
| Gradeability (tan $\theta$ )                                                                                          | 30%                                                |                                             |
| Engine                                                                                                                | Hino P11C-UN 247 kw/2000 min. <sup>1</sup>         |                                             |
| Hoist line speed (front and rear drum)                                                                                | 120 m/min. (393 ft/min.)                           |                                             |
| Lowering line speed (front and rear drum)                                                                             | 120 m/min. (393 ft/min.)                           |                                             |
| Boom raising rope speed                                                                                               | 48 m/min. (157 ft/min.)                            |                                             |
| Boom lowering rope speed                                                                                              | 48 m/min. (157 ft/min.)                            |                                             |
| Swing speed                                                                                                           | 3.2 min. <sup>1</sup> (3.2 rpm)                    |                                             |
| Propel speed                                                                                                          | 1.4/1.0 km/h (0.87/0.62 miles/hour)                |                                             |

#### CKE1100


| Type                                                                                                                  | Crawler mounted, fully revolving                   |                                            |
|-----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------|--------------------------------------------|
| Max lifting capacity                                                                                                  | Standard boom                                      | 110,000 kg x 3.6 m (242,504 lbs x 12 feet) |
| Max boom length                                                                                                       | Standard boom                                      | 70.1 m (230 ft)                            |
| Max boom + Jib length                                                                                                 | 61.0 m boom + 21.3 m jib (200 ft boom + 70 ft jib) |                                            |
| Basic boom length                                                                                                     | Standard boom                                      | 15.2 m (50 ft)                             |
| Working weight (Including upper and lower machine, counter-weights, carbody weights, 50 ft standard boom, hook block) | Approximately 99,000 kg (218,000 lbs)              |                                            |
| Average ground pressure                                                                                               | Approximately 92.9 kPa (13.5 psi)                  |                                            |
| Gradeability (tan $\theta$ )                                                                                          | 30%                                                |                                            |
| Engine                                                                                                                | Hino P11C-UN 247 kw/2000 min. <sup>1</sup>         |                                            |
| Hoist line speed (front and rear drum)                                                                                | 120 m/min. (393 ft/min.)                           |                                            |
| Lowering line speed (front and rear drum)                                                                             | 120 m/min. (393 ft/min.)                           |                                            |
| Boom raising rope speed                                                                                               | 48 m/min. (157 ft/min.)                            |                                            |
| Boom lowering rope speed                                                                                              | 48 m/min. (157 ft/min.)                            |                                            |
| Swing speed                                                                                                           | 3.2 min. <sup>1</sup> (3.2 rpm)                    |                                            |
| Propel speed                                                                                                          | 1.4/1.0 km/h (0.87/0.62 miles/hour)                |                                            |

- 1 The main lifting/lowering rope speed, the auxiliary hoisting/lowering rope speed, and the propel speed vary depending on the load
- 2 The rope speed is of the first layer on the drum

## 1. SPECIFICATION

### 1.1.2 OUTSIDE DIMENSIONS

|                                            |                         |
|--------------------------------------------|-------------------------|
| Height above ground of cab                 | 3 500 mm (11' 5-13/16") |
| Width of upper machine with operator's cab | 3,200 mm (10' 8")       |
| Radius of rear end (with counterweight)    | 5 000 mm (16' 4-7/8")   |
| Counterweight ground clearance             | 1,260 mm (4' 1-5/8")    |
| Center of rotation to boom foot pin        | 1 100 mm (3' 7-5/16")   |
| Height above ground of boom foot pin       | 2,200 mm (7' 2-5/8")    |
| Height to top of gantry (working position) | 7,380 mm (24' 2-9/16")  |
| Overall length of crawlers                 | 6,770 mm (22' 2-1/2")   |
| Distance between centers of tumblers       | 6,800 mm (19' 0-5/16")  |
| Overall width of crawlers (extended)       | 5,300 mm (17' 4-5/8")   |
| Overall of crawler shoe (retracted)        | 4,210 mm (13' 6-3/16")  |
| Width of crawler shoe                      | 900 mm (2' 11-7/16")    |
| Ground clearance of carbody                | 330 mm (1' 1")          |







## 1. SPECIFICATION



### 1.1.3 DIMENSIONS AND WEIGHT OF EACH PARTS

For your reference, the chart below shows the dimensions and weight of each parts.

#### 1 BASE MACHINE

| Name                                                                                                            | Dimension mm (inch)                                                                  | Weight kg (lbs)      |
|-----------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|----------------------|
| Base Machine<br>• With free fall drum<br>• With wire ropes                                                      |    | 60,070<br>(132,430)  |
| Base Machine<br>• Without Crawler<br>• With wire ropes                                                          |   | 36,210<br>(79,830)   |
| Base Machine<br>• Without Crawler<br>• Without gantley<br>• Without boom drum rope<br>• With Fr & Re drum ropes |  | 33,880<br>(74,690)   |
| Base Machine<br>• With boom base<br>• With wire ropes<br>• Without crawler                                      |  | 406,700<br>(896,651) |

**1. SPECIFICATION**







| Name                        | Dimension mm (inch)                                                                                                                                            | Weight kg (lbs)            |
|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|
| Crawler                     |  <p>2770 (22' 2-9/16")</p> <p>900 (2' 7-15/16")</p> <p>1145 (3' 9-1/16")</p> | <p>11 930<br/>(26,300)</p> |
| Transferter<br>(with float) |  <p>1,355 (4' 5-3/8")</p> <p>950 (3' 1-3/16")</p> <p>320 (1' 0-6/16")</p>    | <p>430 (950) / 1 Piece</p> |

# 1. SPECIFICATION








## 2 COUNTERWEIGHT

| Name                     | Dimension, mm (inch) | Weight kg (lbs)    |
|--------------------------|----------------------|--------------------|
| Counterweight (1)        |                      | 10,000<br>(22,050) |
| Counterweight (2)<br>(3) |                      | 7,000<br>(15,435)  |
| Counterweight (4)        |                      | 10,000<br>(22,050) |





## 3. ATTACHMENT

| Name                                  | Dimension mm (inch)                                                                  | Weight kg (lbs)  |
|---------------------------------------|--------------------------------------------------------------------------------------|------------------|
| Upper boom                            |    | 1,525<br>(3,362) |
| Lower boom                            |    | 2,110<br>(4,652) |
| 3.0m (10')<br>Insert boom             |   | 380<br>(838)     |
| 6.1m (20')<br>Insert boom             |  | 655<br>(1,445)   |
| 9.1m (30')<br>Insert boom             |  | 925<br>(2,040)   |
| 9.1m (30')<br>Insert boom<br>With lug |  | 960<br>(2,117)   |

# 1. SPECIFICATION

| Name                                     | Dimension mm (ft-in)                                                                                                                                                                                                                              | Weight kg (lbs)          |
|------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|
| 12.2m (40')<br>Insert boom               |                         | 1,195<br>(2,635)         |
| 12.2m (40')<br>Insert boom<br>(With lug) |  | 1,220<br>(2,690)         |
| Backslap                                 |                                                                                                                                                          | 500/each<br>(1,100/each) |
| Jib tip                                  |                                                                                    | 280<br>(617)             |
| Jib base                                 |                                                 | 200<br>(440)             |
| 3.0m (10')<br>Insert jib                 |                                                              | 100<br>(220)             |
| 6.1m (20')<br>Insert jib                 |                                                              | 180<br>(395)             |



| Name           | Dimension mm (ft-in)                                                                                                                                      | Weight kg (lbs)  |
|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| Strut          |  <p>3,620 (11' 10 1/2")<br/>615 (2' 0-1/2")</p>                         | 250<br>(550)     |
| Gantry         |  <p>1,140 (3' 8-7/8")<br/>5,165 (16' 11 3/8")<br/>760 (2' 5-15/16")</p> | 1,760<br>(3,970) |
| Upper spreader |  <p>1,780 (5' 10 1/16")<br/>800 (2' 7-1/2")<br/>305 (1')</p>           | 300<br>(660)     |
| Lower spreader |  <p>710 (2' 3-15/16")<br/>905 (2' 11-5/16")<br/>255 (10")</p>         | 200<br>(440)     |

## 1. SPECIFICATION

### 1.1.4 STABILITY IN SWINGING AND TRAVELING


#### 1 Without boom base

| Gantry position      | Counter weight (t) | All-round swing  |                                | Propelling |             |
|----------------------|--------------------|------------------|--------------------------------|------------|-------------|
|                      |                    | (A) With crawler | When jacked up Without crawler | Forwarding | Backwarding |
| Low gantry position  | None               | ○                | ○                              | ○          | ○           |
| High gantry position | None               | ○                | ○                              | ○          | ○           |
| Low gantry position  | 10.0 t             | ○                | X                              | ○          | ○           |
| High gantry position | 10.0 t             | ○                | X                              | ○          | ○           |
| Low gantry position  | 17.0 t             | ○                | X                              | ○          | ○           |
| High gantry position | 17.0 t             | ○                | X                              | ○          | ○           |
| Low gantry position  | 24.0 t             | ○                | X                              | ○          | ○           |
| High gantry position | 24.0 t             | ○                | X                              | ○          | ○           |
| Low gantry position  | 34.0 t             | X                | X                              | X          | X           |
| High gantry position | 34.0 t             | X                | X                              | X          | X           |


○ . Operation is available  
X . Operation is unavailable

(A) With crawler


High gantry position




Low gantry position



Jacked up with one crawler



- (1) The table on the previous page above shows the values for operation on a firm ground. On a weak ground, operate with care after curing the ground.
- (2) As a principle, swinging on a trailer is prohibited.
- (3) Maximum slope angle is 16.7 degrees (30%).
- (4) Traveling forward means the case, where the counterweight is at the lower slope and the traveling backward, where it is at the upper slope.



## 1. SPECIFICATION


### 2. With boom base

| Gantry position      | Boom angle          | Counter-weight (t) | ALL-round swing |                                   | Propelling |             |
|----------------------|---------------------|--------------------|-----------------|-----------------------------------|------------|-------------|
|                      |                     |                    | With crawler    | When jacked up<br>Without crawler | Forwarding | Backwarding |
| Low gantry position  | 0 deg. to<br>30 deg | None               | ○               | ○                                 | ○          | ○           |
| High gantry position |                     | None               | ○               | ○                                 | ○          | ○           |
| Low gantry position  |                     | 10.0 t             | ○               | X                                 | ○          | ○           |
| High gantry position |                     | 10.0 t             | ○               | X                                 | ○          | ○           |
| Low gantry position  |                     | 17.0 t             | ○               | X                                 | ○          | ○           |
| High gantry position |                     | 17.0 t             | ○               | X                                 | ○          | ○           |
| Low gantry position  |                     | 24.0 t             | ○               | X                                 | ○          | ○           |
| High gantry position |                     | 24.0 t             | ○               | X                                 | ○          | ○           |
| Low gantry position  |                     | 34.0 t             | X               | X                                 | X          | X           |
| High gantry position |                     | 34.0 t             | X               | X                                 | X          | X           |



○ : Operation is available

X : Operation is unavailable

High gantry position



Low gantry position



---


## **2. MAINTENANCE STANDARDS TEST PROCEDURES**



## 2.1 MAINTENANCE STANDARD

## 2.1.1 PIN, BUSHING, SPRING, LINING AND SHEAVE

## 1. Pin, Bushing



Unit : mm (inch)

| Name    | Location           | Item | Part number   | Std. dimension                    |                  | Usable limit      |                   | Remedy  | See figure         |
|---------|--------------------|------|---------------|-----------------------------------|------------------|-------------------|-------------------|---------|--------------------|
|         |                    |      |               | D                                 | d                | D'                | d'                |         |                    |
| Pawl    | Fr. & Re. Drum     | 2    | GK82W01014P1  | 44.0<br>(1.732)                   |                  | 43.82<br>(1.725)  |                   | Replace | Fig.4-1<br>(P.2-5) |
|         | Boom Drum          | 2    | GB82W01008P1  | 45.0<br>(1.772)                   |                  | 44.82<br>(1.764)  |                   |         | Fig.4-3<br>(P.2-6) |
| Pin     | Brake pedal        | 7    | 2419T6012     | 38.1<br>(1.50)                    |                  | 37.92<br>(1.493)  |                   | Replace | Fig.4-5<br>(P.2-7) |
|         |                    | 8, 9 | 2419T2337D9   | 13.0<br>(0.512)                   |                  | 12.85<br>(0.506)  |                   |         |                    |
|         |                    | 10   | 2419T2337D4   | 13.0<br>(0.512)                   |                  | 12.85<br>(0.506)  |                   |         |                    |
|         |                    | 11   | ZP45X10040    | 10.0<br>(0.394)                   |                  | 9.96<br>(0.392)   |                   |         |                    |
|         |                    | 12   | ZP45X10040    | 10.0<br>(0.394)                   |                  | 9.96<br>(0.392)   |                   |         |                    |
|         | Boom Foot          | 2    | GK03A01068P1  | 114.7 <sup>+0.25</sup><br>(4.516) |                  | 114.04<br>(4.490) |                   | Replace | Fig.4-6<br>(P.2-8) |
| Bushing | Pawl (Front, Rear) | 3    | 2405T1151     |                                   | 44.0<br>(1.732)  |                   | 44.26<br>(1.743)  | Replace | Fig.4-1<br>(P.2-5) |
|         | Pawl (Boom)        | 3    | 2405U101D4540 |                                   | 45.0<br>(1.772)  |                   | 45.27<br>(1.783)  | Replace | Fig.4-3<br>(P.2-6) |
|         | Boom Foot          | 3    | GK52F01057P1  |                                   | 115.0<br>(4.528) |                   | 115.35<br>(4.541) | Replace | Fig.4-6<br>(P.2-8) |

## 2. MAINTENANCE STANDARDS TEST PROCEDURES

### 2. Spring




Unit : mm (inch)

| Location          | Item | Part number  | Std. Free length            | Usable limit of free length | Remedy  | See figure         |
|-------------------|------|--------------|-----------------------------|-----------------------------|---------|--------------------|
| Tr & Re Drum pawl | 5-1  | HP26C15002G1 | 72 (2.835)<br>(Compression) | 68.4<br>(2.693)             | Replace | Fig.4-1<br>(P.2-5) |
| Boom drum pawl    | 5    | HP26C15002G1 | 72 (2.835)<br>(Compression) | 68.4<br>(2.693)             |         | Fig.4-3<br>(P.2-6) |
| Brake pedal       | 5    | 17H286       | 61.5 (2.421)<br>(Tension)   | 63.9<br>(2.516)             |         | Fig.4-5<br>(P.2-7) |



3. Sheave



Unit : mm (inch)

| Equipment        | Item | Part number  | Std. root diameter | Use limit        | Remedy                    | Groove radius      | See figure         |
|------------------|------|--------------|--------------------|------------------|---------------------------|--------------------|--------------------|
| Boom point       | 8    | JL06A01004P1 | 494<br>(19.45)     | 491<br>(19.34)   | Replace<br>or<br>Build-up | 15.5<br>(0.61)     | Fig 4-6<br>(P 2-8) |
| Idler            | 9    | 2407P612     | 549<br>(21.61)     | 546<br>(21.50)   |                           | 15.5<br>(0.61)     |                    |
| Auxiliary sheave | 10   | JL06A01004P1 | 494<br>(19.45)     | 491<br>(19.34)   |                           | 15.5<br>(0.61)     |                    |
| Upper spreader   | 11   | GN64A01002P2 | 381.8<br>(15.00)   | 379.5<br>(14.94) |                           | 11.0<br>(0.43)     | Fig 4-8<br>(P 2-9) |
| Lower spreader   | 5    | GN64A01002P2 | 381.8<br>(15.00)   | 379.5<br>(14.94) |                           | 11.0<br>(0.43)     |                    |
| Jib point        | 12   | 2407P725     | 549<br>(21.61)     | 546<br>(21.50)   |                           | 14.0<br>(0.55)     | Fig 4-7<br>(P 2-8) |
| Jib strut        | 13   |              |                    |                  |                           |                    |                    |
| Gantry peak      | 6    | GK62F01011P1 | 381.8<br>(15.00)   | 379.5<br>(14.94) | 11.5<br>(0.45)            | Fig.4-8<br>(P.2-9) |                    |




Fig.2-1 Front and Rear Dum Lock




Fig.2-2 Pawl (GG82W01005P1)





Fig.2-3 Boom Drum Lock



Wear Limit : 3mm (0.118 inch)

Fig.2-4 Pawl (GG82W01008P1)




Fig.2-5 Brake Pedal




Fig.2-6 Crane Boom




Fig.2-7 Crane Jib






Fig.2-8 Gantry

## 2. MAINTENANCE STANDARDS TEST PROCEDURES

### 2.1.2 PROPEL DEVICE

#### 1. Crawler shoe

GN60D00004P3



Unit : mm (inch)  
Wear limit : 2 mm (0.079 inch)  
Remedy : Build up or replace

Unit : mm (inch)


|              | Std. Dimension | Usable limit | Remedy         |
|--------------|----------------|--------------|----------------|
| Pin hole (D) | Φ45.0 (1.77)   | Φ46.0 (1.81) | Build-up<br>or |
| Pin          | Φ44.45 (1.75)  | Φ4.25 (1.67) |                |
| Pitch (P)    | 228 (8.98)     | 234.6 (9.24) | Replace        |

When 6 pcs shoes are connected by shoe pin and hang vertically, distance between pins should be 1378.0 mm (54.3 inch)



## 2. MAINTENANCE STANDARDS TEST PROCEDURES

### 3. Idler



Unit: mm (inch)

Wear limit: 2mm (0.079 inch)


Remedy: Build up or replace

Unit: mm (inch)

| Symbol | Item                                         | Std. Dimension                         |            |                                  | Usable limit                                                 | Remedy                         |                                |
|--------|----------------------------------------------|----------------------------------------|------------|----------------------------------|--------------------------------------------------------------|--------------------------------|--------------------------------|
| A      | Outer diameter                               | $\phi 785$ (30.9)                      |            |                                  | $\phi 777$ (30.6)                                            | Build-up or Replace            |                                |
| B      | Gap between of shaft and bushing             | Std. Dimension<br>$\phi 110$<br>(4.33) | Shaft      | -0.036 (0.001)<br>-0.071 (0.003) | Standard<br>Gap<br>0.175 (0.007)<br>to<br>0.232 (0.009)      | Allowable<br>Gap<br>1.0 (0.04) | Replace-<br>ment of<br>bushing |
|        |                                              |                                        | Hole       | +0.161 (0.006)<br>+0.139 (0.005) |                                                              |                                |                                |
| C      | Tightening tolerance of sprocket and bushing | $\phi 125$<br>(4.92)                   | Shaft<br>- | +0.117 (0.005)<br>+0.092 (0.004) | Tightening tolerance<br>0.057 (0.002)<br>to<br>0.117 (0.005) | Tightening tolerance<br>0      |                                |



4 Track roller




Unit : mm (inch)

| Symbol | Item                                       | Std. Dimension                        |           |                                  | Usable limit                                                | Remedy                         |                        |
|--------|--------------------------------------------|---------------------------------------|-----------|----------------------------------|-------------------------------------------------------------|--------------------------------|------------------------|
| A      | Outer diameter                             | $\phi 290 \pm 2$ (11.4 $\pm$ 0.08)    |           |                                  | $\phi 282$ (11.1)                                           | Build-up or Replace            |                        |
| B      | Gap between of shaft and bushing           | Std. Dimension<br>$\phi 90$<br>(3.54) | Tolerance |                                  | Standard<br>Gap<br>0.266 (0.01)<br>to<br>0.37 (0.014)       | Allowable<br>Gap<br>0.8 (0.03) | Replacement of bushing |
|        |                                            |                                       | Shaft     | -0.036 (0.001)<br>-0.090 (0.004) |                                                             |                                |                        |
| C      | Tightening tolerance of roller and bushing | $\phi 105$<br>(4.13)                  | Shaft     | +0.12 (0.005)<br>+0.11 (0.004)   | Tightening tolerance<br>0.075 (0.003)<br>to<br>0.12 (0.005) | Tightening tolerance 0         | Replace                |
|        |                                            |                                       | Hole      | +0.035 (0.001)<br>+0             |                                                             |                                |                        |

## 2. MAINTENANCE STANDARDS TEST PROCEDURES



### 5. Guide roller



Unit : mm (inch)

| Symbol | Item           | Std. Dimension | Usable limit | Remedy              |
|--------|----------------|----------------|--------------|---------------------|
| A      | Outer diameter | Φ230 (9.1)     | Φ222 (8.7)   | Build-up or Replace |

6. Guide bar




Unit : mm (inch)

| Symbol | Item                | Std. Dimension | Usable limit | Remedy              |
|--------|---------------------|----------------|--------------|---------------------|
| A      | Height of Guide Bar | 85 (3.35)      | 65 (2.56)    | Build-up or Replace |

## 2. MAINTENANCE STANDARDS TEST PROCEDURES

### 2.1.3 PROPEL BRAKE PLATE



Unit : mm (inch)

| Name of plate   | Number | Std. Dimension (Total) | Wear limit (Total)           | Std Brake torque                      |
|-----------------|--------|------------------------|------------------------------|---------------------------------------|
| Friction plate  | 4      | 22.7 (0.89)            | 21.2 (0.83)                  | 528 to 712 N-m<br>(389 to 525 ft-lbs) |
| Separator plate | 5      |                        | Amount of wear : 1.5 (0.059) |                                       |

**2.2 PERFORMANCE STANDARD AND TEST PROCEDURE**

**1. TERMINOLOGY**

Standard value Standard of assembling new machine,

When the value exceeds the standard, repair or replace the part as required to maintain machine performance and or safety.

Temperature of oil : It means temperature of hydraulic oil.

2 As to the items of which limit of use is not shown, referring to standard value as the guidance, repair or replace the part as required.

**2.2.1 OPERATING SPEED**

| No. | Item                                       | Test Condition                                                                                                                                                                                                                    | Test Procedure                                                                                                                                                                                                          | Standard Value                         |
|-----|--------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------|
| 1   | Boom Hoisting and Lowering wire rope Speed | <ul style="list-style-type: none"> <li>Engine min : High idling</li> <li>Temperature of Hyd. oil : 50°C (113 to 131°F)</li> <li>Boom Length : Std. Boom</li> </ul>                                                                | Measure the time taken to rotate drum 10 times.<br>(Start measuring when the rotation of the drum becomes stable)<br>Take average of 3 times measuring.                                                                 | 17.8 to 20.8 sec.                      |
| 2   | Main and Aux. hoisting wire rope           | <ul style="list-style-type: none"> <li>Engine min : High idling</li> <li>Temperature of Hyd. oil : 50°C (113 to 131°F)</li> <li>Loading : No load</li> </ul>                                                                      | Measure the time taken to rotate drum 10 times.<br>(Start measuring when the rotation of the drum becomes stable)<br>Take average of 3 times measuring                                                                  | 8.7 to 10.3 sec.                       |
| 3   | Swing Speed                                | <ul style="list-style-type: none"> <li>Engine min : High idling</li> <li>Temperature of Hyd. oil : 50°C (113 to 131°F)</li> <li>Boom Length : Standard Boom</li> <li>Loading : No load</li> <li>Swing Mode : Free High</li> </ul> | Measure the time taken to rotate machine one time.<br>Measure the time for 2nd rotation after 1st preliminary rotation.<br>Take average of 3 times measuring.                                                           | 17.8 to 21.2 sec.                      |
| 4   | Propel Speed                               | <ul style="list-style-type: none"> <li>Engine min : High idling</li> <li>Temperature of Hyd. oil : 50°C (113 to 131°F)</li> <li>Boom Length : Std. Boom</li> </ul>                                                                | Measure the time taken to propel machine the distance of 20 m (65.6ft).<br>Propel machine first preliminary more than 2 m (6.6 ft) before starting the measuring.<br>Take average of 3 times measuring.                 | L = 69 to 82 sec.<br>H = 47 to 56 sec. |
| 5   | Propelling Discrepancy                     | <ul style="list-style-type: none"> <li>Engine min : High idling</li> <li>Temperature of Hyd. oil : 50°C (113 to 131°F)</li> <li>Boom Length : Std. Boom</li> </ul>                                                                | Measure the discrepancy volume resulted from propelling the distance of 20 m (65.6 ft).<br>Propel machine first preliminary more than 2 m (6.6 ft) before starting the measuring.<br>Take average of 3 times measuring. | 600 mm<br>(23.62 inch)                 |





## 2. MAINTENANCE STANDARDS TEST PROCEDURES



### 2.2.2 POINT AND METHOD OF MEASURING PRESSURE

Use a pressure gauge which has a surplus of more than 10 MPa (1450 psi) for pressures to be measured and which has passed the inspection.


Prior to pressure measurement, clean the port for pressure measurement so as to be free from oil and dust.

| No.                                                                                           | Item                                  | Test Condition                                                                                                      | Test Procedure                                                                                                                        | Standard Value                                                                                                                                                                                                                                                                                          |                     |
|-----------------------------------------------------------------------------------------------|---------------------------------------|---------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------|
| Connector and hose for measuring pressure.<br>Connector : GB03H01085P1<br>Hose : GG03H01068D1 |                                       |                                                                                                                     |                                                                                                                                       |                                                                                                                                                                                                                                                                                                         |                     |
| 1                                                                                             | Main<br>• Propel Right<br>• Rear Drum | • Engine revolution (min <sup>-1</sup> ): High idling<br>• Temperature of Hydraulic oil : 45 to 55°C (113 to 131°F) | 1. Lower the boom onto the ground<br>2. Lock the rear winch drum.<br>3. Make the valve relieve by rear winch drum lowering operation  |  <p>Diagram showing a hydraulic valve assembly with a pressure gauge port (PF 1/4) and a relief valve. The diagram is a technical drawing of a multi-port valve with various fittings and a central gauge port.</p>  | 31.9 MPa (4622 psi) |
| 2                                                                                             | Main<br>• Propel Left<br>• Front Drum | • Engine revolution (min <sup>-1</sup> ): High idling<br>• Temperature of Hydraulic oil : 45 to 55°C (113 to 131°F) | 1. Lower the main hook onto the ground.<br>2. Lock the main winch drum<br>3. Make the valve relieve by main winch lowering operation. |  <p>Diagram showing a hydraulic valve assembly with a pressure gauge port (PF 1/4) and a relief valve. The diagram is a technical drawing of a multi-port valve with various fittings and a central gauge port.</p> | 31.9 MPa (4622 psi) |

2. MAINTENANCE STANDARDS TEST PROCEDURES

| No.                                                                                  | Item  | Test Condition                                                                                                                                                                                               | Test Procedure                                                                                                                                                                      | Standard Value                   |
|--------------------------------------------------------------------------------------|-------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|
| 3                                                                                    | Boom  | <ul style="list-style-type: none"> <li>• Engine revolution (min<sup>-1</sup>) : High idling</li> <li>• Temperature of Hydraulic oil : 45 to 55°C (113 to 131°F)</li> </ul>                                   | <ol style="list-style-type: none"> <li>1. Lower the boom onto the ground.</li> <li>2. Lock the boom drum.</li> <li>3. Make the valve relieve by boom lowering operation.</li> </ol> | <p>31.9 MPa<br/>(4622.5 psi)</p> |
|    |       |                                                                                                                                                                                                              |                                                                                                                                                                                     |                                  |
| 4                                                                                    | Swing | <ul style="list-style-type: none"> <li>• Engine revolution (min<sup>-1</sup>) : High idling</li> <li>• Temperature of Hydraulic oil : 45 to 55°C (113 to 131°F)</li> <li>• Swing mode : Free high</li> </ul> | <ol style="list-style-type: none"> <li>1. Lock the upper not to turn with the swing lock pin and parking brake.</li> <li>2. Make the valve relieve by swing operation.</li> </ol>   | <p>27.5 MPa<br/>(3982.5 psi)</p> |
|  |       |                                                                                                                                                                                                              |                                                                                                                                                                                     |                                  |

## 2. MAINTENANCE STANDARDS TEST PROCEDURES




| No | Item                               | Test Condition                                                                                                            | Test Procedure                                                                      | Standard Value                                                                                             |
|----|------------------------------------|---------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
| 5  | Control Circuit (Primary pressure) | Temperature of Hydraulic oil : $50^{\circ}\text{C} \pm 5^{\circ}\text{C}$ ( $122^{\circ}\text{F} \pm 9^{\circ}\text{F}$ ) |  | Relief Valve<br>7.0 MPa (1010psi)<br>(High idling)<br>Reduction Valve<br>5.4 MPa (782 psi)<br>(Low idling) |




|          |                                                 |                                                                                                                                                                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|----------|-------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>8</p> | <p>Control Circuit<br/>(Secondary pressure)</p> | <ul style="list-style-type: none"> <li>- Engine revolution (min<sup>-1</sup>)<br/>Low idling</li> <li>- Temperature of Hydraulic oil : 50°C ± 5°C (122°F ± 9°F)</li> </ul> | <p>1. Operate the control lever for the section to be measured<br/>(Operate the speed adjusting knob to the Max. position)<br/>Take pressure out from the quick coupler of the control valve spool end</p> <p style="text-align: center;">Standard value<br/>1st.speed</p> <p>Boom.....<br/>2.50 to 2.79 MPa (362 to 405 psi)</p> <p>Propel.....<br/>1.42 to 1.62 MPa (206 to 235 psi)</p> <p>Swing.....<br/>1.62 to 1.81 MPa (235 to 263 psi)</p> <p>Front &amp; Rear Drum . . .<br/>2.65 to 2.94 MPa (384 to 427 psi)</p> <p>3rd. (Jib)(Op.).....<br/>2.75 to 3.24 MPa (398 to 469 psi)</p> |
|----------|-------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## 2. MAINTENANCE STANDARDS TEST PROCEDURES

| No. | Item                                                                                             | Test Condition                                                                                                                                                       | Test Procedure                                                                                                                                                                                      | Standard Value                      |
|-----|--------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|
| 7   | <ul style="list-style-type: none"> <li>Gantry raising/lowering</li> <li>Lower circuit</li> </ul> | <ul style="list-style-type: none"> <li>Engine revolution (min<sup>-1</sup>): High idling</li> <li>Temperature of Hydraulic oil : 50°C ± 5°C (122°F ± 9°F)</li> </ul> | <ol style="list-style-type: none"> <li>Relief by raising the gantry cylinder.</li> <li>Relief by lowering the gantry cylinder.</li> <li>Relief by operating crawler fixing pin cylinder.</li> </ol> | Raise : 20.6 MPa (2987 psi)         |
|     |                                                                                                  |                                                                                                                                                                      |                                                                                                                                                                                                     | Lower : 4.9 MPa (711 psi)           |
|     |                                                                                                  |                                                                                                                                                                      |                                                                                                                                                                                                     | Lower Circuit : 20.6 MPa (2986 psi) |



2.2.3 SLEWING RING



COUNTERWEIGHT . 34 t Counterweight

| Measuring Condition          | Amount of play             |
|------------------------------|----------------------------|
| Boom length : 15.2 m (50 ft) | Less than 3 mm (0.21 inch) |
| Radius : 9.14 m (30 ft)      |                            |
| Load : 36.8 t (82500 lbs)    |                            |



---

## **3. GENERAL WORK STANDARD**



### 3.1 TIGHTENING TORQUE OF CAPSCREWS AND NUTS

Unless otherwise specified, torque all screws and nuts on this machine to the values shown in the following tables.

#### 3.1.1 METRIC COARSE THREADS

Unit : kg-m (ft-lbs)

| Nominal size | Classification        |             |              |              |              |              |
|--------------|-----------------------|-------------|--------------|--------------|--------------|--------------|
|              | Metric Coarse Threads |             |              |              |              |              |
|              | 4T                    |             | 7T           |              | 10T          |              |
|              | Dry                   | Lubricated  | Dry          | Lubricated   | Dry          | Lubricated   |
| M 6          | 0.45 (3.25)           | 0.38 (2.75) | 0.9 (6.51)   | 0.8 (5.79)   | 1.7 (12.3)   | 1.5 (10.9)   |
| M 8          | 1.09 (7.88)           | 0.9 (6.51)  | 2.4 (17.4)   | 2.0 (14.5)   | 4.3 (31.1)   | 3.6 (26.0)   |
| M10          | 2.2 (15.9)            | 1.8 (13.0)  | 4.7 (34.0)   | 4.0 (28.9)   | 8.5 (61.5)   | 7.2 (52.1)   |
| M12          | 3.7 (26.8)            | 3.2 (23.2)  | 8.1 (58.6)   | 6.8 (49.2)   | 14.6 (106)   | 12.3 (89.0)  |
| M14          | 5.9 (42.7)            | 5.0 (36.2)  | 12.8 (92.6)  | 10.8 (78.1)  | 23.0 (166)   | 19.5 (141)   |
| M16          | 9.0 (65.1)            | 7.6 (55.0)  | 19.5 (141)   | 16.4 (119)   | 35.0 (253)   | 29.0 (210)   |
| M18          | 12.4 (89.7)           | 10.5 (76.0) | 27.0 (195)   | 23.0 (166)   | 49.0 (354)   | 41.0 (297)   |
| M20          | 17.5 (127)            | 14.7 (106)  | 36.0 (275)   | 32.0 (232)   | 68.0 (492)   | 57.0 (412)   |
| M22          | 23.0 (166)            | 19.6 (142)  | 51.0 (369)   | 43.0 (311)   | 92.0 (665)   | 77.0 (557)   |
| M24          | 30.0 (217)            | 24.0 (174)  | 65.0 (470)   | 53.0 (383)   | 118.0 (854)  | 96.0 (694)   |
| M27          | 44.0 (318)            | 36.0 (260)  | 96.0 (694)   | 78.0 (564)   | 173.0 (1251) | 140.0 (1012) |
| M30          | 60.0 (434)            | 50.0 (362)  | 131.0 (948)  | 110.0 (796)  | -            | -            |
| M33          | 81.0 (586)            | 68.0 (492)  | 176.0 (1273) | 148.0 (1070) | -            | -            |
| M36          | 105.0 (760)           | 88.0 (637)  | -            | -            | -            | -            |

#### 3.1.2 METRIC FINE THREADS

Unit : kg-m (ft-lbs)

| Nominal size | Classification |            |              |             |             |             |
|--------------|----------------|------------|--------------|-------------|-------------|-------------|
|              | Fine Threads   |            |              |             |             |             |
|              | 4T             |            | 7T           |             | 10T         |             |
|              | Dry            | Lubricated | Dry          | Lubricated  | Dry         | Lubricated  |
| M 6          | 1.1 (7.96)     | 0.4 (2.89) | 2.5 (15.2)   | 2.1 (15.2)  | 4.5 (32.8)  | 3.8 (27.5)  |
| M10          | 2.3 (16.6)     | 1.9 (13.7) | 4.9 (35.4)   | 4.2 (30.4)  | 8.9 (64.4)  | 7.5 (54.3)  |
| M12          | 4.0 (28.9)     | 3.4 (24.5) | 8.7 (62.9)   | 7.3 (52.8)  | 15.7 (114)  | 13.2 (95.5) |
| M16          | 9.0 (65.1)     | 7.3 (52.8) | 20.0 (145)   | 17.2 (124)  | 37.0 (268)  | 31.0 (224)  |
| M20          | 19.0 (137)     | 15.8 (114) | 41.0 (297)   | 34.0 (246)  | 74.0 (535)  | 62.0 (448)  |
| M24          | 32.0 (232)     | 27.0 (195) | 70.0 (506)   | 58.0 (405)  | 126.0 (911) | 105.0 (760) |
| M30          | 65.0 (470)     | 54.0 (391) | 142.0 (1027) | 118.0 (854) | -           | -           |
| M36          | 109.0 (788)    | 91.0 (658) | -            | -           | -           | -           |

### 3. GENERAL WORK STANDARD

#### 3.1.3 COARSE THREADS UNC

Unit : kg-m (ft-lbs)

| Nominal size | Classification     |             |              |              |              |              |
|--------------|--------------------|-------------|--------------|--------------|--------------|--------------|
|              | Coarse Threads UNC |             |              |              |              |              |
|              | Grade 2            |             | Grade 5      |              | Grade 8      |              |
|              | Dry                | Lubricated  | Dry          | Lubricated   | Dry          | Lubricated   |
| 1/4          | 0.8 (5.79)         | 0.7 (5.06)  | 1.3 (9.40)   | 1.1 (7.96)   | 1.8 (13.0)   | 1.5 (10.8)   |
| 5/16         | 1.6 (11.6)         | 1.4 (10.1)  | 2.6 (18.8)   | 2.2 (15.9)   | 3.6 (26.0)   | 3.1 (22.4)   |
| 3/8          | 2.9 (21.0)         | 2.4 (17.4)  | 4.5 (32.6)   | 3.8 (27.5)   | 6.3 (45.6)   | 5.3 (38.3)   |
| 7/16         | 4.5 (32.5)         | 3.8 (27.5)  | 7.0 (50.6)   | 5.9 (42.7)   | 9.9 (71.6)   | 8.3 (60.0)   |
| 1/2          | 7.0 (50.6)         | 5.9 (42.7)  | 10.8 (78.1)  | 9.1 (65.8)   | 15.2 (110)   | 12.8 (92.6)  |
| 9/16         | 10.0 (72.3)        | 8.4 (60.8)  | 15.5 (112)   | 13.0 (94.0)  | 22.0 (159)   | 18.4 (133)   |
| 5/8          | 14.0 (101)         | 11.8 (85.3) | 22.0 (159)   | 18.2 (132)   | 31.0 (224)   | 26.0 (188)   |
| 3/4          | 25.0 (181)         | 21.0 (152)  | 38.0 (275)   | 32.0 (232)   | 54.0 (391)   | 45.0 (325)   |
| 7/8          | 29.0 (210)         | 25.0 (181)  | 61.0 (441)   | 51.0 (369)   | 86.0 (622)   | 72.0 (521)   |
| 1            | 35.0 (253)         | 30.0 (217)  | 91.0 (658)   | 76.0 (550)   | 128.0 (926)  | 108.0 (781)  |
| 1 1/8        | 51.0 (369)         | 43.0 (311)  | 114.0 (825)  | 95.0 (687)   | 184.0 (1331) | 154.0 (1114) |
| 1 1/4        | 71.0 (514)         | 59.0 (427)  | 159.0 (1150) | 133.0 (962)  | 257.0 (1859) | 216.0 (1562) |
| 1 3/8        | 93.0 (673)         | 78.0 (564)  | 209.0 (1512) | 175.0 (1266) | 338.0 (2445) | 284.0 (2054) |
| 1 1/2        | 124.0 (897)        | 104.0 (752) | 277.0 (2004) | 232.0 (1678) | 449.0 (3248) | 376.0 (2720) |

#### 3.1.4 FINE THREADS UNF

Unit : kg-m (ft-lbs)

| Nominal size | Fine Threads UNF |             |              |              |              |              |
|--------------|------------------|-------------|--------------|--------------|--------------|--------------|
|              | Grade 2          |             | Grade 5      |              | Grade 8      |              |
|              | Dry              | Lubricated  | Dry          | Lubricated   | Dry          | Lubricated   |
| 1/4          | 0.9 (6.51)       | 0.8 (5.79)  | 1.4 (10.1)   | 1.2 (8.68)   | 2.1 (15.2)   | 1.7 (12.3)   |
| 5/16         | 1.8 (13.2)       | 1.5 (10.8)  | 2.8 (20.3)   | 2.4 (17.4)   | 4.0 (28.9)   | 3.4 (24.6)   |
| 3/8          | 3.2 (23.1)       | 2.7 (19.5)  | 4.9 (35.4)   | 4.1 (29.7)   | 7.0 (50.6)   | 5.8 (42.0)   |
| 7/16         | 5.0 (36.2)       | 4.2 (30.4)  | 7.7 (55.7)   | 6.4 (46.3)   | 10.8 (78.1)  | 9.1 (65.8)   |
| 1/2          | 7.7 (55.7)       | 6.4 (46.3)  | 11.9 (86.1)  | 9.9 (71.6)   | 16.8 (122)   | 14.0 (101)   |
| 9/16         | 10.9 (78.8)      | 9.2 (66.5)  | 16.9 (122)   | 14.1 (102)   | 24.0 (174)   | 19.9 (144)   |
| 5/8          | 15.5 (112)       | 12.9 (93.3) | 24.0 (174)   | 20.0 (145)   | 34.0 (246)   | 28.0 (203)   |
| 3/4          | 27.0 (195)       | 22.0 (159)  | 42.0 (304)   | 35.0 (253)   | 58.0 (420)   | 49.0 (354)   |
| 7/8          | 31.0 (224)       | 25.0 (181)  | 66.0 (477)   | 55.0 (398)   | 93.0 (673)   | 77.0 (557)   |
| 1            | 38.0 (275)       | 31.0 (224)  | 98.0 (709)   | 82.0 (593)   | 138.0 (998)  | 115.0 (832)  |
| 1 1/8        | 56.0 (405)       | 46.0 (333)  | 124.0 (897)  | 104.0 (752)  | 201.0 (1454) | 168.0 (1215) |
| 1 1/4        | 77.0 (557)       | 64.0 (463)  | 153.0 (1107) | 143.0 (1034) | 279.0 (2018) | 232.0 (1678) |
| 1 3/8        | 103.0 (745)      | 86.0 (622)  | 231.0 (1671) | 192.0 (1389) | 374.0 (2705) | 311.0 (2249) |
| 1 1/2        | 136.0 (984)      | 113.0 (817) | 304.0 (2199) | 253.0 (1830) | 493.0 (3566) | 410.0 (2966) |




### 3.1.5 TIGHTENING TORQUE OF HYDRAULIC FITTINGS

Excessive or insufficient tightening of hose or tube fittings can cause oil leak and deformation or damage to the metal fittings.


Therefore, to secure and obtain good fixing and performance of fittings it is necessary to tighten to the proper torque. The follows are the recommended torques.

#### 1. BITE TYPE TUBE FITTINGS.


| Size in mm (inch)<br>(Outside diameter X thickness) | Tightening torque in |              | Remarks                                                                                                                                |
|-----------------------------------------------------|----------------------|--------------|----------------------------------------------------------------------------------------------------------------------------------------|
|                                                     | kg-m                 | (ft-lbs)     |                                                                                                                                        |
| 10 (0.364) X 1.5 (0.059)                            | 5 to 7               | (36 to 51)   |  <p>Condition after Tightening<br/>0.2mm (0.01")</p> |
| 15 (0.591) X 2.0 (0.079)                            | 13 to 16             | (94 to 116)  |                                                                                                                                        |
| 18 (0.709) X 2.5 (0.098)                            | 16 to 17             | (116 to 123) |                                                                                                                                        |
| 22 (0.866) X 3.0 (0.118)                            | 20 to 22             | (145 to 159) |                                                                                                                                        |
| 28 (1.102) X 4.0 (0.157)                            | 25 to 29             | (181 to 210) |                                                                                                                                        |
| 35 (1.378) X 5.0 (0.197)                            | 33 to 36             | (239 to 260) |                                                                                                                                        |

#### 2. SPLIT FLANGES

(From SAE Standard)

| Size   | Tightening torque in kg-m (ft-lbs) |                                    | Remarks                                                                               |
|--------|------------------------------------|------------------------------------|---------------------------------------------------------------------------------------|
|        | 3000 psi (210 kg/cm <sup>2</sup> ) | 6000 psi (420 kg/cm <sup>2</sup> ) |                                                                                       |
| 1/2"   | 2 to 2.6                           | (14.5 to 19)                       |  |
| 3/4"   | 2.9 to 4.0                         | (21 to 29)                         |                                                                                       |
| 1"     | 3.75 to 4.9                        | (27 to 35)                         |                                                                                       |
| 1 1/4" | 4.9 to 6.3                         | (35 to 45)                         |                                                                                       |
| 1 1/2" | 6.3 to 8.0                         | (45 to 58)                         |                                                                                       |
| 2"     | 7.5 to 9.5                         | (54 to 69)                         |                                                                                       |
| 2"     | 27.6 to 30.0                       | (200 to 217)                       |                                                                                       |

#### 3. FLARE TYPE TUBE FITTINGS (30° FLARE, PF THREADS)

| Size   | Tightening torque in kg-m (ft-lbs) | Remarks                                                                              |
|--------|------------------------------------|--------------------------------------------------------------------------------------|
| 1/4"   | 2.5 to 3.5 (18 to 25)              |  |
| 3/8"   | 5 to 7 (36 to 51)                  |                                                                                      |
| 1/2"   | 6 to 8 (43 to 58)                  |                                                                                      |
| 3/4"   | 12 to 16 (87 to 116)               |                                                                                      |
| 1"     | 15 to 19 (108 to 137)              |                                                                                      |
| 1 1/4" | 17 to 23 (123 to 166)              |                                                                                      |
| 1 1/2" | 22 to 28 (159 to 202)              |                                                                                      |
| 2"     | 26 to 34 (188 to 246)              |                                                                                      |

### 3. GENERAL WORK STANDARD



#### 4. Jubilee Clip (Low Pressure and Suction)

| Nominal cord | Ø ameter          |           | Recommended torque |        | Working pressure range |     |
|--------------|-------------------|-----------|--------------------|--------|------------------------|-----|
|              | inches            | mm        | kg-cm              | in-lbs | kg/cm <sup>2</sup>     | psi |
| BS5315       |                   |           |                    |        |                        |     |
| 12           | 3/8" - 1/2"       | 9.5 - 12  | 34.5               | 29.9   | 56.0                   | 796 |
| 16           | 1/2" - 5/8"       | 11 - 16   | 34.5               | 29.9   | 56.0                   | 796 |
| 20           | 1/2" - 3/4"       | 13 - 20   | 34.5               | 29.9   | 56.0                   | 796 |
| 22           | 5/8" - 7/8"       | 16 - 22   | 45.7               | 39.7   | 56.0                   | 796 |
| 25           | 3/4" - 1"         | 18 - 25   | 45.7               | 39.7   | 56.0                   | 796 |
| 30           | 7/8" - 1 1/8"     | 22 - 30   | 45.7               | 39.7   | 56.0                   | 796 |
| 35           | 1" - 1 3/8"       | 25 - 35   | 45.7               | 39.7   | 56.0                   | 796 |
| 40           | 1 1/8" - 1 5/8"   | 27 - 40   | 45.7               | 39.7   | 35.0                   | 498 |
| 50           | 1 1/4" - 1 7/8"   | 35 - 50   | 45.7               | 39.7   | 35.0                   | 498 |
| 55           | 1 1/2" - 2 1/8"   | 40 - 55   | 60.4               | 52.4   | 21.0                   | 299 |
| 60           | 1 3/4" - 2 3/8"   | 45 - 60   | 60.4               | 52.4   | 21.0                   | 299 |
| 70           | 2" - 2 3/4"       | 55 - 70   | 60.4               | 52.4   | 16.8                   | 239 |
| 80           | 2 3/8" - 3 1/8"   | 60 - 80   | 60.4               | 52.4   | 16.8                   | 239 |
| 90           | 2 3/4" - 3 1/2"   | 70 - 90   | 69.0               | 59.9   | 16.8                   | 239 |
| 100          | 3 1/4" - 4"       | 85 - 100  | 69.0               | 59.9   | 16.8                   | 239 |
| 120          | 3 3/4" - 4 1/2"   | 90 - 120  | 69.0               | 59.9   | 10.5                   | 140 |
| 140          | 4 1/8" - 5 1/2"   | 110 - 140 | 69.0               | 59.9   | 10.5                   | 140 |
| 150          | 5" - 5 3/4"       | 130 - 150 | 69.0               | 59.9   | 10.5                   | 140 |
| 165          | 5 1/4" - 6 1/2"   | 135 - 165 | 69.0               | 59.9   | 9.8                    | 139 |
| 190          | 6 1/4" - 7 1/2"   | 160 - 190 | 69.0               | 59.9   | 9.8                    | 139 |
| 215          | 7 1/4" - 8 1/2"   | 185 - 215 | 78.0               | 67.7   | 9.0                    | 128 |
| 240          | 8 1/4" - 9 1/2"   | 205 - 240 | 78.0               | 67.7   | 9.0                    | 128 |
| 270          | 9 1/4" - 10 1/2"  | 235 - 270 | 78.0               | 67.7   | 9.0                    | 128 |
| 290          | 10 1/4" - 11 1/2" | 255 - 290 | 78.0               | 67.7   | 9.0                    | 128 |
| 320          | 11 1/4" - 12 1/2" | 285 - 320 | 78.0               | 67.7   | 9.0                    | 128 |

## 3.2 STANDARD PARTS

### 3.2.1 BOLT

Size and kind of bolt can be identified as shown below.



Showing strength and kind of bolt  
 11,16 : shows 4T  
 12,17 shows 7T  
 13,18 shows 10T  
 shows hexagon socket head bolt.

Some bolts are stamped strength class on the heads.


|                |  |                |  |                |  |
|----------------|--|----------------|--|----------------|--|
| 4T             |  | 7T             |  | 10T            |  |
| ZS11F<br>ZS16C |  | ZS12F<br>ZS17C |  | ZS13F<br>ZS18C |  |

### 3. GENERAL WORK STANDARD

#### 3.2.2 O-RING




Size and kind of O-Ring are identified as shown below.

ZD ●● P ●●● 0 0




3.2.3 BACK-UP RING

Size and kind of back-up ring are identified as shown below.




### 3. GENERAL WORK STANDARD


#### 3.2.4 BITE FITTING




| Nominal Diameter | Made by IHARA KOHATSU<br>(ZF) | Made by NIHON AMC<br>(ZA) | Made by NIHON AMC<br>(ZK) |
|------------------|-------------------------------|---------------------------|---------------------------|
| 10               | ZF83H10000                    | ZA82P10000                | ZK82P10000                |
| 15               | ZF83H15000                    | ZA82P15000                | ZK82P15000                |
| 18               | ZF83H18000                    | ZA82P18000                | ZK82P18000                |
| 22               | ZF83H22000                    | ZA82P22000                | ZK82P22000                |
| 28               | ZF83H28000                    | ZA82P28000                | ZK82P28000                |
| 35               | ZF83H35000                    | ZA82P35000                | ZK82P35000                |



| Nominal Diameter | Made by IHARA KOHATSU<br>(ZF) | Made by NIHON AMC<br>(ZA) | Made by NIHON AMC<br>(ZK) |
|------------------|-------------------------------|---------------------------|---------------------------|
| 10               | ZF83P10000                    | ZA83P10000                | ZK83P10000                |
| 15               | ZF83P15000                    | ZA83P15000                | ZK83P15000                |
| 18               | ZF83P18000                    | ZA83P18000                | ZK83P18000                |
| 22               | ZF83P22000                    | ZA83P22000                | ZK83P22000                |
| 28               | ZF83P28000                    | ZA83P28000                | ZK83P28000                |
| 35               | ZF83P35000                    | ZA83P35000                | ZK83P35000                |



| Nominal Diameter | Made by IHARA KOHATSU (ZF) | Made by NIHON AMC (ZA) | Made by NIHON AMC (ZK) |
|------------------|----------------------------|------------------------|------------------------|
| 10               | ZF93N10000                 | ZA93N10000             | ZK93N10000             |
| 15               | ZF93N15000                 | ZA93N15000             | ZK93N15000             |
| 18               | ZF93N18000                 | ZA93N18000             | ZK93N18000             |
| 22               | ZF93N22000                 | ZA93N22000             | ZK93N22000             |
| 28               | ZF93N28000                 | ZA93N28000             | ZK93N28000             |
| 35               | ZF93N35000                 | ZA93N35000             | ZK93N35000             |



| Nominal Diameter | Made by IHARA KOHATSU (ZF) | Made by NIHON AMC (ZA) | Made by NIHON AMC (ZK) |
|------------------|----------------------------|------------------------|------------------------|
| 10               | ZF93S10000                 | ZA93S10000             | ZK93S10000             |
| 15               | ZF93S15000                 | ZA93S15000             | ZK93S15000             |
| 18               | ZF93S18000                 | ZA93S18000             | ZK93S18000             |
| 22               | ZF93S22000                 | ZA93S22000             | ZK93S22000             |
| 28               | ZF93S28000                 | ZA93S28000             | ZK93S28000             |
| 35               | ZF93S35000                 | ZA93S35000             | ZK93S35000             |

## Tightening torque ZE・ZA Type

| Nominal Diameter                   | 10                | 15                | 18                  | 22                   | 28                   | 35                   |
|------------------------------------|-------------------|-------------------|---------------------|----------------------|----------------------|----------------------|
| Tightening Torque<br>kg-m (ft-lbs) | 6 ± 1<br>(43 ± 7) | 9 ± 1<br>(65 ± 7) | 12 ± 2<br>(87 ± 14) | 17 ± 2<br>(123 ± 14) | 22 ± 2<br>(160 ± 14) | 28 ± 3<br>(200 ± 20) |

## Tightening torque ZK Type

| Nominal Diameter                   | 10                | 15                | 18                  | 22                   | 28                   | 35                   |
|------------------------------------|-------------------|-------------------|---------------------|----------------------|----------------------|----------------------|
| Tightening Torque<br>kg-m (ft-lbs) | 6 ± 1<br>(43 ± 7) | 9 ± 1<br>(65 ± 7) | 12 ± 2<br>(87 ± 14) | 17 ± 2<br>(123 ± 14) | 22 ± 2<br>(160 ± 14) | 28 ± 3<br>(200 ± 20) |

### 3. GENERAL WORK STANDARD

#### 3.3 CONVERSION TABLE

##### 3.3.1 UNIT CONVERSION

[ Remarks ] Figures in ( ) show number of zero down a decimal point

Example 0 (2)1 = 0.001

##### 1 Length

| Unit | mm        | cm        | m       | km        | in      | ft        | yd        | mile      |
|------|-----------|-----------|---------|-----------|---------|-----------|-----------|-----------|
| mm   | 1         | 0.1       | 0.001   | 0.00001   | 0.03937 | 0.0032808 | 0.0010936 | 0.(6)6214 |
| cm   | 10        | 1         | 0.01    | 0.0001    | 0.3937  | 0.032808  | 0.010936  | 0.(5)6214 |
| m    | 1000      | 100       | 1       | 0.001     | 39.37   | 3.28083   | 1.0936    | 0.(3)6214 |
| km   | ...       | 100000    | 1000    | 1         | 39370   | 3280.83   | 1093.61   | 0.62137   |
| in   | 25.40     | 2.540     | 0.0254  | 0.(4)254  | 1       | 0.0833    | 0.02778   | 0.(4)1578 |
| ft   | 304.8     | 30.48     | 0.3048  | 0.(3)3048 | 12      | 1         | 0.3333    | 0.(3)1894 |
| yd   | 914.4     | 91.44     | 0.9144  | 0.(3)9144 | 36      | 3         | 1         | 0.(3)5682 |
| mile | 1609347.0 | 160934.70 | 1609.35 | 1.60935   | 63360   | 5280      | 1760      | 1         |

##### 2. Capacity

| Unit            | cm <sup>3</sup> | m <sup>3</sup> | ltr.    | kltr.     | in <sup>3</sup> | ft <sup>3</sup> | yd <sup>3</sup> | gal       |
|-----------------|-----------------|----------------|---------|-----------|-----------------|-----------------|-----------------|-----------|
| cm <sup>3</sup> | 1               | 0.(5)1         | 0.001   | 0.(5)1    | 0.06102         | 0.(4)3531       | 0.(5)1308       | 0.(3)2642 |
| m <sup>3</sup>  | 1000000         | 1              | 1000    | 1         | 61020           | 35.31           | 1.308           | 264.2     |
| ltr.            | 1000            | 0.001          | 1       | 0.001     | 61.02           | 0.03531         | 0.01308         | 0.2642    |
| kltr.           | 1000000         | 1              | 1000    | 1         | 61020           | 35.31           | 1.308           | 264.2     |
| in <sup>3</sup> | 16.39           | 0.(4)1639      | 0.01639 | 0.(4)1639 | 1               | 0.(3)5787       | 0.(4)2143       | 0.004429  |
| ft <sup>3</sup> | 28320           | 0.02832        | 28.32   | 0.02832   | 1728            | 1               | 0.03704         | 7.48055   |
| yd <sup>3</sup> | 764500          | 0.7645         | 764.5   | 0.7645    | 46660           | 27              | 1               | 201.974   |
| gal             | 3785            | 0.003785       | 3.785   | 0.003785  | 231             | 0.1337          | 0.004951        | 1         |

##### 3 Weight

| Unit | kg      | oz      | lb      | (2000 lbs) mt | (2240 lbs) gt | mt        |
|------|---------|---------|---------|---------------|---------------|-----------|
| kg   | 1       | 35.2740 | 2.20462 | 0.001102      | 0.(3)9842     | 0.001     |
| oz   | 0.02835 | 1       | 0.06250 | 0.(4)3125     | 0.(4)2790     | 0.(4)2835 |
| lb   | 0.45359 | 16      | 1       | 0.00050       | 0.(3)4460     | 0.(3)4536 |
| mt   | 907.185 | 32000   | 2000    | 1             | 0.89286       | 0.90719   |
| gt   | 1016.05 | 35840   | 2240    | 1.12          | 1             | 1.01605   |
| mt   | 1000    | 35274   | 2204.6  | 1.10231       | 0.98421       | 1         |

[ Remarks ] mt : ton (Metric) mt : ton (U.S. unit) gt : (British Unit)



## 3.3.2 MILLIMETER : INCH CONVERSION TABLE

1. 1mm to 99mm

| mm | 0      | 1      | 2      | 3      | 4      | 5      | 6      | 7      | 8      | 9      |
|----|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| 0  | 0.0000 | 0.0394 | 0.0787 | 0.1181 | 0.1575 | 0.1969 | 0.2362 | 0.2756 | 0.3150 | 0.3543 |
| 10 | 0.3937 | 0.4331 | 0.4724 | 0.5118 | 0.5512 | 0.5906 | 0.6299 | 0.6693 | 0.7037 | 0.7480 |
| 20 | 0.7874 | 0.8268 | 0.8661 | 0.9055 | 0.9449 | 0.9843 | 1.0236 | 1.0630 | 1.1024 | 1.1417 |
| 30 | 1.1811 | 1.2205 | 1.2598 | 1.2992 | 1.3386 | 1.3780 | 1.4173 | 1.4567 | 1.4961 | 1.5354 |
| 40 | 1.5748 | 1.6142 | 1.6536 | 1.6929 | 1.7323 | 1.7717 | 1.8110 | 1.8504 | 1.8898 | 1.9291 |
| 50 | 1.9685 | 2.0079 | 2.0472 | 2.0866 | 2.1260 | 2.1654 | 2.2047 | 2.2441 | 2.2835 | 2.3228 |
| 60 | 2.3622 | 2.4016 | 2.4409 | 2.4803 | 2.5197 | 2.5591 | 2.5984 | 2.6378 | 2.6772 | 2.7165 |
| 70 | 2.7559 | 2.7953 | 2.8346 | 2.8740 | 2.9134 | 2.9528 | 2.9921 | 3.0315 | 3.0709 | 3.1102 |
| 80 | 3.1496 | 3.1890 | 3.2283 | 3.2677 | 3.3071 | 3.3465 | 3.3858 | 3.4252 | 3.4646 | 3.5039 |
| 90 | 3.5433 | 3.5827 | 3.6220 | 3.6614 | 3.7008 | 3.7402 | 3.7795 | 3.8189 | 3.8583 | 3.8976 |

25.4mm = 1 in

### 3. GENERAL WORK STANDARD

#### 2. Inch Fraction-Millimeter

| in    | 0      | 1      | 2      | 3       | 4       | 5       | 6       | 7       | 8       | 9       |
|-------|--------|--------|--------|---------|---------|---------|---------|---------|---------|---------|
|       | mm     |        |        |         |         |         |         |         |         |         |
| 0     | 0.000  | 25.400 | 50.800 | 76.200  | 101.600 | 127.000 | 152.400 | 177.800 | 203.200 | 228.600 |
| 1/64  | 0.397  | 25.797 | 51.197 | 76.597  | 101.997 | 127.397 | 152.797 | 178.197 | 203.597 | 228.997 |
| 1/32  | 0.794  | 26.194 | 51.594 | 76.994  | 102.394 | 127.794 | 153.194 | 178.594 | 203.994 | 229.394 |
| 1/16  | 1.588  | 26.988 | 52.388 | 77.788  | 103.188 | 128.588 | 153.988 | 179.388 | 204.788 | 230.188 |
| 3/32  | 2.381  | 27.781 | 53.181 | 78.581  | 103.981 | 129.381 | 154.781 | 180.181 | 205.581 | 230.981 |
| 1/8   | 3.175  | 28.575 | 53.975 | 79.375  | 104.775 | 130.175 | 155.575 | 180.975 | 206.375 | 231.775 |
| 5/32  | 3.969  | 29.369 | 54.769 | 80.169  | 105.569 | 130.969 | 156.369 | 181.769 | 207.169 | 232.569 |
| 3/16  | 4.763  | 30.163 | 55.563 | 80.963  | 106.363 | 131.763 | 157.163 | 182.563 | 207.963 | 233.363 |
| 7/32  | 5.556  | 30.956 | 56.356 | 81.756  | 107.156 | 132.556 | 157.956 | 183.356 | 208.756 | 234.156 |
| 1/4   | 6.350  | 31.750 | 57.150 | 82.550  | 107.950 | 133.350 | 158.750 | 184.150 | 209.550 | 234.950 |
| 9/32  | 7.144  | 32.544 | 57.944 | 83.344  | 108.744 | 134.144 | 159.544 | 184.944 | 210.344 | 235.744 |
| 5/16  | 7.938  | 33.338 | 58.738 | 84.138  | 109.538 | 134.938 | 160.338 | 185.738 | 211.138 | 236.538 |
| 11/32 | 8.731  | 34.131 | 59.531 | 84.931  | 110.331 | 135.731 | 161.131 | 186.531 | 211.931 | 237.331 |
| 3/8   | 9.525  | 34.925 | 60.325 | 85.725  | 111.125 | 136.525 | 161.925 | 187.325 | 212.725 | 238.125 |
| 13/32 | 10.319 | 35.719 | 61.119 | 86.519  | 111.919 | 137.319 | 162.719 | 188.119 | 213.519 | 238.919 |
| 7/16  | 11.113 | 36.513 | 61.913 | 87.313  | 112.713 | 138.113 | 163.513 | 188.913 | 214.313 | 239.713 |
| 15/32 | 11.906 | 37.306 | 62.706 | 88.106  | 113.506 | 138.906 | 164.306 | 189.706 | 215.106 | 240.506 |
| 1/2   | 12.700 | 38.100 | 63.500 | 88.900  | 114.300 | 139.700 | 165.100 | 190.500 | 215.900 | 241.300 |
| 17/32 | 13.494 | 38.894 | 64.294 | 89.694  | 115.094 | 140.494 | 165.894 | 191.294 | 216.694 | 242.094 |
| 9/16  | 14.288 | 39.688 | 65.088 | 90.488  | 115.888 | 141.288 | 166.688 | 192.088 | 217.488 | 242.888 |
| 19/32 | 15.081 | 40.481 | 65.881 | 91.281  | 116.681 | 142.081 | 167.481 | 192.881 | 218.281 | 243.681 |
| 5/8   | 15.875 | 41.275 | 66.675 | 92.075  | 117.475 | 142.875 | 168.275 | 193.675 | 219.075 | 244.475 |
| 21/32 | 16.669 | 42.069 | 67.469 | 92.869  | 118.269 | 143.669 | 169.069 | 194.469 | 219.869 | 245.269 |
| 11/16 | 17.463 | 42.863 | 68.263 | 93.663  | 119.063 | 144.463 | 169.863 | 195.263 | 220.663 | 246.063 |
| 23/32 | 18.256 | 43.656 | 69.056 | 94.456  | 119.856 | 145.256 | 170.656 | 196.056 | 221.456 | 246.856 |
| 3/4   | 19.050 | 44.450 | 69.850 | 95.250  | 120.650 | 146.050 | 171.450 | 196.850 | 222.250 | 247.650 |
| 25/32 | 19.844 | 45.244 | 70.644 | 96.044  | 121.444 | 146.844 | 172.244 | 197.644 | 223.044 | 248.444 |
| 13/16 | 20.638 | 46.038 | 71.438 | 96.838  | 122.238 | 147.638 | 173.038 | 198.438 | 223.838 | 249.238 |
| 27/32 | 21.431 | 46.831 | 72.231 | 97.631  | 123.031 | 148.431 | 173.831 | 199.231 | 224.631 | 250.031 |
| 7/8   | 22.225 | 47.625 | 73.025 | 98.425  | 123.825 | 149.225 | 174.625 | 200.025 | 225.425 | 250.825 |
| 29/32 | 23.019 | 48.419 | 73.819 | 99.219  | 124.619 | 150.019 | 175.419 | 200.819 | 226.219 | 251.619 |
| 15/16 | 23.813 | 49.213 | 74.613 | 100.013 | 125.413 | 150.813 | 176.213 | 201.613 | 227.013 | 252.413 |
| 31/32 | 24.606 | 50.006 | 75.406 | 100.806 | 126.206 | 151.606 | 177.006 | 202.406 | 227.806 | 253.206 |

## 3.3.3 METER-FOOT CONVERSION TABLE

| Foot | Meter | Foot | Meter | Foot | Meter  |
|------|-------|------|-------|------|--------|
| 5    | 1.52  | 155  | 47.24 | 355  | 108.20 |
| 10   | 3.05  | 160  | 48.77 | 360  | 109.73 |
| 15   | 4.57  | 165  | 50.29 | 365  | 111.25 |
| 20   | 6.10  | 170  | 51.82 | 370  | 112.78 |
| 25   | 7.62  | 175  | 53.34 | 375  | 114.30 |
| 30   | 9.14  | 180  | 54.86 | 380  | 115.82 |
| 35   | 10.67 | 185  | 56.39 | 385  | 117.35 |
| 40   | 12.19 | 190  | 57.91 | 390  | 118.87 |
| 45   | 13.72 | 195  | 59.44 | 395  | 120.40 |
| 50   | 15.24 | 200  | 60.96 | 400  | 121.92 |
| 55   | 16.78 | 205  | 62.48 | 405  | 123.44 |
| 60   | 18.29 | 210  | 64.01 | 410  | 124.97 |
| 65   | 19.81 | 215  | 65.53 | 415  | 126.49 |
| 70   | 21.34 | 220  | 67.06 | 420  | 128.02 |
| 75   | 22.86 | 225  | 68.58 | 425  | 129.54 |
| 80   | 24.38 | 230  | 70.10 | 430  | 131.06 |
| 85   | 25.91 | 235  | 71.63 | 435  | 132.59 |
| 90   | 27.43 | 240  | 73.15 | 440  | 134.11 |
| 95   | 28.96 | 245  | 74.68 | 445  | 135.64 |
| 100  | 30.48 | 250  | 76.20 | 450  | 137.16 |
| 105  | 32.00 | 255  | 77.72 | 455  | 138.68 |
| 110  | 33.53 | 260  | 79.25 | 460  | 140.21 |
| 115  | 35.05 | 265  | 80.77 | 465  | 141.73 |
| 120  | 36.58 | 270  | 82.30 | 470  | 143.26 |
| 125  | 38.10 | 275  | 83.82 | 475  | 144.78 |
| 130  | 39.62 | 280  | 85.34 | 480  | 146.30 |
| 135  | 41.15 | 285  | 86.87 | 485  | 147.83 |
| 140  | 42.67 | 290  | 88.39 | 490  | 149.35 |
| 145  | 44.20 | 295  | 89.92 | 495  | 150.88 |
| 150  | 45.72 | 300  | 91.44 | 500  | 152.40 |

### 3. GENERAL WORK STANDARD

#### 3.3.4 GRADIENT CONVERSION TABLE

| Degree | Percent | Degree | Percent | Degree | Percent |
|--------|---------|--------|---------|--------|---------|
| 1      | 1.8     | 16     | 28.7    | 31     | 60.1    |
| 2      | 3.5     | 17     | 30.6    | 32     | 62.5    |
| 3      | 5.2     | 18     | 32.5    | 33     | 64.9    |
| 4      | 7.0     | 19     | 34.4    | 34     | 67.5    |
| 5      | 8.8     | 20     | 36.4    | 35     | 70.0    |
| 6      | 10.5    | 21     | 38.4    | 36     | 72.7    |
| 7      | 12.3    | 22     | 40.4    | 37     | 75.4    |
| 8      | 14.1    | 23     | 42.5    | 38     | 78.1    |
| 9      | 15.8    | 24     | 44.5    | 39     | 81.0    |
| 10     | 17.6    | 25     | 46.6    | 40     | 83.9    |
| 11     | 19.4    | 26     | 48.8    | 41     | 85.9    |
| 12     | 21.3    | 27     | 51.0    | 42     | 90.0    |
| 13     | 23.1    | 28     | 53.2    | 43     | 93.3    |
| 14     | 24.9    | 29     | 55.4    | 44     | 96.6    |
| 15     | 26.8    | 30     | 57.7    | 45     | 100.0   |

## 3.4 TABLE OF UNIT WEIGHT

| Material  | Weight per<br>Cub. Meter (t) | Material    | Weight per<br>Cub. Meter (t) |
|-----------|------------------------------|-------------|------------------------------|
| Lead      | 11.4                         | Sand        | 1.9                          |
| Copper    | 8.9                          | Coal cold   | 0.8                          |
| Steel     | 7.8                          | Coal powder | 1.0                          |
| Cast iron | 7.2                          | Coke        | 0.5                          |
| Aluminum  | 2.7                          | Oak         | 0.9                          |
| Concrete  | 2.3                          | Cedar       | 0.4                          |
| Soil      | 2.0                          | Cypress     | 0.4                          |
| Gravel    | 1.9                          | Paulownia   | 0.3                          |

**Note**

1. Weight of wood is that of the dried.
2. Value shown in the table may well be taken for specific gravity.



---

## **4. POWER TRAIN**





## 4.1 INTRODUCTION

This is a fully hydraulic crawler crane.

The crane's engine drives two pairs of tandem-plunger-type double pump and tandem gear double pump connected to each plunger-type pump through the power divider.

Both of the tandem plunger type double pump are variable.

One plunger type double pump is the main pump.



The main pump powers the front and rear drum motors and the right and left drive motors through the two control valves.

For another plunger type double pump, the inner pump powers the swing motor, and the outer pump powers the boom drum motor, respectively.

The tandem gear double pump connected to the swing and boom pump feed oil to the free fall brake cooling line of front and rear drums. The inner pump of tandem gear double pump connected to the main pump feed pressurized oil to control line, and the other pump feed it to the auxiliary actuator (gantry cylinder / counter-weight self removal cylinder / translifter cylinder).

#### 4. POWER TRAIN

Fig.1-1 Component Locations



## 4.2 ENGINE

### 4.2.1 INTRODUCTION

This chapter explains how to remove and re-install the engine. Refer to the manual provided by the engine manufacturer for maintenance and repair details.

### 4.2.2 REMOVAL

Proceed as follows when removing the engine from the machine.

**Note**

Remove the pump drive assembly with the engine.

1. Lower the boom to the ground, pin the upper spreader to the lower boom.  
Store the gantry in its travel position.
2. Remove the grounding cable of the battery.
3. Remove the muffler.
4. Remove the air inlet hose from the engine and air cleaner.
5. Remove the air inter cooler hose from the engine and air inter cooler.
6. When removing the engine and pump drive assembly, it is necessary to first remove the guard.
7. Drain the engine oil, hydraulic oil and coolant water.

**WARNING**

**Do not drain the oil and water when it is hot.**

**The hot oil and water may spout out which could result in personal injury. After the oil and water has cooled, drain the oil and water.**

**Failure to observe this precaution may result in serious injury or death.**

8. Remove the cap screws that hold the fanguard to the radiator and take off the radiator assembly.
9. Label and then remove the hydraulic hoses from the hydraulic pumps.  
All the ports and hoses should be plugged to prevent soil from getting into them.
10. Label and then remove the fuel line and electric harness from engine.  
Cap all the fuel lines to prevent soil from getting into them.

## 4. POWER TRAIN

---

11. Recheck to be sure that no electrical lines, mechanical connections and fuel pipes are remaining to interfere with the removal of the engine.
12. Use a sufficiently strong engine lift. (The engine/ power divider combined weight is approximately 1500 kg (3307 lbs) . Note the three designated lifting points on the engine assembly.
13. Remove the nuts, washers and bolts from the rubber mounts of the engine and power divider.
14. Slowly lift to remove as a single unit the engine and pump drive assembly.
15. Check the rubber mounts and replace them if necessary.

### 4.2.3 REPAIR AND MAINTENANCE

Regarding the repair and maintenance of the engine, refer to the manual provided by the manufacturer.

The engine manufacturer : HINO MOTORS, LTD.

The engine model : CK1200  
CKE1100 ; P11C-UN

#### 4.2.4 RE-INSTALLATION

Proceed as follows when re-installing the engine. (See page 4-8, 4-9)

1. Check to make sure that no fuel lines, coolant water hoses, mechanical connection parts or other items are left to interfere with the re-installation.
2. If the rubber mounts were removed, replace them.
3. Using a sufficiently strong engine lift, lift the engine and place it onto the mount pads.
4. Use Loctite #271 on the rubber mount holding bolts and tighten them to  $559 \pm 59$  N-m ( $412 \pm 44$  ft-lbs) torque.
5. Install the radiator assembly and fan guard. The space between the fan shroud and fan should be even all around.  
Use Loctite #271 on the bolts of the radiator assembly and tighten them with  $314 \pm 31$  N-m ( $232 \pm 23$  ft-lbs) torque.
6. Connect all the electric lines that were disconnected when the engine was removed.
7. Install all the fuel lines that were removed when the engine was removed.
8. Install the guard, and connect the battery cable.
9. Install the air inter cooler hose that were removed when the engine was removed.

#### WARNING

- Do not bring a flame or spark close to the batteries.
- Since the battery electrolyte is dilute sulfuric acid, avoid battery acid contact with the skin, eyes, or clothing.  
If accidentally contacted, immediately flush the area with water and consult a doctor immediately.
- Wear eye glasses to protect eyes when working with electrolyte.

Failure to observe this precaution may result in serious injury or death.

10. Install the air inlet hose and muffler.
11. Install hydraulic hoses to the hydraulic pumps.
12. Refill the engine with coolant water and engine oil to the required levels.

#### 4. POWER TRAIN

13. Remove the air from the fuel lines.
14. Start the engine and set it to low idle. Check for water and fuel leaks, and any strange noises.

#### **CAUTION**

Before starting the engine, re-check all electrical, fuel, water and hydraulic connections as well as mechanical connections.

Be prepared to stop the engine immediately if something unusual develops.

Fig.2-1 Engine (1/2)





Fig.2-1 Engine (2-2)



## 4. POWER TRAIN

### 4.3 PUMP DRIVE ASSEMBLY

#### 4.3.1 INTRODUCTION

This chapter explains how to remove, inspect, repair and re-install the pump drive assembly.

The pump drive assembly is mounted directly onto the back of the engine. It consists of a coupling, a power divider, tandem-mounted main pump (hoist, propel), swing/boom hoist pump and two tandem gear double pumps connected to each tandem pump.

The power of the engine is transferred from a flywheel through the coupling to the center core of the power divider. Three pairs of gears divide this power between the main pump shaft and the swing/boom pump shaft and option pump shaft. (See page 4-11)

#### 4.3.2 REMOVAL

Proceed as follows when removing the pump drive assembly (See page 4-11)

#### CAUTION

Pump drive assembly should be removed from the engine according to the following procedure only after the engine has been removed from the machine as described in Section 4.2.



1. Drain the oil in the power divider through the port on the lower part of the power divider.
2. Remove the main pump, swing/boom pump and gear pump.

|                     |                                 |
|---------------------|---------------------------------|
| Main pump           | 124kg<br>(273 lbs)              |
| Swing/Boom pump     | 124kg<br>(273 lbs)              |
| Gear pump (Control) | 7.4kg<br>(16.3 lbs)             |
| Gear pump (Cooling) | 8.4kg<br>(18.5 lbs)<br>(OPTION) |

3. Using a sufficiently strong lift device (the approximate weight of the power divider is 130 kg (287 lbs)), attach the lift riggings to suspension screws provided on the power divider. (screw holes : M16)  
Remove the cap screws set in the fly wheel housing of the engine and move the power divider slowly toward the back of the engine.  
Remove the coupling and disconnect the power divider.
4. The main part of this coupling will be removed with the power divider connected to its core.



Fig.3-1 Pump Drive Assembly



## 4. POWER TRAIN

---

### 4.3.3 DISASSEMBLING THE POWER DIVIDER

Proceed as follows when disassembling the power divider (See page 4-16,4-17,4-18,4-19,4-20)

1. Set the power divider on a block with the pump side facing up.
2. Use the screw holes (M8) provided when removing support (3) with a puller. Remove the O-ring (15).
3. Remove the gear (6) and remove the bearings (11, 13) on both sides if necessary.
4. Use the screw holes (M8) provided when removing support (30) with a puller. Remove the O-ring (15).
5. Remove gear (33) and remove the bearings (31, 32) on both sides if necessary.
6. Now, turn the assembly over and set the power divider on a block with the fly wheel side facing up.
7. Remove the capscrew (23), insert the capscrew (M10) into the screw hole for removing the support (2) and remove support (2).
8. Remove the shaft (8) and gear (5).
9. Remove the oil seal (17), O-ring (15) and outer race of the bearing (10) from the support (2). Remove the outer race of the bearing (10) from the housing (1).  
Retain and keep all the shims (27, 28, 29) together.
10. If necessary, remove the inner race of the tapered roller bearing (10) from the shaft (8).

#### 4.3.4 CHECK AND REPAIR OF THE POWER DIVIDER

Check all parts prior to reassembling the power divider. All questionable parts should be replaced to maximize the re-assembled power divider's service life and to avoid further break downs. Checking should proceed in the following order:

1. Clean all the parts with fresh cleaning oil and blow them dry.
2. Check bearing balls, rollers, inner and outer races to see that they are free of pitting and scratches. Replace any defective ones.
3. Bearings with no pitting or scratches should be lightly lubricated, but replace any bearings that develop rattles due to excessive clearances toward the shaft or toward the external side should be replaced.
4. Check the bearings' outer and inner races. Replace any that show indications of slipping and/or rolling.
5. Check the teeth of all the gears and replace any that show pitting, scratch, signs of friction wear, peeling or cracking.
6. Check the shafts and replace any with signs of cracking, deformation, wear at contact surfaces or bearing slippage.
7. Check the splines of the shafts and gears. Replace or fix any that show cracking, signs of wear or impact damage.
8. Check the bearing casings and replace any that show slip wear or other deformations.
9. Check the gear casings and replace or fix any that show cracks, deformation or scratches.
10. All the O-rings and oil seals should be replaced with new ones.
11. Check cap screw threadings and screw hole threadings and replace or repair any that show signs of cross-threading and or stripping.

## 4. POWER TRAIN

---

### 4.3.5 ASSEMBLING THE POWER DIVIDER

Assembling the power divider takes place in the reverse order for disassembly. Be particularly cautious with the following factors. (See page 4-16,4-17,4-18,4-19,4-20)

1. Apply clean oil to each part before assembling.
2. When assembling the shaft (8), drive gear (5), tapered roller bearing (10) and support (2), adjust with the shims (27, 28, 29) to 0 mm to 0.15 mm (0 inch to 0.006 inch) clearance at point "S"
3. Install the support (2) to the housing (1) so that the oil hole is positioned
4. Apply Loctite #242 to the assembling bolts (23) for the support (2) before tightening them to  $70 \pm 7$  N-m ( $52 \pm 5$  ft-lbs) torque.
5. Install the bearing (11), insert the gear (6) and install the support (3) in which the bearing (13) is inserted.
6. Install the bearing (31), insert the gear (33) and install the support (30) in which the bearing (32) is inserted.
7. After assembly is completed, make sure the input shaft can be turned easily by hand, and no noise is emitted.

### 4.3.6 RE-INSTALLATION

Assemble the pump drive as follows.

(See page 4-20)

1. Grease the spline of the input shaft (9) and insert the coupling hub (2) to the until it comes in contact with the shaft shoulder section.  
Torque the clamping screws (7) to  $206 \pm 9.8$  N·m ( $152 \pm 7$  ft·lb).
2. Assemble the coupling in the following order : first put spring pins (8) into the coupling hub (2) , then the elements (1) and then inserts (R) (4).
3. Torque the cap screws (6) to  $451 \pm 29$  N·m ( $332 \pm 21$  ft·lbs).
4. On the side of the fly wheel(11), put spring pins (12) into the fly wheel (11), install inserts (A)(3) and then torque the cap screws (5) to  $451 \pm 29$  N·m ( $332 \pm 21$  ft·lbs).
5. Fit the hook of a hoisting device with suitable capacity to the eyebolt of the power divider ; insert the element at the coupling side of the power divider into the bushing at the flywheel and thus set the power divider assembly to the flywheel housing.
6. Apply Loctite #242 to the capscrews (10) and tighten to  $66.7 \pm 6.9$  N·m ( $49 \pm 5.1$  ft·lbs).
7. Apply Loctite #242 to the respective cap screws, and tighten them to the two tandem-type pumps (main and swing/boom) with a tightening torque from  $314 \pm 29.4$  N·m ( $231 \pm 21.4$  ft·lbs) and the tandem-type gear pumps from  $25 \pm 3$  N·m ( $18 \pm 2$  ft·lbs). Ensure that the installation positions of the main pump and swing/boom pump are correct (refer to page 4-11).
8. Supply the specified #90 gear oil to the power divider to the specified level [about 3.5 ltr. (0.92 gals) is needed]
9. Attach power divider to the engine, and install the engine assembly to base machine
10. Start the engine, and check that there is no abnormal noise, oil leakage, etc

**Note**

If the pump is not installed to the power divider, the support (3), (30) may come off.

#### 4. POWER TRAIN

Fig. 3-2 Power Divider (1/4)





Fig. 3-2 Power Divider (2/4)



|            |              |                     |                  |                  |                |
|------------|--------------|---------------------|------------------|------------------|----------------|
| 1. Housing | 10. Bearing  | 18. Oil level gaugu | 27. Shim         | 33. Gear         | 40. Cap        |
| 2. Support | 11. Bearing  | 19. Plug            | 28. Shim         | 34. Cover        | 41. Tube       |
| 3. Support | 13. Bearing  | 23. Capscrew        | 29. Shim         | 35. Cover        | 42. Drain cock |
| 5. Gear    | 15. O-ring   | 24. Capscrew        | 30. Support      | 37. Breather "B" | 43. Connector  |
| 6. Gear    | 16. O-ring   | 25. Plate           | 31. Ball bearing | 38. Tube         |                |
| 8. Shaft   | 17. Oil seal | 26. Rivet           | 32. Ball bearing | 39. Elbow        |                |

#### 4. POWER TRAIN

Fig. 3-2 Power Divider (3/4)








Fig. 3-2 Power Divider (4/4)



|            |             |                    |                  |                  |                |
|------------|-------------|--------------------|------------------|------------------|----------------|
| 1. Housing | 10. Bearing | 18 Oil level gauge | 27. Shim         | 33. Gear         | 40. Cap        |
| 2. Support | 11 Bearing  | 19 Plug            | 28. Shim         | 34. Cover        | 41. Tube       |
| 3. Support | 13 Bearing  | 23 Capscrew        | 29. Shim         | 35. Cover        | 42. Drain cock |
| 5. Gear    | 15 O ring   | 24 Capscrew        | 30. Support      | 37. Breather "B" | 43. Connector  |
| 6. Gear    | 16 O-ring   | 25 Plate           | 31. Ball bearing | 38. Tube         |                |
| 8. Shaft   | 17 Oil seat | 26 Rivet           | 32. Ball bearing | 39. Elbow        |                |

Fig. 3-3 Coupling



- |                        |                             |
|------------------------|-----------------------------|
| 1. Element             | 7 Clamping screw (M20 X 25) |
| 2. Hub                 | 8 Spring pin                |
| 3. Insert (A)          | 9 Shaft                     |
| 4. Insert (R)          | 10 Capscrew                 |
| 5. Capscrew (M20 X 65) | 11 Flywheel                 |
| 6. Capscrew (M20 X 65) | 12 Spring pin               |



---

## 5. HYDRAULIC SYSTEM



## 5.1 LOCATION OF MAIN HYDRAULIC COMPONENTS


### Location of Main Component




## 5. HYDRAULIC SYSTEM


### 5.2 HYDRAULIC CIRCUITS AND COMPONENTS

#### 5.2.1 HYDRAULIC CIRCUIT








REEVING WINCH (OPTION)



TAGLINE (OPTION)







## 5. HYDRAULIC SYSTEM

### 5.2.2 COMPONENT SPECIFICATIONS

| Item                    | Name of Component                                            | Specification                                                                                                                                                                                                                                                               |                 |             |             |                         |              |              |                       |
|-------------------------|--------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|-------------|-------------|-------------------------|--------------|--------------|-----------------------|
| 1                       | Pump (Front & Rear Drum, Propel)<br>[K3V1120T]               | Swash Plate Type, Variable Capacity<br>Max. Delivery : 252 ltr./min X 2<br>Max. Working Pressure : 31.9 MPa                                                                                                                                                                 |                 |             |             |                         |              |              |                       |
| 3                       | Pump (Swing / Boom)<br>[K3V1120T]                            | Swash Plate Type, Variable Capacity                                                                                                                                                                                                                                         |                 |             |             |                         |              |              |                       |
|                         |                                                              | <table border="1"> <thead> <tr> <th></th> <th>Swing</th> <th>Boom</th> </tr> </thead> <tbody> <tr> <td>Max. Delivery</td> <td>175 ltr./min</td> <td>252 ltr./min</td> </tr> <tr> <td>Max. Working Pressure</td> <td>27.5 MPa</td> <td>32.0 MPa</td> </tr> </tbody> </table> |                 | Swing       | Boom        | Max. Delivery           | 175 ltr./min | 252 ltr./min | Max. Working Pressure |
|                         | Swing                                                        | Boom                                                                                                                                                                                                                                                                        |                 |             |             |                         |              |              |                       |
| Max. Delivery           | 175 ltr./min                                                 | 252 ltr./min                                                                                                                                                                                                                                                                |                 |             |             |                         |              |              |                       |
| Max. Working Pressure   | 27.5 MPa                                                     | 32.0 MPa                                                                                                                                                                                                                                                                    |                 |             |             |                         |              |              |                       |
| 4                       | Gear Pump (Control / Aux. Actuator)<br>[SD1A2718F2H1]        | Control Aux. Actuator                                                                                                                                                                                                                                                       |                 |             |             |                         |              |              |                       |
|                         |                                                              | <table border="1"> <tbody> <tr> <td>Max. Delivery :</td> <td>61 ltr./min</td> <td>40 ltr./min</td> </tr> <tr> <td>Max. Working Pressure :</td> <td>7.0 MPa</td> <td>21.0 MPa</td> </tr> </tbody> </table>                                                                   | Max. Delivery : | 61 ltr./min | 40 ltr./min | Max. Working Pressure : | 7.0 MPa      | 21.0 MPa     |                       |
| Max. Delivery :         | 61 ltr./min                                                  | 40 ltr./min                                                                                                                                                                                                                                                                 |                 |             |             |                         |              |              |                       |
| Max. Working Pressure : | 7.0 MPa                                                      | 21.0 MPa                                                                                                                                                                                                                                                                    |                 |             |             |                         |              |              |                       |
| 5                       | Gear Pump (Drum Brake Cooling)<br>[SD1A3232F2H1]<br>(OPTION) | Max. Delivery : 73 ltr./min X 2<br>Max. Working pressure : -                                                                                                                                                                                                                |                 |             |             |                         |              |              |                       |
| 8                       | Motor (Front & Rear Drum & Third or Jib)<br>[M3B8C0BC]       | Swash Plate Type, Variable Capacity<br>Max. Oil Flow : 252 ltr./min<br>Max. Working Pressure : 31.9 MPa                                                                                                                                                                     |                 |             |             |                         |              |              |                       |
| 10                      | Motor (Boom)<br>[A2F250]                                     | Bent Axis Type, Fixed Capacity<br>Max. Oil Flow : 252 ltr./min<br>Max. Working Pressure : 32.0 MPa                                                                                                                                                                          |                 |             |             |                         |              |              |                       |
| 12                      | Motor (Swing)<br>[M2X210]                                    | Swash Plate Type, Fixed Capacity<br>Max. Oil Flow : 175 ltr./min<br>Max. Working Pressure : 27.5 MPa                                                                                                                                                                        |                 |             |             |                         |              |              |                       |
| 13                      | Motor (Propel)<br>[M3V260]                                   | Swash Plate Type, Variable Capacity (2-Speed Type)<br>Max. Oil Flow : 252 ltr./min<br>Max. Working Pressure : 31.9 MPa                                                                                                                                                      |                 |             |             |                         |              |              |                       |
| 14                      | Motor (Tagline)<br>[2-080AF2-L]<br>(OPTION)                  | Internal Trochoid Gear Type, Fixed Capacity<br>Max. Oil Flow : 40 ltr./min<br>Max. Working Pressure : 13.7 MPa                                                                                                                                                              |                 |             |             |                         |              |              |                       |
| 15                      | Motor (Reeving)<br>[TRCF44C]<br>(OPTION)                     | Radial Plunger Type, Fixed Capacity<br>Max. Oil Flow : 40 ltr./min<br>Max. Working pressure : 12.7 MPa                                                                                                                                                                      |                 |             |             |                         |              |              |                       |
| 16                      | Flow Control Valve (Tagline)<br>[FDCB] (OPTION)              | Max. Oil Flow : 40 ltr./min                                                                                                                                                                                                                                                 |                 |             |             |                         |              |              |                       |
| 17                      | Control Valve (Front & Rear Drum, Propel)<br>[MWP225]        | Max. Oil Flow : 252 ltr./min<br>Set Pressure : 31.9 MPa                                                                                                                                                                                                                     |                 |             |             |                         |              |              |                       |
| 18                      | Control Valve (Boom)<br>[MWP125]                             | Max. Oil Flow : 252 ltr./min<br>Set Pressure : 32.0 MPa                                                                                                                                                                                                                     |                 |             |             |                         |              |              |                       |
| 19                      | Control Valve (Third or Jib)<br>[MWP125]<br>(OPTION)         | Max. Oil Flow : 252 ltr./min<br>Set Pressure : 32.0 MPa                                                                                                                                                                                                                     |                 |             |             |                         |              |              |                       |
| 20                      | Control Valve (Swing)<br>[KSC19L]                            | Max. Oil Flow : 175 ltr./min<br>Set Pressure : 27.5 MPa                                                                                                                                                                                                                     |                 |             |             |                         |              |              |                       |

| Item | Name of Component                                                     | Specification                                                                                                                                                                                                                                                                                                                                  |
|------|-----------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 22   | Control Valve (Gantry & Circuit-change)<br>[KMC10-2]                  | Max. Oil Flow : 40 ltr./min<br>Set Pressure : 20.6 MPa                                                                                                                                                                                                                                                                                         |
| 23   | Control Valve (Translifter)<br>[KMC10-6]                              | Max. Oil Flow : 40 ltr./min<br>Set Pressure : 20.6 MPa                                                                                                                                                                                                                                                                                         |
| 24   | Control Valve (Counter-Weight Removal)<br>[KMC10-2]                   | Max. Oil Flow : 40 ltr./min<br>Set Pressure : 21.0 MPa                                                                                                                                                                                                                                                                                         |
| 25   | Control Valve (Boom Foot Pin & Reeving)<br>[SC3A-3]<br>(OPTION)       | Max. Oil Flow : 40 ltr./min<br>Set Pressure : 12.7 MPa                                                                                                                                                                                                                                                                                         |
| 27   | 8-Section Valve<br>(Automatic Stop & Speed Adjusting)                 | 3rd.(Jib) Drum Lower Control Press. Reduce (OPT.)<br>3rd.(Jib) Drum Hoist Control Press. Reduce (OPT.)<br>Fr. Drum Lower Control Press. Reduce<br>Fr. Drum Hoist Control Press. Reduce<br>Re. Drum Lower Control Press. Reduce<br>Re. Drum Hoist Control Press. Reduce<br>Boom Lower Control Press. Reduce<br>Boom Raise Control Press. Reduce |
| 28   | 5- Section Valve<br>(Limit Stop)                                      | Boom Raise Stop (No.2)<br>Boom Lower Stop (No.2)<br>Re. Drum Hoist Stop (No.2)<br>Fr. Drum Hoist Stop (No.2)<br>3rd(Jib) Drum Hoist Stop (No.2) [OPT.]                                                                                                                                                                                         |
| 29   | 4 Section Valve<br>(Motor Negative Brake)                             | Fr. Drum Motor Parking Brake<br>Re. Drum Motor Parking Brake<br>Boom Drum Motor Parking Brake<br>3rd.(Jib) Drum Motor Parking Brake [OPT.]                                                                                                                                                                                                     |
| 30   | 2 Section Valve                                                       | Function Lock / Swing Parking Brake<br>Swing Pressure Changeover / Propel Speed<br>Changeover                                                                                                                                                                                                                                                  |
| 31   | 1-Section Valve                                                       | Swing Reaction                                                                                                                                                                                                                                                                                                                                 |
| 33   | 4-Section Valve<br>(Free Fall Changeover)<br>(OPTION)                 | Re. Drum Clutch On/Off<br>Re. Drum Emergency Stop<br>Fr. Drum Emergency Stop<br>Re. Drum Clutch On/Off                                                                                                                                                                                                                                         |
| 34   | 3-Section Valve<br>(Free Fall Acceleration)<br>(OPTION)               | Fr. Drum Free Fall Acceleration<br>Re. Drum Free Fall Acceleration<br>3rd. Drum Free Fall Acceleration                                                                                                                                                                                                                                         |
| 37   | Port Relief valve                                                     | .                                                                                                                                                                                                                                                                                                                                              |
| 38   | Slow Return Check Valve                                               | .                                                                                                                                                                                                                                                                                                                                              |
| 39   | 2-Section Valve<br>(Free Fall Changeover) (OPTION)                    | 3rd. Drum Clutch On/Off<br>3rd. Drum Emergency Stop                                                                                                                                                                                                                                                                                            |
| 40   | Pilot Valve<br>(3rd. Motor Negative Brake) (OPTION)                   | 3rd.(Jib) Drum Motor Parking Brake                                                                                                                                                                                                                                                                                                             |
| 41   | Solenoid Valve<br>(3rd. Automatic Stop & Speed Adjusting)<br>(OPTION) | 3rd.(Jib) Drum Lower Control Press. Reduce<br>3rd.(Jib) Drum Hoist Control Press. Reduce                                                                                                                                                                                                                                                       |
| 42   | Solenoid Valve<br>(3rd. Limit Stop) (OPTION)                          | 3rd.(Jib) Drum Hoist Stop (No.2)                                                                                                                                                                                                                                                                                                               |

## 5. HYDRAULIC SYSTEM


| Item | Name of Component                             | Specification                                                                                                                                                                                              |
|------|-----------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 45   | Remote Control Valve                          | Fr Drum<br>Re Drum<br>Boom                                                                                                                                                                                 |
| 46   | Remote Control Valve                          | Swing<br>3rd Drum (Jib) [OPT]                                                                                                                                                                              |
| 47   | Remote Control Valve                          | Propel                                                                                                                                                                                                     |
| 48   | Brake Master Valve (OPTION)                   | Foot Brake                                                                                                                                                                                                 |
| 49   | Remote Control Valve (OPTION)                 | Boom Control Pedal                                                                                                                                                                                         |
| 51   | Cylinder (Translifer)                         | $\Phi$ 140 / $\Phi$ 110 X 700<br>Pressure : 20.6 MPa                                                                                                                                                       |
| 52   | Cylinder (Crawler Removal)                    | $\Phi$ 160 / $\Phi$ 75 X 1246<br>Pressure : 17 MPa / 20.6 MPa                                                                                                                                              |
| 53   | Cylinder (Counter-Weight Removal)             | $\Phi$ 90 / $\Phi$ 45 X 631<br>Pressure : 21.0 MPa / 10.0 MPa                                                                                                                                              |
| 54   | Cylinder (Gantry)                             | $\Phi$ 100 / $\Phi$ 50 X 480<br>Pressure : 20.6 MPa / 4.9 MPa                                                                                                                                              |
| 57   | Oil Cooler / Radiator                         | -                                                                                                                                                                                                          |
| 58   | Swivel Joint (Gantry Cylinder)                | 1 Port G3/8 (PF 3/8)                                                                                                                                                                                       |
| 59   | Swivel Joint                                  | 8 Port<br>A : Propel (R.H.) Backward<br>B : Propel (L.H.) Backward<br>C : Propel (R.H.) Forward<br>D : Propel (L.H.) Forward<br>E : Propel Speed<br>F : Return (To Tank)<br>G : Aux. Actuator<br>H : Drain |
| 60   | Valve Block (Relief Valve & Reduction Valve)  | Control<br>Relief Pressure : 7.0 MPa<br>Reducing Pressure : 5.4 MPa                                                                                                                                        |
| 61   | Relief Valve (Tagline)<br>(OPTION)            | Tagline<br>Inversely Proportional<br>Solenoid Operated                                                                                                                                                     |
| 63   | Shuttle Valve<br>(OPTION)                     | 2-Section<br>Boom (or Jib) remote control                                                                                                                                                                  |
| 64   | Slow Return Check Valve<br>(OPTION)           | Tagline (OPT)<br>Back Pressure Valve                                                                                                                                                                       |
| 65   | Slow Return Check Valve                       | Drum Motor Parking Brake Control                                                                                                                                                                           |
| 66   | Suction Strainer                              | 80 Mesh 6,720 cm <sup>2</sup>                                                                                                                                                                              |
| 67   | Return Filter                                 | $\beta$ 10 $\geq$ 8 15,000 cm <sup>2</sup>                                                                                                                                                                 |
| 68   | Return Filter (Drum Cooling Circuit) (OPTION) | 10 $\mu$ (Nominal) 7,230 cm <sup>2</sup>                                                                                                                                                                   |
| 69   | Drain Filter                                  | 10 $\mu$ (Nominal) 2,000 cm <sup>2</sup>                                                                                                                                                                   |
| 70   | Line Filter (Control)                         | 149 $\mu$ (Nominal) [100 Mesh] 370 cm <sup>2</sup>                                                                                                                                                         |
| 71   | Line Filter (Aux. Actuator)                   | 149 $\mu$ (Nominal) [100 Mesh] 380 cm <sup>2</sup>                                                                                                                                                         |
| 73   | Check Valve (Oil Cooler)                      | Bypass Valve<br>Bypass Pressure : 0.294 MPa                                                                                                                                                                |




| Item | Name of Component                                                     | Specification                                                                       |
|------|-----------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| 74   | Check Valve (1 <sup>st</sup> & Re. Drum Cooling Circuit)<br>(OPTION)  | Bypass Valve<br>Bypass Pressure : 0.294 MPa                                         |
| 75   | Check Valve (3 <sup>rd</sup> . Drum Cooling Circuit)<br>(OPTION)      | Bypass Valve<br>Bypass Pressure : 0.49 MPa                                          |
| 76   | Accumulator                                                           | Gas : N <sub>2</sub><br>Gas capacity : 2900 cc<br>Gas Set Pressure : 3.4 to 3.7 MPa |
| 77   | Plug (OPTION)                                                         | For Carry Over                                                                      |
| 78   | Flow Control Valve (Remote Control)                                   | Remote Control Circuit                                                              |
| 79   | Pressure Sensor                                                       | Remote Control Pressure Detect                                                      |
| 80   | Pressure Sensor                                                       | Swing Pressure Detect                                                               |
| 81   | Pressure Sensor (OPTION)                                              | Winch Clutch Pressure Detect                                                        |
| 82   | Pressure Switch                                                       | Control Pressure<br>Foot Brake Pressure [OPT.]                                      |
| 83   | Pressure Switch                                                       | Remote Control Pressure<br>Swing<br>Propel                                          |
| 84   | Hyd. Oil Temperature Switch<br>(For Hyd. Oil Tank)                    | 90°C                                                                                |
| 85   | Hyd. Oil Temperature Switch<br>(For Drum Cooling Circuit)<br>(OPTION) | 130°C                                                                               |
| 86   | Check Valve                                                           | Control Return Line<br>Protect From Back-Pressure-Surge                             |

## 5. HYDRAULIC SYSTEM


### 5.2.3 LOCATION OF HYDRAULIC COMPONENTS

The item numbers in figure are linked with the item number in the hydraulic circuit diagrams and 5.2.2 COMPONENT SPECIFICATIONS







49 | REMOTE CONTROL VALVE  
(BOOM CONTROL)  
[OPTIONAL]



BOOM CONTROL PEDAL











RIGHT SIDE LEVER STAND




LEFT SIDE LEVER STAND





PROPEL CONTROL LEVER STAND











### 5.3 HYDRAULIC SYSTEM

#### 5.3.1 PREFACE

This chapter provides a general outline of the overall hydraulic system. For more detailed explanations of each circuit, please refer to the specific sections relating to each systems.


#### 5.3.2 OUTLINE

The pressurized hydraulic oil flowing through these circuits is supplied by eight pumps (four variable displacement, four fixed gear) installed on the power divider mounted directly on the engine. The tandem-mounted variable displacement double pump (main pump) power the front and rear drums, and the propel system. The other variable displacement double pump, power the swing system and the boom drum. The gear pumps directly connected to the tandem plunger type pumps are provided for control, auxiliary actuator and drum brake cooling system.

The gear pumps directly connected to the tandem plunger type pumps are provided for control, auxiliary actuator and drum brake cooling system.

**Note**

The gear pump for drum cooler is optional (with option with free fall).





### 5.3.3 OIL FLOW FROM No.1 and No. 2 PUMPS


These are tandem mounted, variable capacity pumps.

The pressurized oil from the No.1 pump flows through the 2-sectioned control valve for the L. H. propel, front drum circuits, while the oil from the No.2 pump flows through the 2-sectioned control valve for R. H. propel, rear drum circuits. In neutral, the flow from each pump passes through its respective control valve and returns freely to the oil tank. However, when one of the control valve spools is moved by oil pressure from its remote control valve, then the oil flow from the pump is directed toward the targeted actuator.

When the "Inching Speed" switch installed to the boom control lever in the operator's cab is used, this activates the inching speed solenoid on the pump's regulator which minimizes the discharge rate of oil from that pump.

## 5. HYDRAULIC SYSTEM

### Oil Flow From No.1 and No.2 Pumps



#### 5.3.4 OIL FLOW FROM No.3 AND No.4 PUMPS

This is also a variable capacity pump

The oil flow from the No. 3 pump flows through the control valve for the swing system. In neutral, the flow from No. 3 pump passes through the control valve and return freely to the oil tank


When the swing valve spool is moved by oil pressure directed from the swing remote control valve, the oil flow from the No. 3 pump powers the swing motor to rotate the crane's upper body.

On the other hand, the pressurized oil flow from the No. 4 pump flows into the boom control valve, and returns to the tank with no load.

When the control valve spool is moved by the pressurized oil from the remote control valve, the main pressurized oil is led to the boom motor to actuate the boom.

## 5. HYDRAULIC SYSTEM

### Oil Flow From No.3 and No.4 Pumps



### 5.3.5 OIL FLOW FROM No.5 PUMPS (Control Pumps)

The pressurized oil discharged from this fixed capacity gear pump flows through a line filter, by an accumulator, and through a relief valve and a pressure reducing valve that reduces line pressure to 5.4 MPa (782 psi).


The pressurized oil is now available to the foot brake valves as it flows toward the 4-section valve and it flows to two 2-section valve and 4-section valve.

When the Function Lock lever is in the "Shut Down" position, the solenoid valve (Sol 3) that is part of the 2-section valve disallows delivery of oil to the remote control valves. As there is no control pressure, the machine will not move even if the its control levers are operated.


When the Function Lock lever is in the "Work" position, however, then solenoid valve (Sol 3) allows pressurized oil to be directed from the remote control valves to the main control valves. Thus operating the control levers will cause the machine to move.

## 5. HYDRAULIC SYSTEM

Oil Flow From No.5 Pump (When the function lock lever is "Shut Down" position)



Oil Flow From No.5 Pump (When the function lock lever is "Work" position)



## 5. HYDRAULIC SYSTEM

---

### 5.3.6 OIL FLOW FROM No.6 PUMP (For Auxiliary Actuator Circuit)


The No. 6 pump is fixed capacity gear pump. It is used to the gantry cylinder, reeving winch, boom foot pin cylinder, counterweight removal cylinder and transfer.

The pressurized oil flow from pump No. 6 flows through the counterweight removal cylinder control valve. If the counterweight removal control valve, gantry control valve and hydraulic selector valve are in its neutral position, the oil flow returns freely to the reservoir.

Pressurized oil can be supplied to the reeving winch, boom foot pin, or transfer with the hydraulic selector switch (sol. 45).




Oil Flow From No.6 Pump (When the hydraulic switch is neutral)






## 5. HYDRAULIC SYSTEM

Oil Flow From No.6 Pump (When the hydraulic switch is shifted)



5.4 VALVES



4-Section Valve (GN20V00004F1)



4-Section Valve Hydraulic Schematic



## 5. HYDRAULIC SYSTEM

### 8-Section Valve (With shuttle valve) (GG20V00017F2)



8-Section Valve Hydraulic Schematic



4-Section Valve (JJ35V00006F1)



4-Section Valve Hydraulic Schematic



## 5. HYDRAULIC SYSTEM

### 3-Section Valve (JJ35V00010F1)



3-Section Valve Hydraulic Schematic



5-Section Valve (JJ35V00009F1)




5-Section Valve Hydraulic Schematic

5. HYDRAULIC SYSTEM

2-Section Valve (YN35V00027F1)





2-Section Valve Hydraulic Schematic



2-Section Valve Hydraulic Schematic



## 1-Section Valve (YN35V00001F1)





---

## **6. HOIST SYSTEM**




## 6.1 APPARATUS AND LOCATION OF COMPONENTS

The hoist system consists of the main pumps, the control valves, and the front and rear drum assemblies.

Both of the drum assemblies consist of a hoist motor (with a built-in mechanical brake) and reduction unit as well as a clutch and drum lock.

The No.1 and No.2 main pumps supply the pressurized oil for the hoist system by way of control valves.



## 6. HOIST SYSTEM


---

### 6.2 CONSTRUCTION AND FUNCTION

#### 6.2.1 HYDRAULIC SCHEMATIC

This drawing includes the free fall circuit (Optional)

Fig. 2.1 Hoist System Hydraulic Schematic



## 6. HOIST SYSTEM

---

The front and rear drums are mechanically identical so the following explanation uses the front drum for illustration purposes.

### 6.2.2 LIFTING A LOAD

Pressurized oil from the main pump flows through two main control valves to power the hoist system. While the function lock lever is in the "Operation" position (Sol 3;On position), oil pressure from the control system pump flows past the accumulator and into the brake valve block, the clutch valve block, the clutch valve block, and it flows through the valve block (2-section solenoid valves) and into the remote control valve. The pressurized oil is fed to the both sides oil chambers of the clutch cylinder (Cl M, FSM) via the valve block (4 section solenoid valves). Since the cylinder thrust force by the pressurized oil is not generated, the clutch is connected with the spring.


When the Hoist Control lever is operated in the "hoist load" direction, it directs control pressure oil through the remote control valve and into the port of the main control valve where it moves the spools.

At the same time, the control pressurized oil flows into the port of the brake cylinder built in the winch motor via the valve block (4-section pilot operated valves) and the motor brake is released.

As directed by the position of the spools, the main pump oil flowing into the control valve is sent to the lift side of the hoist motor to drive the hoist drum and thereby hoist the load.



Figure 6-10



### 6.2.3 HOLDING A RAISED LOAD

With the Hoist Control lever back in its neutral position, the control pressure coming from the remote control valve is cut, and then the spool in the main control valve returns to its neutral position.

When the spool returns to neutral, the pressurized oil to the motor is cut off and the motor stops.

Now, although the weight of the suspended load continues to pull on the drum, further rotation of the drum is prevented by a motor counterbalance valve that disallows any motor rotation by blocking the return of oil to the reservoir.


At the same time, the control oil pressure in the motor brake cylinder is directed back to the reservoir and the motor brake resets itself.

The pressurized oil is fed to the both sides oil chambers of the clutch cylinder (CLM, ESM), and the cylinder thrust force by the pressurized oil is not generated.

Therefore, the clutch remains connected with the spring.

The load is now held in suspension by the combined effects of the motor counterbalance valve, and the motor brake and the clutch.

Fig. 3 Hoisting



## 6. HOIST SYSTEM

---

### 6.2.4 LOWERING A LOAD (POWERED LOWERING)

Pressurized oil from the main Pump flows through the main control valves to power the hoist system.


When the function Inck lever is in the "Operation" position (Sol. 3 On position) oil pressure from the control pump flows past the accumulator and it flows the brake valve block, the clutch valve block, valve block (2-section solenoid valves) and into the remote control valve. The pressurized oil is fed to the both sides oil chambers of the clutch cylinder (CLM, ESM) via the valve block (4-section solenoid valves). Since the cylinder thrust force by the pressurized oil is not generated, the clutch is connected with the spring.

When the Hoist Control lever is operated in the "lower load" direction, this control oil pressure is directed by the remote control valve to flow through into ports of the main control valve where it moves the spool.

At the same time, control pressure is also directed to the port of the motor brake cylinders where it causes the motor brake to disengage.

Now the main pump oil flowing into the control valve, as directed by the position of the spools, activates the hoist motor to drive the drum and thereby lower the load. The counterbalance valve is opened by pilot pressure from the "running in" side to allow the motor to rotate.

Fig 2-4 Lowering (Revised) system



## 6. HOIST SYSTEM

---

### 6.2.5 FREE FALL OPERATION

When the brake selector switch is set to the "FREE FALL" mode, the solenoid valve (Sol. 22) in the valve block (4-section solenoid valves) is switched.

When the solenoid valve is switched and the foot brake is released, the pressurized oil in the CLM side oil chamber of the clutch cylinder returns to the tank, and the cylinder thrust force is generated against the spring to release the clutch.

As a result, the load falls freely (free fall), and the brake can be applied with the foot brake.

When the brake pedal is operated, the control pressurized oil flows into the CLM side oil chamber of the clutch cylinder through the brake valve, and the cylinder thrust force is decreased to actuate the brake (braking with the clutch).

Fig. 2-6. Final End





Fig 2-5 Footal Control





This page is blank for editing convenience.

### 6.2.6 FREE FALL ACCELERATION

Free fall with the "FREE FALL SPEED INCREASED SELECTOR SWITCH" on the side panel set to the "HIGH" position


- When the brake pedal is released, the solenoid valve (SOL-10) is switched, and pressurized oil flows into the [ PDM ] port of the main control valve through the solenoid valve (SOL-10) in the 3-section solenoid valve block and shuttle valve and solenoid proportional valve (SOL-55) to move the spool. Simultaneously, the oil also goes into the brake cylinder [ PBM ] port of the winch motor through the valve block (4-section pilot operated valve) to release the motor brake. Then, the motor rotates to the lowering direction.

Though the clutch is released while the "FREE FALL" mode is selected, the rotation of the winch motor is transmitted to the drum, and the free fall speed is increased by the power lowering, because the rotation resistance of the clutch is larger than that of the drum. In this status, the drum rotates without any load.

- When the brake pedal is depressed, pressurized oil is fed to the [ CLM ] side of the clutch cylinder through the brake valve. Then, the cylinder thrust is decreased to slow down the free fall, and the control pressure from the solenoid valve [ SOL-10 ] in the 3-section valve block is also decreased by proportional valve (sol-55) and solenoid valve (sol-10) to return the main control valve spool to the neutral position.

When the spool is returned to the neutral position, pressurized oil to the motor is shut off, and the motor stops rotating.


Fig. 2-7 Free Fall Speed Acceleration



## 6. HOIST SYSTEM

### 6.3 DRUM LOCK

#### 6.3.1 ASSEMBLY DRAWING




## 6.3.2 ADJUSTMENT OF DRUM LOCK



Do not adjust the drum locks until the boom, hook block, and load have been lowered to the ground. Failure to observe this precaution may result in serious injury or loss of life.


- (1) Pull the drum lock knob in the LOCK position and check to see that the pawl is engaged in the bottom of the drum ratchet. If the pawl is not engaged in the bottom of the ratchet, adjust the spring length to allow the pawl to be engaged in the bottom.
- (2) With the condition of step 1, adjust the respective dimension as shown in the figure.
- (3) Push the drum lock knob in the RELEASE position and check to see that the pawl is clear of the ratchet by at least 20 mm (13/16). Operate the knob to the LOCK position and to the RELEASE position and confirm that the pawl moves smoothly.



FRONT AND REAR DRUM LOCK


6.4 WINCH ASSEMBLY

6.4.1 WINCH INSTAL




6.4.2 WINCH ASSEMBLY / REDUCTION UNIT WITHOUT FREE FALL (STD.)

WINCH ASSY






## 6. HOIST SYSTEM

### REDUCTION UNIT ASSY











6.4.3 WINCH ASSEMBLY WITH FREE FALL (OPT.)



6.5 BRAKE PEDAL

6.5.1 ASSEMBLY DRAWING




|                   |                 |                     |
|-------------------|-----------------|---------------------|
| 1. Bracket        | 20. Spacer      | 37. Washer          |
| 2. Lever assembly | 21. Bolt        | 38. Washer          |
| 3. Link           | 22. Spacer      | 39. Pedal           |
| 4. Pedal          | 23. Shim (0.4)  | 40. Brake valve     |
| 5. Pawl           | 24. Shim (0.6)  | 42. Capscrew        |
| 6. Link           | 25. Shim (0.9)  | 43. Lock washer     |
| 7. Link           | 26. Cotter pin  | 44. Elbow           |
| 8. Link           | 27. Cotter pin  | 45. 90° Elbow       |
| 12. Pin           | 28. Cotter pin  | 46. 90° Elbow       |
| 13. Pin           | 29. Bolt        | 47. Capscrew        |
| 14. Pin           | 30. Bolt        | 48. 90° Elbow       |
| 15. Pin           | 31. Sems bolt   | 49. Connector       |
| 16. Bearing       | 32. Nut         | 50. Plug            |
| 17. Pin           | 33. Nut         | 51. Eye bolt        |
| 18. Bolt          | 34. Washer      | 52. Spring          |
| 19. Spacer        | 35. Lock washer | 53. Pressure switch |
|                   | 36. Plate       | 54. Sems bolt       |

| Item | Name            | Size     | Tightening torque<br>N-m (ft-lbs) |
|------|-----------------|----------|-----------------------------------|
| 29   | Bolt            | M12 X 40 | 41.19 ± 3.92 (30.3 ± 3)           |
| 42   | Capscrew        | M10 X 70 | 34.32 ± 3.92 (25.3 ± 3)           |
| 53   | Pressure Switch | PF3/8    | 29.41 ± 2.94 (21.7 ± 2)           |

- Prior to the installation of the bearing (No. 16), sufficiently pack grease
- Apply Moly coat to the rotating sections.

## 6. HOIST SYSTEM

### 6.5.2 ADJUSTING THE BRAKE PEDAL



#### Adjustment

1. Adjust the eye bolt until the dimension S is 53 mm (2-3/32).
2. Depress the brake pedal until the valve spool reaches the stroke end (dimension S = 37.5 mm (1-15/32)).
3. Bring the bolt (No.47) into contact with the lever (No.2) in the status described in the 2 above, and loosen 3/4 turn (protrude upward) to adjust the dimension S until it is 35.0 mm to 38.3 mm (1.496 to 1.508 inch). Then, tighten the nut.
4. Raise the lever (No.2) up, and return the valve spool to the neutral position (dimension S = 53 mm (2-3/32)). Bring the cap screw (No.30) into contact with the lever (No.2), and loosen 3/4 turn (protrude left). Then, tighten the nut. (dimension S = 52.3 mm to 52.5 mm (2.06 to 2.07 inch))
5. Adjust the spring (No.52) until the dimension L is 70 mm (2-3/4) in the status described in the 4 above.
6. Ensure that the effective stroke of the valve (No.40) from the time when the pedal is depressed to the time it is released is 15 mm (19/32).

## 6.6 BLEEDING AIR FROM BRAKE CIRCUIT





If air remains in the piping from the brake valve to the cylinder built in the winch, the brake response becomes poor.

After the brake valve and piping are removed, bleed air by the following sequences shown below.

### **⚠ DANGER**

Be sure to lower the hook onto the ground, and select the "Neutral free" mode. Then, ensure that the drum does not rotate even when you release your foot from the brake pedal.

1. Bypass the quick coupler of the winch brake section with a hose, while the engine is stopped.  
Hose used: GG20HQ1033D1
2. Start the engine, and increase the engine revolution to the high idling. (\*)
3. Fully depress the brake pedal, and press the brake selector switch to enter the "Free fall mode".  
\* The free fall indicator lamp lights up.
4. Release your foot from the brake pedal, and wait for approx. a minute.  
At this time, air is bled.
5. Return to the "Neutral brake mode", and stop the engine.  
After the engine is stopped, wait until the control pressure is lost (approx. a minute), and then, remove the bypass hose.




- \* If the error message shown in the drawing on the right side appears on the cluster gauge of the operator's cabin at the startup of the engine, provide the procedures below.

## 6. HOIST SYSTEM

---

- (1) Stop the engine.
- (2) Remove the electrical harness connector of the basic machine from the clutch selector solenoid valve block.
- (3) Start the engine.
- (4) Reconnect the connector that was removed in the step (2).



---

## **7. BOOM HOIST SYSTEM**






## 7.1 APPARATUS AND LOCATION OF COMPONENTS

The boom hoist system consists of the boom pump, the boom control valve, the boom drum motor, a reduction unit, the boom drum itself and the drum lock mechanism.

The pressurized oil for the boom hoist system is supplied by the No.4 pump installed on the engine's power divider. From this pump, the oil flows through the control valve to power the motor for the boom drum.




This page is blank for editing convenience.

## 7.2 CONSTRUCTION AND FUNCTION

## 7.2.1 HYDRAULIC SCHEMATIC

## Boom Hoist Hydraulic Schematic



## 7. BOOM HOIST SYSTEM


---

### 7.2.2 RAISING THE BOOM

Pressurized hydraulic oil from the No. 4 pump flows continuously through the control valve. While the Function lock lever is in the "Operation" position (SOL-3.ON POSITION), pressurized oil is also flowing from the control pump, past the accumulator and then through the valve block and into the remote control valve.

Shifting the Boom Hoist control lever to "Raise" directs control system oil through the remote control valve and valve block and into the [PUB] port of the control valve. This pressure shifts the spool. At the same time, the control pressurized oil flows into the port [PBB] of the brake cylinder built in the boom motor via the valve block (4-section pilot operated valves), and then control pressure is applied to release the negative brake mechanisms. This allows the oil pressure from the No. 4 pump to activate the boom hoist motor and drive the drum to raise the boom.

Raising the Boom



## 7. BOOM HOIST SYSTEM

---


### 7.2.3 NEUTRAL (MAINTAINING THE BOOM POSITION)

With the Boom Hoist control lever returned to its neutral position, the control pressure is cut off, and the oil flow from the No 4 pump is again allowed to pass through the control valve and flow freely back to the oil reservoir.

Now, although the weight of the suspended load and the boom continues to pull on the drum, further rotation of the drum is prevented by a motor counterbalance valve that disallows any motor rotation by blocking the return of oil to the reservoir.

At the same time, the oil pressure to the boom drum motor negative brake is also released back to the reservoir. Both braking mechanisms then re-engage to hold the boom hoist drum in position.

Neutral The Boom (Maintaining Boom Position)



## 7. BOOM HOIST SYSTEM

---

### 7.2.4 LOWERING THE BOOM

Pressurized hydraulic oil from the No.4 pump flows through the control valve while oil from the control pump flows past the accumulator and into the valve block and the remote control valve. (The function lock lever remains in the "Operation" position. (SOL-3:ON POSITION) )


Shifting the Boom Hoist control lever to "Lower" directs control system oil through the remote control valve and through the valve block and into the [ PDB ] port of the control valve to shift the spool.

At the same time, the control pressurized oil flows into the port [PBB] of the brake cylinder built in the boom motor via the valve block (4-section pilot operated valves), and then control pressure is applied to release the motor parking brake.

The pressurized oil from the No.4 pump is sent to the lowering side of the boom hoist motor. This line pressure opens the counterbalance valve and drives the boom hoist motor so that the boom drum lowers the boom.




## Lowering the Boom



## 7. BOOM HOIST SYSTEM

### 7.3 BOOM DRUM LOCK

#### 7.3.1 ASSEMBLY DRAWING



- When the assembly is complete, fill grease until it is squeezed out from the clearances of the pawl.

## 7.3.2 ADJUSTING THE BOOM DRUM LOCK


**WARNING**

Do not adjust the boom hoist drum locks until the boom has been lowered to the ground.  
Failure to observe this precaution may result in serious injury or loss of life.

1. Pull the drum lock knob in the LOCK position and check to see that the pawl is engaged in the bottom of the drum ratchet with the drum lock condition. If the pawl is not engaged in the bottom of the ratchet, adjust the spring dimension to allow the pawl to be engaged in the bottom.
2. With the condition of step 1, adjust the respective dimension as shown in the figure.
3. Push the drum lock knob in the RELEASE position and check to see that the pawl is clear of the ratchet by at least 22mm (7/8 inch). Operate the knob to the LOCK position and to the RELEASE position and confirm that the pawl moves smoothly.

**WARNING**


Keep hands and clothing clear of the rotating drum.  
Failure to observe this precaution may result in serious injury or loss of life.



## 7. BOOM HOIST SYSTEM

### 7.4 DRUM AND REDUCTION UNIT

#### 7.4.1 BOOM WINCH ASSEMBLY




- |               |                |                          |
|---------------|----------------|--------------------------|
| 1. Winch Assy | 5 Nut          | 9 Capscrew               |
| 2. Rope Wedge | 6 Keeper Plate | 10. Nut                  |
| 3. Pin        | 7 Capscrew     | 11 O-Ring                |
| 4. Capscrew   | 8 Block        | 12. Capscrew             |
|               |                | 13. Hydraulic Motor Assy |

## Tightening torque

| Item | Name     | Size      | Tightening Torque N-m (ft-lbs)                                                                                           |
|------|----------|-----------|--------------------------------------------------------------------------------------------------------------------------|
| 5    | Nut      | M20       | 336 to 410 (246 to 303)<br>Lightly press the code No.4 cap screw against the winch, and tighten it.                      |
| 7    | Capscrew | M10 X 20  | 35.3 to 43.1 (26 to 31)<br>Apply Loctite #271                                                                            |
| 10   | Nut      | M16       | 171 to 211 (126 to 155)<br>Screw in the code No.9 cap screw so that the code No.8 block is stable, and then, tighten it. |
| 12   | Capscrew | M10 X 7.5 | 64.7 to 77.5 (48 to 57)<br>Apply Loctite #242                                                                            |

## 7. BOOM HOIST SYSTEM

### 7.4.2 BOOM DRUM AND REDUCTION UNIT ASSEMBLY



|                    |                    |                  |
|--------------------|--------------------|------------------|
| 3 Capscrew         | 23. Plate          | 46 Winch Drum    |
| 4 Capscrew         | 24. O-Ring         | 47 Retainer      |
| 5 Sleeve           | 26. Collar         | 48 Plate         |
| 6 Oil seal         | 27. Retaining ring | 49 Bearing       |
| 7 Retainer         | 28. Retainer       | 50 Retainer      |
| 8 Spacer           | 29. Pin            | 51 Capscrew      |
| 9 Pin              | 30. Ball Bearing   | 52 Grease Nipple |
| 10 Capscrew        | 31. Plate          | 53 Breather      |
| 11 Thrust washer   | 32. Retainer       | 54 Thrust Washer |
| 12 Pinion          | 33. Sun gear       | 55. Keeper Plate |
| 13 Needle Bearing  | 34. Plug           | 56. Capscrew     |
| 14. Spring pin     | 35. Spider         | 57. Washer       |
| 15. Retaining ring | 37. Retaining ring | 60. Shim         |
| 16 Thrust washer   | 38. Capscrew       | 61. Shim         |
| 17. Pinion         | 39. Washer         | 62. Shim         |
| 18. Needle Bearing | 40. Sun gear       | 63. Shim         |
| 19. Pin            | 41. Spider         | 68. Ring Gear    |
| 20. Capscrew       | 43. Cover          | 69. Ring Gear    |
| 21. Collar         | 44. Ball Bearing   |                  |
| 22. Oil seal       | 45. Spacer         |                  |

## Tightening torque

| Item | Name     | Size     | Tightening Torque N-m (ft-lbs) |                    |
|------|----------|----------|--------------------------------|--------------------|
| 3    | Capscrew | M20 X 70 | 500 to 618 (368 to 455)        | Apply Loctite #242 |
| 4    | Capscrew | M10 X 45 | 500 to 618 (368 to 455)        | Apply Loctite #242 |
| 10   | Capscrew | M10 X 25 | 63.7 to 77.5 (45 to 57)        | Apply Loctite #242 |
| 34   | Plug     | PF3/4    | 113 to 123 (83 to 90)          | -                  |
| 38   | Capscrew | M12 X 40 | 82 to 100 (61 to 72)           | Apply Loctite #242 |
| 51   | Capscrew | M10 X 85 | 35.3 to 43.1 (28 to 31)        | Apply Loctite #242 |





---

## **8. SWING SYSTEM**




## 8.1 APPARATUS AND LOCATION OF COMPONENTS

The swing system consists of the swing motor which includes an internal brake, the swing control valve, the reduction unit, the swing bearing ring, the swivel joint, the swing gear and the swing lock.

To swing the machine's upper body, pressurized oil from the swing pump mounted on the power divider is sent to the swing motor by way of the control valve which is directly mounted on the swing motor.


### Main Component Locations



8.2 CONSTRUCTION AND FUNCTION

8.2.1 HYDRAULIC SCHEMATIC

Swing hydraulic schematic



This page is blank for editing convenience.

## 8. SWING SYSTEM

---

### 8.2.2 SWING

The working principle of the rightward swing, identical to that of the leftward swing, is shown below. [The swing brake is released (SPB SOL5 is actuated).]

The pressurized oil from the swing pump is led to the swing control valve. On the other hand, the control pressurized oil from the control pump flows into the valve block, swing remote control valve, and brake mode select solenoid valve (SOL48) built in the swing control valve through the accumulator.

[The function lock lever is at the "working position" (SOL3 is actuated).]

#### (1) Neutral free mode

When the swing mode selector switch on the side stand panel in the operator's cab is set to the "free" side, the control pressurized oil flows through the solenoid valve (SOL 48) to move the spool "B" of the swing control valve to the full stroke.

In this status, when the swing control lever is swung down to the right swing side (back ward), the control oil flows through the remote control valve, and is led to the [ PSb ] port of the control valve to move the spool "A".

The main pressurized oil controlled by the control valve is fed to the swing motor to run the motor.


#### (2) Neutral brake mode

When the swing mode selector switch on the side stand panel in the operator's cab is set to the "brake" side, the solenoid valve (SOL 48) is actuated to connect the both pilot ports, the swing control valve spool "A" and "B".

In this status, when the swing control lever is swung down to the right swing side (back ward), the control oil flow is led to the [ PSb ] port of the control valve to move the spools "A" and "B" at the same time.


The main pressurized oil controlled by the control valve is fed to the swing motor to run the motor.

Swing (Neutral Free Mode)



## B. SWING SYSTEM

### Swing (Neutral Braka Mode)





### 8.2.3 STOPPING

When the swing control lever is returned from the swing mode to the neutral mode, the control pressure from the remote control valve is lost and the control valve spool "A" returns to neutral. Thus, the main pressurized oil returns to the tank with no load.

#### (1) Neutral free mode

Although the pressurized oil flow to the swing motor is shut down, the returned oil circulates in the motor and valves, since the spool "B" has been moved to the full stroke by the pilot pressure. Thus, the motor continues rotating by inertia. (The swing brake is released.) To stop the swing motion, carefully swing down the swing control lever to the opposite side.

#### (2) Neutral brake mode


The brake mode select solenoid valve (SOL 48) is actuated, and the spool "B" returns to neutral.

The brake pressure is generated at the exit port of the swing motor by the oil returned from the swing motor passing the restrictor section of the control valve spool "B". The swing motor is decelerated by the brake pressure until the motor is stopped smoothly. (The swing brake is released.)


The main pressurized oil returned from the swing motor is interrupted by the orifice of the spool "B", then the swing stops. If an unusually high pressure occurs, the overload valve is actuated to protect the circuit from damage. (At the neutral brake mode, the overload valve relief set is Low side.) However, remember that the motor will not be stopped completely when external forces are always applied, including the operation on a slope or on windy days.

## 8. SWING SYSTEM


### Stop (Neutral Free Mode)



Stop (Neutral Brake Mode)



8.3 SWING REDUCTION UNIT




|                  |                    |                   |
|------------------|--------------------|-------------------|
| 1. Housing       | 17. Bearing        | 32. Shim (0.2) mm |
| 2. Housing       | 18. Bearing        | 33. Shim (0.5) mm |
| 3. Housing       | 19. Bearing        | 34. Shim (1.1) mm |
| 4. Pinion        | 20. Bearing        | 35. Shim (1.2) mm |
| 5. Shaft         | 21. Oil seal       | 36. Shim (1.3) mm |
| 6. Ring gear     | 22. Plug           | 37. Shim (1.4) mm |
| 7. Sun gear      | 23. Plug           | 38. Shim (1.5) mm |
| 8. Pinion        | 24. Retainer       | 39. Shim (1.6) mm |
| 9. Pinion        | 25. Retaining ring | 40. Shim (1.7) mm |
| 10. Gear         | 26. Capscrew       | 41. Shim (1.8) mm |
| 11. Pin          | 27. Capscrew       | 42. Spacer        |
| 12. Pin          | 28. Capscrew       | 43. Thrust button |
| 13. Pin          | 29. Capscrew       | 44. Shim (0.1) mm |
| 14. Plate        | 30. Capscrew       | 45. Shim (0.2) mm |
| 15. Keeper plate | 31. Capscrew       | 46. Shim (0.3) mm |
| 16. Bearing      |                    |                   |

## Tightening torque

| Item | Name of Part | Size      | Tightening Torque N·m (ft·lb) | Remedy              |
|------|--------------|-----------|-------------------------------|---------------------|
| 22   | Plug         | PT1/2     | 57.9 to 71.6 (43 to 53)       | Apply seal tape     |
| 23   | Plug         | PT3/4     | 88.2 to 107.8 (65 to 79.5)    | Apply seal tape     |
| 26   | Capscrew     | M20 X 140 | 500 to 618 (369 to 455)       | Apply locktite #242 |
| 27   | Capscrew     | M20 X 150 | 500 to 618 (369 to 455)       | Apply locktite #242 |
| 28   | Capscrew     | M12 X 35  | 109 to 133 (80 to 98)         | Apply locktite #242 |
| 29   | Capscrew     | M16 X 40  | 255 to 313 (188 to 230)       | Apply locktite #242 |
| 30   | Capscrew     | M10 X 25  | 63.7 to 77.5 (47 to 57)       | Apply locktite #242 |
| 31   | Capscrew     | M8 X 20   | 31.4 to 39.2 (23 to 28)       | Apply locktite #242 |

- Apply Loctite #515 to the circumference of oil seal No.21
- Apply Loctite #242 to capscrew.
- Assembly weight : Approx. 400 kg (882 lbs)


8.4 SWING BEARING



**Method of bolt tightening**

1. The soft zone of the bearing inner ring (S-marked area) against the lower unit must be positioned as shown in the figure.
2. Apply LOCKTITE #242 to screw of bolt and apply / molybdenum disulfide grease to seat of bolt.
3. Temporary tighten two axisymmetrically bolts positioned in the car body with a tightening torque of 147 N/m (15 kgf/m).
4. Temporary tighten two bolts, which are positioned 90 degree apart from the bolts tightened in step (1), with a tightening torque of 147 N/m (15 kgf / m).
5. Similarly, tighten all the bolts, in parts, in parts of axisymmetrically located two, with a tightening torque of 147 N/m (15 kgf / m).
6. Fully tighten all the bolts with a tightening torque of 2.51 to 3.07 kN/m (256 to 313 kgf/m).
7. After all the bolts are tighten to the car body, fully apply molybdenum disulfide grease to the gear tooth faces.
8. Place the upper unit with the roll pins inserted in the front and rear sides fitting to the bearing.
9. Tighten the four bolts which are located on the front both ends and rear both ends of the swing frame side with a tightening torque of 147 N/m (15 kgf / m).
10. Tighten the bolts axisymmetrically one after another with a tightening torque of 147 N / m (15 kgf N / m).
11. Tighten all the bolts with a tightening torque of 2.51 to 3.07 kN / m (256 to 313 kgf / m).

8.5 SWING LOCK





---

## 9. PROPEL SYSTEM




## 9.1 LOCATION OF THE MAJOR COMPONENTS

The Propel system consists of the main pump, the main control valve, the propel motors, the propel reduction units, the upper/lower rollers, the drive tumbler, idlers and shoes.

Pressurized oil from the main pumps (No. 1 and No. 2 installed on the power divider) is controlled through the main control valve. This stream of pressurized oil flows through the swivel joint and then on to the left and right propel motors to run their respective motors.


A spring set/hydraulic release disk brake is installed on each of the two propel motors (built-in type).



9.2 CONSTRUCTION AND FUNCTION

9.2.1 HYDRAULIC SCHEMATIC

Propel hydraulic schematic



This page is blank for editing convenience.

## 9. PROPEL SYSTEM

---

### 9.2.2 PROPELLING (RIGHT SIDE FORWARD)

Propeling the right and/or left sides and to the forward and reverse are basically the same operation.

We will use a rightside forward operation as the example here.

Pressurized oil from the main pump (No. 2) is directed into the control valve.

The oil from the control pump goes through the accumulator and into the propel circuit's remote control valve.

(The machine's function lock lever remains in the "Operation" position.)


When the right propel control lever is shifted to "forward" the control oil runs through the remote control valve to the control valve's [PRF] port to shift the spool of the propel section.

The pressurized oil directed by the control valve then goes through the swivel joint and runs into the propel motor. At the same time, this oil runs into the pilot of the brake valve and the brake cylinder.

The oil in this cylinder releases the brake, and the oil in the brake valve pilot moves the spool, so that the pressurized oil releases the mechanical and hydraulic brake.

The pressurized oil that activated the propel motor then is free to return to the reservoir.

Propel R.H.(forward) hydraulic schematic



## 9. PROPEL SYSTEM

---

### 9.2.3 STOPPING

When the propel control lever is shifted back to neutral from propel position, the flow from the remote control valve is cut and the spool of the control valve repositions itself. At the same time, the pilot pressure on the propel brake valve is discontinued, and the spool in the brake valve also repositions itself.


Inertia may continue momentarily to rotate the propel motor. This creates negative pressure on the supply side and high pressure on the return side. Therefore, the supply side is connected to the reservoir in neutral.

If extreme pressure develops on the return side, an overload relief valve will open to protect the circuit.


At the same time, the pressurized oil in the brake cylinder is returned to the reservoir, and the parking brake engages slowly.





Stopping hydraulic schematic



9.3 PROPEL REDUCTION UNIT



9.3.1 MOTOR AND REDUCTION UNIT



## 9. PROPEL SYSTEM

|                    |                     |                            |
|--------------------|---------------------|----------------------------|
| 1. Cover           | 30. Floating Seal   | 59. Retaining ring         |
| 2. Corner          | 31. Seal cover      | 60. Retaining ring         |
| 3. Corner pin      | 32. Thrust ring     | 61. Shifter piston         |
| 4. Bearing         | 33. Shim            | 62. Piston seal            |
| 5. Thrust washer   | 34. Bearing spacer  | 63. Ball joint             |
| 6. Planetary gear  | 35. Capscrew        | 64. Ball                   |
| 7. Spring pin      | 36. Capscrew        | 65. Orifice                |
| 8. Spacer          | 37. Capscrew        | 66. Orifice                |
| 9. Sun gear        | 38. Capscrew        | 67. Oil seal               |
| 10. Sun gear       | 39. Plug            | 68. Spring                 |
| 11. Carrier        | 40. Plug            | 69. Spring                 |
| 12. Carrier pin    | 41. O-ring          | 70. Brake Spring           |
| 13. Bearing        | 42. Casing          | 71. Bearing                |
| 14. Thrust washer  | 43. Rear Cover      | 72. Bearing                |
| 15. Planetary gear | 44. Cylinder brock  | 73. Capscrew               |
| 16. Spring pin     | 45. Shoe retainer   | 74. Shim                   |
| 17. Sun gear       | 46. Friction plate  | 75. Parallel pin           |
| 18. Corner         | 47. Brake piston    | 76. O-ring                 |
| 19. Corner pin     | 48. Separated plate | 77. O-ring                 |
| 20. Needle bearing | 49. Valve plate     | 78. O-ring                 |
| 21. Thrust washer  | 50. Shaft           | 79. O-ring                 |
| 22. Planetary gear | 51. Coupling        | 80. O-ring                 |
| 23. Coupling       | 52. Swash plate     | 81. Over load relief valve |
| 24. Holder         | 53. Pivot           | 82. Pilot valve            |
| 25. Ring gear      | 54. Spring holder   | 83. Brake valve            |
| 26. Housing        | 55. Piston Assembly | 84. Plug                   |
| 27. Bearing        | 56. D-Ring          | 85. Plug                   |
| 28. Shim           | 57. D-Ring          |                            |
| 29. Spring pin     | 58. Check valve     |                            |

| Item | Name                   | Size     | Tightening Torque N-m (ft-lbs) |                    |
|------|------------------------|----------|--------------------------------|--------------------|
|      |                        |          |                                |                    |
| 35   | Capscrew               | M12 X 35 | 106 to 130 (78.2 to 95.8)      | Apply Loctite #242 |
| 36   | Capscrew               | M12 X 30 | 106 to 130 (78.2 to 95.8)      | Apply Loctite #242 |
| 37   | Capscrew               | M18 X 55 | 363 to 441 (267.7 to 325.3)    | Apply Loctite #242 |
| 38   | Capscrew               | M10 X 30 | 61.8 to 76.4 (45.6 to 55.6)    | Apply Loctite #242 |
| 39   | Plug                   | PT 3/4   | 88.3 to 107.9 (65.1 to 78.6)   | Wrap a seal tape   |
| 40   | Plug                   | PF 1/4   | 26.5 to 32.3 (19.6 to 23.8)    | -                  |
| 73   | Capscrew               | M18 X 50 | 291 to 356 (140.9 to 262.5)    | -                  |
| 81   | Over load relief valve | -        | 98.1 to 117.7 (72.4 to 86.8)   | -                  |

Assembly weight about 950 kg (2094 lbs)

## 9.4 ADJUSTMENT




If the crawler shoes are too tight, the shoes wear quickly and a connection between two shoes could break.

On the other hand, if the shoes are too loose, the shoes may ride off the drive sprocket and idler wheel during the travel operation. To prevent these occurrence from happening, it is required to adjust shoe tension. To adjust shoe tension, proceed as follows:

1. Move the machine forward about the crawler length so that the slackening of the crawler shoes appear on the upper side of the crawler.
2. Remove all the shims from shim pack (A).
3. Set the hydraulic jack in the position between the bracket and block of the side frame. Operate the jack to push the idler wheel, and remove the slackening of the shoes.
4. Insert the shims removed from pack (A) in step 2 into the vacant room of pack (B). Insert the remaining shims into pack (A).
5. Remove the hydraulic jack. Store spare shims in the shim pack (A).

### Note

Equalize the tension in right and left crawler tracks.





---

## **10. ELECTRIC SYSTEM**

**CAUTION**

1. Before unplugging or plugging in the connector, be sure to shut off the power supply (set the starter switch to the OFF position).
2. When unplugging the connector, hold it with both hands and draw it straight, while pressing down the catch. DO NOT pull on the cable. Otherwise, the inner conductors can be damaged. NEVER twist or pry the connector. Otherwise, its internal female terminal will be expanded, leading to disconnection.
3. When plugging in the connector, fully insert it until the catch is engaged (clicks into position). Otherwise, disconnection can occur later.
4. When performing a continuity test or voltage measurement on the connector, follow the procedure below.

• Square connector

For easy measurement, place the measurement probes of the multimeter onto the pins of male side connector. NEVER insert the probe of the multimeter into the socket of the female side connector. Otherwise, disconnection can occur later.

• Round waterproof connector

The male side connector has waterproof construction, and the measurement probe of the multimeter cannot touch its pins. Therefore, place the measurement probes onto the terminals on the female side connector. NEVER forcibly insert the measurement probe. Otherwise, disconnection can occur later. Short-circuiting across terminals inside a connector can damage electronic components. Be absolutely careful to prevent short-circuit.

**Harness line Color**

Base single color

| Color Sign | Color Name  |
|------------|-------------|
| B          | Black       |
| W          | White       |
| R          | Red         |
| G          | Green       |
| Y          | Yellow      |
| Br         | Brown       |
| -          | Blue        |
| Gr         | Gray        |
| O          | Orange      |
| Sb         | Skyblue     |
| P          | Pink        |
| Lg         | Light green |

Multi color

| Color Sign | Base Color  | Line Color |
|------------|-------------|------------|
| WR         | White       | Black      |
| RB         | Red         | Black      |
| GB         | Green       | Black      |
| YB         | Yellow      | Black      |
| BrB        | Brown       | Black      |
| lB         | blue        | Black      |
| GrB        | Gray        | Black      |
| OB         | Orange      | Black      |
| SbB        | Skyblue     | Black      |
| PB         | Pink        | Black      |
| LgB        | Light blue  | Black      |
| BW         | Black       | White      |
| RW         | Red         | White      |
| GW         | Green       | White      |
| YW         | Yellow      | White      |
| LW         | blue        | White      |
| Wl         | White       | blue       |
| Yl         | Yellow      | blue       |
| Gl         | Gray        | blue       |
| Sbl        | Skyblue     | blue       |
| Pl         | Pink        | blue       |
| Lgl        | Light green | blue       |
| WR         | White       | Red        |

| Color Sign | Base Color  | Line Color |
|------------|-------------|------------|
| YR         | Yellow      | Red        |
| GR         | Gray        | Red        |
| SbR        | Skyblue     | Red        |
| PR         | Pink        | Red        |
| LgR        | Light green | Red        |
| BY         | Black       | Yellow     |
| BR         | Black       | Red        |
| WY         | White       | Yellow     |
| WG         | White       | Green      |
| RY         | Red         | Yellow     |
| RL         | Red         | Green      |
| RL         | Red         | blue       |
| GR         | Green       | Red        |
| GY         | Green       | Yellow     |
| GL         | Green       | blue       |
| YG         | Yellow      | Green      |
| BrW        | Brown       | White      |
| BrR        | Brown       | Red        |
| BrY        | Brown       | Yellow     |
| LR         | blue        | Red        |
| LY         | blue        | Yellow     |
| LgY        | Light green | Yellow     |
| LgW        | Light green | White      |



10.1 ELECTRICAL WIRING SCHEMATIC

Note: Devices indicated in dotted line are not used in this model.

| KEY SWITCH |   |
|------------|---|
| OFF        | 0 |
| ON         | 1 |
| STOP       | 2 |
| START      | 3 |




Fig.10-1 GK03Z00008P1 (1/11)




Fig.10-2 GK03Z00008P1 (2/11)




Fig.10-3 GK03Z00008P1 (3/11)

10. ELECTRIC SYSTEM




Fig.10-4 GK0320008P1 (4/11)






Fig.10-6 GK03Z00008P1 (6/11)




Fig.10-7 GK03Z00008P1 (7/11)





| SWITCH |          |                             |   |                  |
|--------|----------|-----------------------------|---|------------------|
| SY-NO. | LINE NO. | USE                         | Q | QIBELCO PART NO. |
| SW-1   | 01-01    | OVER CUP                    | 1 | 400000001        |
| SW-2   | 02-01    | FR. DRUM WINCH SELECT       | 1 | 400000002        |
| SW-3   | 02-02    | RE. DRUM WINCH SELECT       | 1 | 400000002        |
| SW-4   | 02-03    | 3RD DRUM WINCH SELECT       | 1 | 400000002        |
| SW-5   | 02-04    | PROPEL SPEED SELECT         | 1 | 400000002        |
| SW-6   | 02-05    | TRUCKED SPEED SELECT        | 5 | 400000002        |
| SW-10  | 02-06    | SWING NOSE SELECT           | 1 | 247000007        |
| SW-11  | 02-07    | AIRING PARKING BRAKE        | 1 | 400000002        |
| SW-12  | 02-08    | SAFETY CONTROL              | 1 | 247000007        |
| SW-13  | 02-09    | HOSE OVERHEAT RELEASE       | 3 | 247000007        |
| SW-14  | 02-10    | ROCK OVERHEAT RELEASE       | 3 | 247000007        |
| SW-15  | 02-11    | LFI RELEASE                 | 3 | 247000007        |
| SW-16  | 02-12    | MASTER KEY                  | 3 | 247000007        |
| SW-17  | 02-13    | R-PERFORM UPPER             | 6 | 400000001        |
| SW-18  | 02-14    | R-PERFORM LOWER             | 6 | 400000001        |
| SW-19  | 02-15    | WIPER ON/OFF                | 5 | 400000001        |
| SW-20  | 02-16    | NOON LIGHT                  | 6 | 400000001        |
| SW-21  | 02-17    | NIGHT LIGHT                 | 6 | 400000001        |
| SW-22  | 02-18    | MOCK LIGHT (EARM)           | 6 | 400000001        |
| SW-23  | 02-19    | SMILING ALARM SELECT        | 6 | 400000001        |
| SW-24  | 02-20    | HOOK                        | 6 | 400000001        |
| SW-25  | 02-21    | PROPEL SWING NOISE ALARM    | 6 | 400000001        |
| SW-27  | 02-22    | FREE FALL NOISE ALARM       | 6 | 400000001        |
| SW-30  | 02-23    | ROCK JIB                    | 3 | 400000001        |
| SW-33  | 02-24    | DRUM FLAM DETECT SWIP       | 6 | 400000001        |
| SW-35  | 02-25    | STOP SWICH                  | 3 | 247000007        |
| SW-36  | 02-26    | LFI BYPASS (UP)             | 3 | 247000007        |
| SW-37  | 02-27    | LFI BYPASS (DOWN)           | 3 | 247000007        |
| SW-38  | 02-28    | PC BYPASS                   | 4 | 247000007        |
| SW-41  | 02-29    | MODE SELECT (NO)            | 6 | 400000001        |
| SW-45  | 02-30    | FREE FALL LOCK              | 1 | 400000001        |
| SW-50  | 02-31    | MULTI-MODE CONTROL POSSIBLE | 2 | 400000001        |
| SW-51  | 02-32    | WINCH SELECTOR              | 2 | 400000001        |
| SW-52  | 02-33    | FTD SELECTOR                | 1 | 247000007        |
| SW-56  | 02-34    | FR. DRUM FREE FALL SWICH    | 5 | 247000007        |
| SW-57  | 02-35    | RE. DRUM FREE FALL SWICH    | 5 | 247000007        |
| SW-58  | 02-36    | 3RD DRUM FREE FALL SWICH    | 5 | 247000007        |
| SW-59  | 02-37    | HYD OIL TEMP SP             | 1 | 400000001        |
| SW-62  | 02-38    | EMERGENCY NOBLE             | 6 | 400000001        |
| SW-64  | 02-39    | UNDULATION PEDAL SELECT     | 1 | 400000001        |
| SW-65  | 02-40    | HYDRAULIC SELECT            | 1 | 247000007        |
| SW-71  | 02-41    | L/S EMERGENCY STOP          | 5 | 400000001        |
| SW-72  | 02-42    | NOCKLE BYPASS               | 6 | 247000007        |
| SW-77  | 02-43    | MOCK LIGHT (EARM)           | 6 | 400000001        |

| PILOT LAMP |          |                         |   |                  |
|------------|----------|-------------------------|---|------------------|
| P-NO.      | LINE NO. | USE                     | Q | QIBELCO PART NO. |
| P-1        | 01-01    | FR. DRUM FREE FALL      | 5 | 400000001        |
| P-2        | 01-02    | RE. DRUM FREE FALL      | 5 | 400000001        |
| P-3        | 01-03    | 3RD DRUM FREE FALL      | 5 | 400000001        |
| P-4        | 01-04    | SMILING SWICH FREE NOSE | 1 | 400000001        |
| P-7        | 01-05    | CHECK L/S LAMP          | 5 | 400000001        |

| PRESSURE SENSOR |          |                                               |   |                  |
|-----------------|----------|-----------------------------------------------|---|------------------|
| PT-NO.          | LINE NO. | USE                                           | Q | QIBELCO PART NO. |
| PT-1            | 01-01    | WIND PUMP PRESSURE SENSOR                     | 4 | 400000001        |
| PT-3            | 01-02    | FR. DRUM HOIST NO PRESSURE SENSOR             | 4 | 400000001        |
| PT-4            | 01-03    | FR. DRUM LOWER NO PRESSURE SENSOR             | 4 | 400000001        |
| PT-5            | 01-04    | RE. DRUM HOIST NO PRESSURE SENSOR             | 4 | 400000001        |
| PT-6            | 01-05    | RE. DRUM LOWER NO PRESSURE SENSOR             | 4 | 400000001        |
| PT-7            | 01-06    | SIDE 12 IN DCM HOIST NO PRESSURE SENSOR       | 4 | 400000001        |
| PT-8            | 01-07    | SIDE 12 IN DCM LOWER NO PRESSURE SENSOR       | 4 | 400000001        |
| PT-9            | 01-08    | FR. DRUM CLUTCH PRESSURE SENSOR               | 4 | 400000001        |
| PT-10           | 01-09    | FR. DRUM CLUTCH PRESSURE SENSOR               | 4 | 400000001        |
| PT-11           | 01-10    | FR. DRUM CLUTCH PRESSURE SENSOR               | 4 | 400000001        |
| PT-12           | 01-11    | ROCK WHEEL PRESSURE SENSOR                    | 4 | 400000001        |
| PT-13           | 01-12    | ROCK LOWER PRESSURE SENSOR                    | 4 | 400000001        |
| PT-14           | 01-13    | FR. DRUM CONTROL PROPORTIONAL PRESSURE SENSOR | 4 | 400000001        |
| PT-16           | 01-14    | 3RD DRUM CONTROL PROPORTIONAL PRESSURE SENSOR | 4 | 400000001        |

| LIMIT SWITCH |      |          |                                            |                  |           |
|--------------|------|----------|--------------------------------------------|------------------|-----------|
| LS-NO.       | TYPE | LINE NO. | USE                                        | QIBELCO PART NO. |           |
| LS-1         | A.C. | 01-01    | FUNCTION LOCK                              | 1                | 400000001 |
| LS-2         | A.C. | 01-02    | MAIN HOIST OVERHEAT                        | 2                | 400000001 |
| LS-3         | A.C. | 01-03    | AUX HOIST OVERHEAT                         | 2                | 400000001 |
| LS-4         | A.C. | 01-04    | 3RD HOIST OVERHEAT                         | 2                | 400000001 |
| LS-5         | A.C. | 01-05    | TOWER JIB NOSE OVERHEAT                    | 2                | 400000001 |
| LS-6         | A.C. | 01-06    | LAPPING - 10 ALC. OVERHEAT OVERHEAT        | 2                | 247000007 |
| LS-7         | A.C. | 01-07    | CRANE ROOM OVERHEAT                        | 2                | 400000001 |
| LS-8         | A.C. | 01-08    | ROCK JIB PROPORTIONAL LAPPING JIB OVERHEAT | 2                | 400000001 |
| LS-9         | A.C. | 01-09    | ROCK WHEEL WHEEL LAPPING WHEEL OVERHEAT    | 2                | 400000001 |
| LS-10        | A.C. | 01-10    | LAPPING JIB OVERHEAT                       | 2                | -         |
| LS-12        | A.C. | 01-12    | ROCK WHEEL WHEEL LAPPING WHEEL OVERHEAT    | 2                | 400000001 |
| LS-14        | A.C. | 01-14    | ROCK LIGHT                                 | 2                | 247000007 |
| LS-15        | A.C. | 01-15    | HYD OIL FILTER ALARM                       | 5                | -         |
| LS-19        | A.C. | 01-19    | HYD OIL TEMP.                              | 5                | 247000007 |
| LS-20        | A.C. | 01-20    | BRACE COOLING OIL TEMP. (FR. DRUM)         | 5                | 400000001 |
| LS-21        | A.C. | 01-21    | BRACE COOLING OIL TEMP. (RE. DRUM)         | 5                | 400000001 |
| LS-22        | A.C. | 01-22    | L.H.E. FILTER ALARM                        | 5                | 400000001 |
| LS-26        | A.C. | 01-26    | FR. DRUM OVER HEAT DETECTOR                | 2                | 400000001 |
| LS-27        | A.C. | 01-27    | RE. DRUM OVER HEAT DETECTOR                | 2                | 400000001 |
| LS-30        | A.C. | 01-30    | HYD OIL TEMP.                              | 1                | 400000001 |
| LS-31        | A.C. | 01-31    | FR. DRUM FOOT BRAKE                        | 5                | 400000001 |
| LS-32        | A.C. | 01-32    | RE. DRUM FOOT BRAKE                        | 5                | 400000001 |
| LS-33        | A.C. | 01-33    | 3RD DRUM FOOT BRAKE                        | 5                | 400000001 |
| LS-35        | A.C. | 01-35    | A-R CLEANER ALARM                          | 5                | -         |
| LS-5         | A.C. | 01-05    | PREL FILTER                                | 5                | -         |

| FUSE  |     |          |                                        |                  |           |
|-------|-----|----------|----------------------------------------|------------------|-----------|
| F-NO. | WTR | LINE NO. | USE                                    | QIBELCO PART NO. |           |
| F-1   | 1FA | 01-01    | ELECTRIC POWER SOURCE                  | 1                | 247000007 |
| F-2   | BA  | 01-02    | BACK-UP                                | 1                | 247000007 |
| F-3   | BA  | 01-03    | PRO. SWICH                             | 1                | 247000007 |
| F-4   | BA  | 01-04    | NOSE MOTOR                             | 1                | 247000007 |
| F-5   | 1BA | 01-05    | WINCH                                  | 1                | 247000007 |
| F-6   | 1BA | 01-06    | ROCK MOTOR                             | 1                | 247000007 |
| F-7   | BA  | 01-07    | CONTROL POWER SOURCE                   | 2                | 247000007 |
| F-8   | BA  | 01-08    | LFI OVI. FLT WIPER SOURCE              | 2                | 247000007 |
| F-9   | 3BA | 01-09    | WIPER                                  | 2                | 247000007 |
| F-10  | 1BA | 01-10    | AIR COND TIMER                         | 2                | 247000007 |
| F-11  | 1BA | 01-11    | DRY-RAY-RAJIO                          | 2                | 247000007 |
| F-12  | 3BA | 01-12    | TOTAL CONTROLLER                       | 4                | 247000007 |
| F-13  | 1BA | 01-13    | ROCK CLUSTER NON TOR. CAMERA           | 3                | 247000007 |
| F-14  | 1BA | 01-14    | DRUM FLASHER                           | 2                | 247000007 |
| F-15  | 1BA | 01-15    | FUEL PUMP-TIM                          | 2                | 247000007 |
| F-16  | 1BA | 01-16    | COMPUTER WEIGHT SELF TEMPAL CONTROL SW | 3                | 247000007 |
| F-17  | 1BA | 01-17    | EMERGENCY CIRCUIT                      | 3                | 247000007 |
| F-18  | 1BA | 01-18    | W/PANE                                 | 3                | 247000007 |
| F-19  | 1BA | 01-19    | W/PANE                                 | 3                | 247000007 |
| F-20  | 1BA | 01-20    | HYDRAULIC SELECT                       | 1                | 247000007 |
| F-21  | 1A  | 01-21    | OVER HEAT                              | 2                | 247000007 |
| F-22  | 1BA | 01-22    | L/S CONTROL UNIT                       | 2                | 247000007 |
| F-27  | 1BA | 01-27    | PEYI                                   | 2                | 247000007 |
| F-28  | 1BA | 01-28    | PEYE                                   | 2                | 247000007 |
| F-29  | 1A  | 01-29    | L/S CONTROL UNIT                       | 2                | 247000007 |

Fig.10-9 GK03Z00008P1 (9/11)




| P R E S S U R E S W I T C H |       |             |                                     |                  |
|-----------------------------|-------|-------------|-------------------------------------|------------------|
| PSW NO.                     | RATED | LINE NO.    | U S E                               | KOBELOD PART NO. |
| PSW-1                       | N.O.  | 57-E<br>200 | FR. DRUM FOOT BRAKE PRESSURE SW.    | GG5300021F1      |
| PSW-2                       | N.O.  | 78-E<br>210 | R.R. DRUM FOOT BRAKE PRESSURE SW.   | GG5300021F1      |
| PSW-3                       | N.O.  | 70-E<br>227 | 3rd. DRUM FOOT BRAKE PRESSURE SW.   | GG5300021F1      |
| PSW-4                       | N.O.  | 09-243      | SWING CONTROL DEFECT SW. (L.H.)     | GG5050021F1      |
| PSW-5                       | N.O.  | 09-243      | SWING CONTROL DEFECT SW. (R.H.)     | GG5050021F1      |
| PSW-6                       | N.O.  | 09-E<br>248 | CONTROL PRIMARY PRESSURE DETECT SW. | GG5050021F1      |
| PSW-7                       | N.O.  | 09-243      | PROPEL CONTROL DEFECT SW. (L.H.)    | GG5050021F1      |
| PSW-8                       | N.C.  | 511-E       | ENGINE OIL PRESSURE SW.             | 5                |
| PSW-10                      | N.C.  | 09-243      | PROPEL CONTROL DEFECT SW. (R.H.)    | GG5050021F1      |

| S O L E N O I D V A L V E |          |                                      |     |                  |
|---------------------------|----------|--------------------------------------|-----|------------------|
| SOL. NO.                  | LINE NO. | U S E                                | QTY | KOBELOD PART NO. |
| SOL-51                    | 432-433  | SWING REACTION                       | 4   | YK35Y0018F1      |
| SOL-52                    | 413-414  | BOOM RAISE CONTROL                   | 4   | YK35Y0018F1      |
| SOL-53                    | 417-420  | BOOM LOWER CONTROL                   | 4   | YK35Y0018F1      |
| SOL-54                    | 424-426  | FR. DRUM HOIST CONTROL               | 4   | YK35Y0018F1      |
| SOL-55                    | 418-420  | FR. DRUM LOWER CONTROL               | 4   | YK35Y0018F1      |
| SOL-56                    | 427-428  | R.R. DRUM HOIST CONTROL              | 4   | YK35Y0018F1      |
| SOL-57                    | 429-430  | R.R. DRUM LOWER CONTROL              | 4   | YK35Y0018F1      |
| SOL-58                    | 431-432  | 3rd. DRUM HOIST CONTROL              | 4   | YK35Y0018F1      |
| SOL-59                    | 433-434  | 3rd. DRUM LOWER CONTROL              | 4   | YK35Y0018F1      |
| SOL-62                    | 400-410  | TAGLINE                              | 4   | GB32Y00007F1     |
| SOL-65                    | 415-418  | FR. HOIST CONTROL PROMOTIONAL VALVE  | 4   | YK35Y0018F2      |
| SOL-66                    | 427-428  | R.R. HOIST CONTROL PROMOTIONAL VALVE | 4   | YK35Y0018F2      |
| SOL-67                    | 429-430  | 3rd. HOIST CONTROL PROMOTIONAL VALVE | 4   | YK35Y0018F2      |
| SOL-70                    | 430-433  | BOOM PUMP CONTROL                    | 4   | YK35Y0018F2      |
| SOL-72                    | 401-403  | SWING CONSTANT SPEED                 | 4   | YK35Y0018F2      |
| SOL-77                    | 427-E    | BOOM/7th PEDAL SELECT                | 1   | YK35Y0038F1      |
| SOL-80                    | 400-E    | VERTICAL EXT. (FR. R.H.)             | 7   | GB35Y0002801     |
| SOL-81                    | 401-E    | VERTICAL EXT. (R.R. R.H.)            | 7   | GB35Y0002801     |
| SOL-82                    | 402-E    | CRANER FIRING P.H.(R. EXT.)          | 7   | GB35Y0002801     |
| SOL-83                    | 403-E    | CRANER FIRING P.H.(L. EXT.)          | 7   | GB35Y0002801     |
| SOL-84                    | 404-E    | VERTICAL EXT. (FR. L.H.)             | 7   | GB35Y0002801     |
| SOL-85                    | 405-E    | VERTICAL EXT. (FR. L.H.)             | 7   | GB35Y0002801     |
| SOL-86                    | 406-E    | VERTICAL RET. (FR. R.H.)             | 7   | GB35Y0002801     |
| SOL-87                    | 407-E    | VERTICAL RET. (R.R. R.H.)            | 7   | GB35Y0002801     |
| SOL-88                    | 408-E    | CRANER FIRING P.H.(R. EXT.)          | 7   | GB35Y0002801     |
| SOL-89                    | 409-E    | CRANER FIRING P.H.(L. EXT.)          | 7   | GB35Y0002801     |
| SOL-90                    | 410-E    | VERTICAL RET. (FR. L.H.)             | 7   | GB35Y0002801     |
| SOL-91                    | 411-E    | VERTICAL RET. (FR. L.H.)             | 7   | GB35Y0002801     |
| SOL-92                    | 412-E    | LEFT CYLINDER RET.                   | 7   | GB30Y00213F1     |
| SOL-93                    | 413-E    | LEFT CYLINDER EXT.                   | 7   | GB30Y00213F1     |
| SOL-94                    | 414-E    | RIGHT CYLINDER RET.                  | 7   | GB30Y00213F1     |
| SOL-95                    | 415-E    | RIGHT CYLINDER EXT.                  | 7   | GB30Y00213F1     |


| S O L E N O I D V A L V E |          |                             |     |                  |
|---------------------------|----------|-----------------------------|-----|------------------|
| SOL. NO.                  | LINE NO. | U S E                       | QTY | KOBELOD PART NO. |
| SOL-1                     | 424-E    | MAIN PUMP WCHING SPEED      | 5   | YK35Y0000F1      |
| SOL-2                     | 425-E    | BOOM PUMP WCHING SPEED      | 5   | YK35Y0000F1      |
| SOL-3                     | 426-E    | FUNCTION LOCK               | 1   | YK35Y0020F1      |
| SOL-4                     | 427-E    | PROPEL SPEED SELECT         | 1   | YK35Y0020F1      |
| SOL-5                     | 428-E    | SWING PARKING               | 1   | YK35Y0020F1      |
| SOL-10                    | 429-E    | FR. DRUM C/V                | 5   | YK35Y0020F1      |
| SOL-11                    | 430-E    | R.R. DRUM C/V               | 5   | YK35Y0020F1      |
| SOL-12                    | 431-E    | 3rd. DRUM C/V               | 5   | YK35Y0020F1      |
| SOL-15                    | 432-E    | FR. DRUM MOTOR BOOST        | 5   | YK35Y0020F1      |
| SOL-16                    | 433-E    | R.R. DRUM MOTOR BOOST       | 5   | YK35Y0020F1      |
| SOL-17                    | 434-E    | 3rd. DRUM MOTOR BOOST       | 5   | YK35Y0020F1      |
| SOL-18                    | 435-E    | 3rd. HOIST STOPING. 2I      | 2   | YK35Y0020F1      |
| SOL-19                    | 436-E    | FR. DRUM CLUTCH ESM         | 5   | GG3500001F1      |
| SOL-20                    | 437-E    | R.R. DRUM CLUTCH ESM        | 5   | GG3500001F1      |
| SOL-21                    | 438-E    | 3rd. DRUM CLUTCH EST        | 5   | GG3500001F1      |
| SOL-22                    | 439-E    | FR. DRUM CLUTCH CLM         | 5   | JJ3500011F1      |
| SOL-23                    | 440-E    | R.R. DRUM CLUTCH CLM        | 5   | JJ3500011F1      |
| SOL-24                    | 441-E    | 3rd. DRUM CLUTCH CLT        | 5   | JJ3500011F1      |
| SOL-25                    | 442-E    | HYDRAULIC SELECT            | 1   |                  |
| SOL-26                    | 443-E    | GANTRY UP                   | 1   | GG30Y00019F1     |
| SOL-27                    | 444-E    | GANTRY DOWN                 | 1   | GG30Y00019F1     |
| SOL-35                    | 552-E    | BOOM RAISE STOP (NO. 2I)    | 2   | YK35Y0020F1      |
| SOL-36                    | 554-E    | BOOM LOWER STOP (NO. 2I)    | 2   | YK35Y0020F1      |
| SOL-37                    | 553-E    | FR. DRUM HOIST STOPING. 2I  | 2   | YK35Y0020F1      |
| SOL-38                    | 555-E    | R.R. DRUM HOIST STOPING. 2I | 2   | YK35Y0020F1      |
| SOL-40                    | 445-E    | FR. DRUM TURN DEFECT GRIP   | 5   | GB50401003F1     |
| SOL-41                    | 446-E    | R.R. DRUM TURN DEFECT GRIP  | 5   | GB50401003F1     |
| SOL-42                    | 447-E    | PRESS. RELIEF SH:FT         | 1   | YK35Y00001F1     |
| SOL-44                    | 448-E    | TRANS-LIFTER SELECT         | 1   | JJ-3000003F1     |
| SOL-45                    | 449-E    | REEVING WINCH SELECT        | 1   | JJ-3000003F1     |
| SOL-47                    | 450-E    | HYD. OIL HEAT               | 1   | GG27Y00001F1     |
| SOL-48                    | 451-E    | SWING NEUTRAL MODE SELECT   | 1   | GB35Y00002F1     |
| SOL-49                    | 452-E    | SWING NEUTRAL MODE SELECT   | 1   | GB35Y00002F1     |
| SOL-50                    | 404-403  | MAIN PUMP CONTROL           | 4   | YK35Y00018F2     |

Fig.10-11 GK03Z00008P1 (11/11)


10.2 CONNECTOR LIST




CN-11F



CN-12AF




CN-13F





CN-14F


(C 75sq 3 CORE SHIELDED 5)




CN-15F




CN-17F



CN-18F



CN-21F



CN-31F


10. ELECTRIC SYSTEM

|  |            |           |           |           |           |           |           |           |  |
|--|------------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|--|
|  | 101<br>LY  | 104<br>RB | 107<br>LB | 109<br>YW | 103<br>Gr | 151<br>RY | 11E<br>I  | 120<br>GB |  |
|  | 130<br>B-R | 132<br>WB | 242<br>RG | 243<br>YB | 568<br>Y  | /         | 547<br>GR | 524<br>-P |  |

CN 32F (AVSS0.75)

|  |           |           |            |           |            |           |
|--|-----------|-----------|------------|-----------|------------|-----------|
|  | 137<br>PB | 175<br>RY | 138<br>I   | 169<br>WG | 141<br>GB  | 142<br>RB |
|  | 564<br>-Y | /         | 174<br>BrW | 164<br>G  | 165<br>B-R | 186<br>LR |

CN-33F (AVSS0.75)



|          |            |           |           |           |          |           |         |
|----------|------------|-----------|-----------|-----------|----------|-----------|---------|
| 27<br>WR | 468<br>LR  | 140<br>RY | 144<br>LA | 159<br>GR | 235<br>O | 551<br>PB | /       |
| /        | 325<br>B-R | 324<br>YI | 325<br>PB | 326<br>W. | 448<br>Y | 450<br>DW | 55<br>B |


CN-35F

|           |           |           |           |           |           |
|-----------|-----------|-----------|-----------|-----------|-----------|
| 329<br>YB | 323<br>D  | 330<br>GB | 331<br>RL | 358<br>SB | 367<br>WY |
| 308<br>L  | 368<br>FL | 353<br>WR | 356<br>RY | 338<br>LB | 397<br>WG |


CN-36F (AVSS0.75)

|           |           |            |           |           |          |           |           |           |           |
|-----------|-----------|------------|-----------|-----------|----------|-----------|-----------|-----------|-----------|
| 312<br>YR | 313<br>RL | 314<br>Br  | 315<br>YU | 318<br>LR | 319<br>P | 320<br>YL | 321<br>G- | 474<br>DW | 477<br>R# |
| 479<br>WY | 478<br>PW | 434<br>GrI | 435<br>GB | 43E<br>Y  | 437<br>P | 471<br>W  | 172<br>WG | 267<br>-  | 480<br>55 |


CN-37F (AVSS0.75)




CN-41F



CN-43AF




CN-43BF




CN-42M




CN-46M




CN-42AF




CN-46F




CN-42BF




CN-44M




CN-45M









CN-43M








CN-47F




CN-47M











CN-101F (Ø 75mm 2 CORE SHIELDED ☉)




CN-102F




10. 5aa 3 CORR SHIELDED (1)


10. 5aa 3 CORR SHIELDED (2)

10. 5aa 3 CORR SHIELDED (3)







CN-113F




CN-113AM



CN-115F




CN-113M




CN-114F




CN-115M




CN-114AM



CN-108F




CN-109F




CN-110F

(0.5sq 3 CORE SHIELDED ②)




CN-120F


(0.5sq 3 CORE SHIELDED ②)











CN-120M
















CN-121F



CN-121M








CN-159M




CN-150F




CN-162M




CN-150F




CN-160M




CN-163F  
(AVSSO. 75)



CN-154F




CN-161F




CN-164F  
(AVSSO. 75)



CN-154M




CN-161M



CN-173F




CN-155F




CN-162F



CN-173M



CN-155M




CN-174F




CN-177M



CN-178F




CN-181M




CN-174M




CN-178M




CN-176F  
(AVSS0.75)




CN-179F




CN-187F



CN-176F  
(AVSS0.75)




CN-186M




CN-187M



CN-177F














CN-186F




CN-187M








CN-216F



CN-217F


10.75sq 2 CORE SHIELDED ① :




CN-223F




CN-224F



CN-224M




CN-235F




CN-237F


① C CN 560F  
② C CN-327M



CN-237M




CN-239F



CN-240F




CN-239M




CN-240M


AVSSD. 7E




CN-241F




CN-243M




CN-249M




CN-244F (AVSS0.75)




CN-244M




CN-251F




AVSS0.75 CN-246M




CN-251M




CN-248F




CN-259F 1.25sq




CN-260F




CN-260M




CN-261M



CN-261F



CN-294M




CN-294F




CN-298M




CN-298F




CN-272F




CN-295M




CN-295F




CN-296M




CN-296F




CN-263F




CN-263M




CN-299F







CN-311M




CN-312F




CN-312M




CN-314F



CN-315F




CN-315M



CN-316F

|                     |           |           |
|---------------------|-----------|-----------|
| 314<br>BrR          | 19<br>RW  | 613<br>LY |
| E <sub>1</sub><br>S | E12<br>LE | 611<br>#Y |

CN-322F




CN-318M


1.25sq

|                     |           |            |
|---------------------|-----------|------------|
| 603<br>GY           | 13<br>RW  | 600<br>YB  |
| E <sub>1</sub><br>S | 607<br>RY | 60E<br>JrW |

CN-323F



CN-323M




CN-317F

1.25sq

|                     |           |           |
|---------------------|-----------|-----------|
| 604<br>G/W          | 18<br>RW  | 603<br>LG |
| E <sub>1</sub><br>B | 602<br>YL | 607<br>WB |

CN-324F




CN-317M

25sq 255sq

|                     |          |            |          |
|---------------------|----------|------------|----------|
| 613<br>Y            | 25<br>R1 | 20<br>YB   | 19<br>RW |
| E <sub>1</sub><br>B |          | 314<br>BrR |          |

CN-325F












CN-321F

1.75sq 2sq


|            |                     |          |           |
|------------|---------------------|----------|-----------|
| 19<br>RW   | 20<br>YB            | 25<br>RL | 615<br>LY |
| 614<br>BrR | E <sub>1</sub><br>B |          |           |

C 55sq  
1.25sq  
CN-325M










CN-330F


CN-330M



CN-332M







(TWISTED PAIR D. 65sa ②)









(TWISTED PAIR D. 85sa ②)







FAN SW




TRISTED PAIR 0 8E




CN-381F




CN-386M




CN-382F




CN-384F




CN-387F



CN-382M




CN-384M




1.25mm

CN-388F




CN-383F




1.25mm

CN-385F




1.25mm

CN-389F




CN-383M




1.25mm


CN-385M



CN-389M




CN-390F




CN-392F




CN-392M



CN-394F



CN-401F




CN-404F




CN-402F



CN-404M



CN-403F

















CN-405F




CN-403M




CN-405M







CN-502F




CN-503F




CN-504F




CN-505F




CN-505M




CN-506F



CN-506M




CN-507F



CN-509F




CN-509M




CN-510F



CN-510M




CN-511F




CN-507M




CN-512F




CN-508F




CN-513F




CN-508M




CN-513M




CN-514F




CN-515F




CN-514M




CN-515M










CN-516F




CN-518F




CN-516M









CN-523F  
(AVSS0.75)




CN-531F




CN-528F  
(AVSS0.75)




CN-531M




CN-530F




CN-533F  
(AVSS0.75)



CN-530M




CN-536F  
(AVSS0.75)




CN-536M




CN-541F




CN-544F  
(AVSS0.75)




CN-537F  
(AVSS0.75)




CN-542F  
(AVSS0.75)




CN-544M




CN-539F  
(AVSS0.75)




CN-542M



CN-545F




CN-539M




CN-543F




CN-540F




CN-543M




CN-545M



CN-546F  
(AVSS0.75)




CN-546M




CN-547F




CN-548F




CN-549M




CN-549F




CN-550M











CN-550F




CN-551M




CN-551F







CN-555M (AVSSO. 75)




CN-556F  
(AVSSO. 75)




CN-557M




CN-557F




CN-558M




CN-558F




CN-559A




CN-559F




CN-560M




CN-560F



CN-561M




CN-561F



CN-562F


AVSSO. 75

AVSSO. 75  
AVSSO. 85




CN-562M
















AVSSO. 75














CN-563M




CN-563F











CN-595M




A9550 7E


CN-595F




CN-596M




CN-596F




CN-597M




CN-597F




CN-598M




CN-598F



CN-601F




CN-602F




CN-603F



CN-605F




CN-652M




CN-652F



CN-671F



CN-673M




CN-673F



(AVSSO. 5)  
(AVSSO. 65)


CN-751F




CN-777F




CN-801M



CN-801F




CN-802M




CN-802F




CN-804M



CN-804F



CN-805M




CN-805F



CN-807M




CN-807F




CN-808F




CN-812M




CN-812F




CN-815M




CN-815F




CN-81BM




CN-81BF




CN-817M




CN-817F




CN-819F




CN-823M




CN-823F




CN-821F




CN-853M




CN-853F




CN-851M




CN-851F  
(AVSSD. 75)



CN-858F














CN-855M













CN-855F




CN-858M







10. 750 2 CORE SHIELD (L) 361 (W)  
 10. 750 2 CORE SHIELD (L) 382 (B)  
 10. 750 2 CORE SHIELD (L) E1 (BR)




CN-935F




CN-937M  
(AVSSO. 5)




CN-937F




CN-938M









CN-938F  
(AVSSO. 5)



CN-939M




CN-939F




|     |     |
|-----|-----|
| 11  | 53  |
| WC  | LR  |
| 857 | 955 |
| Y   | YE  |


**CN-944F**




CN-945M




CN-945F




CN-949F



CN-953F A26  
(AVSS0. 5)



















CN-954F A27  
(AVSS0. 5)

























CN-955F A28  
(AVSS0. 5)

















CN-J23M




CN-J23F




CN-J41M




CN-J41F




CN-J50M




CN-J50F




CN-J99M




CN-J99F



CN-J102M




CN-J102F  
(AVSS1. 25)




CN-J105M

- ① 10.75sq 2 CORE SHIELDED ① 823 (W) ITC CN-937F
- ② 10.75sq 2 CORE SHIELDED ① 823 (W) ITC CN-937F
- ③ AVSS0.85170 CN-950F 823 (W)
- ④ AVSS0.85170 CN-950F 823 (W)
- ⑤ AVSS0.85170 CN-957F 826 (W)
- ⑥ AVSS0.85170 CN-957F 826 (W)
- ⑦ 10.75sq 2 CORE SHIELDED ① 826 (W) ITC CN-977F
- ⑧ 10.75sq 2 CORE SHIELDED ① 826 (W) ITC CN-977F




CN-J105F



CN-J106M

- ▼ ITC CN-937F 84 (YB)
- ▼ ITC CN-947F 84 (YB)
- ④ 04 LY01 ITC CN-938F


CN-J106F (AVSS0.5)



CN-J109M

- ① 10.75sq 2 CORE SHIELDED ① EG0 (BR) ITC CN-977F
- ② 10.75sq 2 CORE SHIELDED ① EG0 (BR) ITC CN-977F
- ③ 10.75sq 2 CORE SHIELDED ① EG0 (BR) ITC CN-977F
- ④ 10.75sq 2 CORE SHIELDED ① EG0 (BR) ITC CN-977F
- ⑤ 10.75sq 2 CORE SHIELDED ① EG0 (BR) ITC CN-977F
- ⑥ 10.75sq 2 CORE SHIELDED ① EG0 (BR) ITC CN-977F
- ⑦ 10.75sq 2 CORE SHIELDED ① EG0 (BR) ITC CN-977F
- ⑧ 10.75sq 2 CORE SHIELDED ① EG0 (BR) ITC CN-977F
- ⑨ EG0 (BR) ITC CN-977F
- ⑩ EG0 (BR) ITC CN-977F
- ⑪ EG0 (BR) ITC CN-977F
- ⑫ EG0 (BR) ITC CN-977F


CN-J109F



CN-J111M

- ① ITC CN-950M EG0 (BR)
- ② ITC CN-950M EG0 (BR)
- ③ ITC LA-881 EG0 (BR)
- ④ ITC CN-913M 25 (R)
- ⑤ ITC CN-950M 25 (R)
- ⑥ EG0 (BR) ITC CN-950M
- ⑦ 25 (RL) ITC CN-977F
- ⑧ 25 (RL) ITC CN-977F

CN-J111F



CN-J112M

- ① ITC CN-951M EG0 (BR)
- ② ITC CN-951M EG0 (BR)
- ③ ITC CN-912M EG0 (BR)
- ④ EG0 (BR) ITC CN-951M
- ⑤ EG0 (BR) ITC CN-951M
- ⑥ EG0 (BR) ITC CN-951M
- ⑦ EG0 (BR) ITC CN-951M
- ⑧ EG0 (BR) ITC CN-951M
- ⑨ EG0 (BR) ITC CN-951M
- ⑩ EG0 (BR) ITC CN-951M


CN-J112F




10. ELECTRIC SYSTEM

10.3 ARRANGEMENT OF ELECTRICAL PART


10.3.1 ELECTRICAL PART OF CAB





ENGINE CONTROL UNIT








10. ELECTRIC SYSTEM





VIEW J

# 10. ELECTRIC SYSTEM

## 10.3.2 ELECTRICAL PART OF RIGHT DECK




Fig.10-12 GG01E00071 (1/8)




Fig.10-13 GG01E00071 (2/8)




Fig.10-14 GG01E00071 (3/8)





Fig.10-15 GG01E00071 (4/8)






Fig.10-16 GG01E00071 (5/8)



RIGHT DECK HARNESS B






Fig.10-17 GG01ED0071 (6/8)






Fig.10-18 GG01E00071 (7/8)





Fig.10-19 GG01E00071 (6/8)

# 10. ELECTRIC SYSTEM

## 10.3.3 ELECTRICAL PART OF FLOOR PLATE & LEFT SIDE STAND PANEL




Fig.10-20 GG01E00068 (1/5)




Fig.10-21 GG01E00068 (2/5)





Fig.10-22 GG01E00068 (3/5)



DETAIL OF SEAT STAND




Fig.10-23 GG01E00068 (4/5)




Fig.10-24 GG01E00068 (5/5)



10.3.4 ELECTRICAL PART OF REVOLVING FRAME







Fig.10-25 GK01E00029 (1/3)



SECTION A-A



SECTION B-B



SECTION C-C

Fig.10-26 GK01E00029 (2/3)




Fig.10-27 GK01E00028 (3/3)

10. ELECTRIC SYSTEM

10.3.5 ELECTRICAL PART OF LEFT DECK




Fig.10-28 GH01E00001 (1/7)





Fig.10-29 GH01E00001 (2/7)







Fig.10-30 GH01E00001 (3/7)



SECTION D-D



SECTION E-E

Fig.10-31 GH01E00001 (4/7)

10. ELECTRIC SYSTEM




Fig.10-32 GH01E00001 (5/7)






Fig.10-33 GH01E00001 (6/7)





Fig.10-34 GH01E00001 (7/7)

10.3.6 ELECTRICAL PART OF LEFT GUARD





10.4 ELECTRICAL PART

10.4.1 FUSE BOX (GG73E00004F1)


**⚠ DANGER**

1. In the case that a same fuse is frequently burnt out, it is considered that burning out of the fuse may be due to some fault in the electric circuit and it is not yet repaired. In such case, absolutely do not replace the burnt fuse simply with a fuse over the specified capacity. This could cause damage to the wiring and electrical apparatus.
2. In the above case, or when installing a new optional apparatus, be sure to consult the service shop of our representative. They will make a proper treatment or give a proper instruction.
3. When replacing the fuse with a new one, be sure to turn the key switch off.






### Fuse Connection Schematic






# 10. ELECTRIC SYSTEM


## 10.4.2 WIPER CONTROL UNIT (2480U306)



10.4.3 SWING FLASHER UNIT (2480U306)




TERMINAL MARKS




## 10. ELECTRIC SYSTEM

### 10.4.4 PRESSURE SWITCH (CONTROL PRESSURE CUT & FREE FALL) (GG52S00006P1)



- 1 --- W --- COMMON
- 2 --- R --- POWER (+)
- 3 --- NC
- 4 --- G --- Open collector (-)






| Use                                             | Part number                 | (ON)<br>Pressure MPa<br>(Psi) | (ON)<br>Pressure MPa<br>(Psi) | Pressure Range<br>MPa (Psi) |
|-------------------------------------------------|-----------------------------|-------------------------------|-------------------------------|-----------------------------|
| Foot Pedal (Front•Rear•3rd)<br>Control Pressure | GG50S00006P1<br>(N.O. Type) | 4.4 (640)                     | 3.6 (522)                     | 0 to 19.6<br>(0 to 2843)    |



## 10.4.5 PRESSURE SENSOR

(LC52S00011P1 - LC52S00012P1)




| Use                                             | Part number  | Pressure range MPa (psi) | Power (V) | Out-put (V) |
|-------------------------------------------------|--------------|--------------------------|-----------|-------------|
| • Remote control pressure (Front-Rear-3rd-Boom) | LC52S00011P1 | 0 to 3.5 (0 to 507)      | 5         | 0.5 to 4.5  |
| • Control pressure (Rear-3rd)                   |              |                          |           |             |
| • Swing pump pressure                           | LC52S00012P1 | 0 to 50 (0 to 7252)      | 5         | 0.5 to 4.5  |

## [ NOTE ]

| LC52S00011P1                                      | LC52S00012P1                                      |
|---------------------------------------------------|---------------------------------------------------|
| • Pressure range : 0 to 3.0 MPa                   | • Pressure range : 0 to 49 MPa                    |
| • Voltage Vcc : 5.0 ± 0.5 V DC                    | • Voltage Vcc : 5.0 ± 0.5 V DC                    |
| • Out-put : 1/10 Vcc to 9/10 Vcc = 0.5 V to 4.5 V | • Out-put : 1/10 Vcc to 9/10 Vcc = 0.5 V to 4.5 V |
| • Tightening torque : 38.3 N-m max (26.7 ft-lbs)  | • Tightening torque : 73.5 N-m max (54.2 ft-lbs)  |

## 10. ELECTRIC SYSTEM



### GN52S00002P1



Location of connector terminal

Terminal No.

- 1...COMMON
- 2...OUT-PJ1 (+)
- 3...POWER (+)



| Use                                 | Part number  | Pressure range MPa<br>(psi) | Power (V) | Out-put (V) |
|-------------------------------------|--------------|-----------------------------|-----------|-------------|
| Clutch pressure<br>(Front-Rear-3rd) | GN52S00002P1 | 0 to 19.6 (0 to 2842)       | 5         | 0.5 to 4.5  |



[ NOTE ]

GN52S00002P1

\* Tightening torque : 73.5 N·m

10.4.6 RELAY BOX (GG24E00024F1)

10.4.6.1 ARRANGEMENT OF CONNECTOR



10. ELECTRIC SYSTEM

|         |           |           |           |           |           |           |           |           |          |           |           |           |           |
|---------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|----------|-----------|-----------|-----------|-----------|
|         | 443<br>G  | 238<br>LY | 233<br>LB | 118<br>SE | 189<br>CW | 200<br>YR | 139<br>SW | 198<br>W  | 197<br>Y | 166<br>D  | 157<br>R  | 170<br>WL | 18<br>GrL |
| E,<br>B | 451<br>PW | 445<br>GR | 112<br>LR | 110<br>GL | /         | /         | /         | 153<br>Br | /        | 131<br>RD | 129<br>WJ | 103<br>P  | /         |

CN-31

|         |           |           |           |           |           |           |           |            |
|---------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|------------|
|         | 120<br>GR | 115<br>I  | 151<br>RY | 109<br>Gr | 108<br>PW | 107<br>LB | 104<br>RB | 101<br>LY  |
| E,<br>B | 524<br>Lb | 647<br>GR | /         | 588<br>Y  | 243<br>YB | 242<br>RG | 137<br>WR | 130<br>GrR |

CN-32

|         |           |            |           |            |           |           |
|---------|-----------|------------|-----------|------------|-----------|-----------|
|         | 142<br>RB | 141<br>GW  | 168<br>WG | 129<br>L   | 176<br>RY | 137<br>GW |
| E,<br>B | 186<br>IR | 185<br>BrR | 164<br>YR | 174<br>BrW | /         | 584<br>LY |

CN-33

|         |           |          |          |           |           |           |           |           |           |            |           |
|---------|-----------|----------|----------|-----------|-----------|-----------|-----------|-----------|-----------|------------|-----------|
|         | 552<br>PW | 128<br>G | 180<br>U | 146<br>PW | 123<br>GR | 122<br>Lb | 121<br>Sb | 139<br>RG | 135<br>YL | 27<br>WY   | 18<br>YR  |
| E,<br>B | 147<br>L  | /        | /        | 258<br>WG | 238<br>LR | 187<br>GY | 152<br>O  | 143<br>LB | 118<br>W  | 554<br>GrL | 553<br>LW |

CN-34

|         |           |          |           |           |           |            |          |
|---------|-----------|----------|-----------|-----------|-----------|------------|----------|
| E,<br>B | 551<br>GW | 269<br>H | 158<br>GR | 144<br>LW | 140<br>RY | 468<br>LR  | 27<br>WR |
|         | 450<br>WL | 448<br>Y | 328<br>WL | 325<br>PW | 324<br>YL | 323<br>BrW | /        |

CN-35


|         |           |           |           |           |           |           |
|---------|-----------|-----------|-----------|-----------|-----------|-----------|
|         | 357<br>WY | 359<br>Sb | 331<br>RL | 330<br>GB | 329<br>G  | 328<br>YB |
| E,<br>B | 357<br>WG | 398<br>LD | 396<br>RY | 393<br>WR | 388<br>PL | 309<br>L  |


CN-36


|         |           |           |           |           |           |           |           |            |           |           |
|---------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|------------|-----------|-----------|
|         | 477<br>RW | 474<br>CW | 321<br>G  | 320<br>Y  | 319<br>P  | 318<br>LR | 315<br>YG | 314<br>B   | 313<br>RL | 312<br>YR |
| E,<br>B | 480<br>Sb | 267<br>L  | 172<br>WG | 171<br>LW | 437<br>Lb | 436<br>Y  | 435<br>GW | 434<br>GrL | 418<br>PW | 478<br>WY |

CN-37

10.4.6.2 RELAY BOX SCHEMATIC









10. ELECTRIC SYSTEM

10.4.7 LEFT SIDE STAND PANEL








GG17M01050F4 (Free-fall spec.)

CKE1100







CKE1100









10. ELECTRIC SYSTEM

CK1200



CK1200



## 10.5 TROUBLESHOOTING OF EXHAUST GAS THIRD REGULATION ENGINE


### 10.5.1 FAILURE DIAGNOSIS FUNCTION

ECU always diagnoses whether or not the sensors malfunction while the key switch (M) is turned ON, and if lights on the diagnosis lamp when the sensor is judged as being malfunctioned and restores the place of failure at the same time to inform the operator of abnormality and ECU restricts the injection amount of fuel depending on the failure content.

It is possible to check the place of failure by using the diagnosis lamp or the diagnosis tool via the DST-1 connector.

- Diagnosis lamp status while the key is turned ON  
The lamp lights on when the key is ON (M) and engine is stopped as shown in the following chart. When the lamp does not go off even if the engine has been started, promptly stop the engine after avoiding danger because the system may have abnormality.

How to turn off the engine trouble detect lamp




### 10.5.2 HOW TO CHECK THE FAILURE CONTENTS

When the abnormality is detected by the diagnosis lamp, the diagnosis code can be checked by connecting the diagnosis switch.

(1) Position of the equipment related to the diagnosis

- Position of ECU
- Position of the diagnosis lamp
- Position of the diagnosis switch
- Position of the DST-1 connector



# 10. ELECTRIC SYSTEM

## (2) Table of Diagnosis codes

| DAF code | System                                     | Diagnosis code | Function                                                 | Check lamp | Failure criteria                                                        | Recovery timing                     | Injection amount restriction | Affect to engine | Remarks                                                                                                         |
|----------|--------------------------------------------|----------------|----------------------------------------------------------|------------|-------------------------------------------------------------------------|-------------------------------------|------------------------------|------------------|-----------------------------------------------------------------------------------------------------------------|
| P0217    | Sensor systems and their element diagnosis | 5              | Overheat                                                 | —          | Water temperature 115°<br>After 500°Cm or higher<br>100% (100/100) 100% | Water temperature 115°<br>Immediate | Controlled to 75%            | Control stop     |                                                                                                                 |
| P0220    | Sensor systems and their element diagnosis | 15             | Atmospheric pressure sensor failure (LH)                 | ○          |                                                                         | Immediate                           | Controlled to 75%            | Control stop     |                                                                                                                 |
| P0278    | Sensor systems and their element diagnosis | 67             | Atmospheric pressure sensor failure (RH)                 | ○          |                                                                         | Immediate                           | Controlled to 75%            | Control stop     |                                                                                                                 |
| P0190    | Sensor systems and their element diagnosis | 67             | Common rail pressure sensor failure (LH)                 | ○          | < 0.70 V                                                                | After 10-OFF                        | Controlled to 75%            | Control stop     |                                                                                                                 |
| P1101    | Sensor systems and their element diagnosis | 67             | Common rail pressure sensor failure (RH)                 | ○          | > 4.70 V                                                                | After 10-OFF                        | Controlled to 75%            | Control stop     |                                                                                                                 |
| P0191    | Sensor systems and their element diagnosis | 67             | Common rail pressure sensor failure                      | ○          |                                                                         | After 10-OFF                        | Controlled to 75%            | Control stop     |                                                                                                                 |
| P0207    | Sensor systems and their element diagnosis | 37             | Throttle pressure sensor failure (LH)                    | ○          | < 0.20 V                                                                | After 15-ON                         | Controlled to 75%            | Control stop     |                                                                                                                 |
| P0109    | Sensor systems and their element diagnosis | 37             | Throttle pressure sensor failure (RH)                    | ○          | > 4.80 V                                                                | After 15-ON                         | Controlled to 75%            | Control stop     |                                                                                                                 |
| P0117    | Sensor systems and their element diagnosis | 7              | Water temperature sensor failure (LH)                    | ○          | < 0.05 V                                                                | Immediate                           | Controlled to 75%            | Control stop     |                                                                                                                 |
| P0118    | Sensor systems and their element diagnosis | 7              | Water temperature sensor failure (RH)                    | ○          | > 4.80 V                                                                | Immediate                           | Controlled to 75%            | Control stop     |                                                                                                                 |
| P0162    | Sensor systems and their element diagnosis | 4              | Fuel temperature sensor failure (LH)                     | ○          | < 0.15 V                                                                | Immediate                           | No limitation                | Control stop     |                                                                                                                 |
| P0183    | Sensor systems and their element diagnosis | 4              | Fuel temperature sensor failure (RH)                     | ○          | > 4.65 V                                                                | Immediate                           | No limitation                | Control stop     |                                                                                                                 |
| P0122    | Accelerator sensor system                  |                | Both accelerator sensor failure                          | ○          | After 1 and 2 sensors reference                                         | After 15-OFF                        | No limitation                | Control stop     |                                                                                                                 |
| P0123    | Accelerator sensor system                  |                | Accelerator sensor failure (LH)                          | ○          | < 0.90 V                                                                | After 15-OFF                        | No limitation                | Control stop     |                                                                                                                 |
| P0124    | Accelerator sensor system                  |                | Accelerator sensor failure (RH)                          | ○          | > 4.65 V                                                                | After 15-ON                         | No limitation                | Control stop     |                                                                                                                 |
| P0127    | Accelerator sensor system                  |                | Accelerator sensor failure (LH)                          | ○          | < 0.90 V                                                                | After 15-ON                         | No limitation                | Control stop     |                                                                                                                 |
| P0128    | Accelerator sensor system                  |                | Accelerator sensor failure (RH)                          | ○          | > 4.65 V                                                                | After 15-OFF                        | No limitation                | Control stop     |                                                                                                                 |
| P0129    | Accelerator sensor system                  |                | Accelerator sensor failure                               | ○          |                                                                         | Immediate                           | No limitation                | Control stop     |                                                                                                                 |
| P0130    | Accelerator sensor system                  |                | Accelerator sensor failure                               | ○          |                                                                         | After 15-OFF                        | No limitation                | Control stop     |                                                                                                                 |
| P0005    | Pressure sensor system                     |                | High pressure sensor failure, both intake/exhaust valves | ○          |                                                                         | Immediate                           | Controlled to 3%             | Control stop     | Backup function in exhaust valve fault sensor malfunction                                                       |
| P0006    | Pressure sensor system                     |                | High pressure sensor failure                             | ○          |                                                                         | Immediate                           | No limitation                | Control stop     |                                                                                                                 |
| P0007    | Pressure sensor system                     |                | Sub intake sensor failure                                | ○          |                                                                         | Immediate                           | No limitation                | Control stop     |                                                                                                                 |
| P0011    | Pressure sensor system                     |                | Sub exhaust sensor failure                               | ○          |                                                                         | Immediate                           | No limitation                | Control stop     |                                                                                                                 |
| P1206    | Supply pump system                         |                | Supply pump pressure sensor failure                      | ○          |                                                                         | After 10-OFF                        | Controlled to 3%             | Control stop     | Output limit 0%<br>Cylinders occlude<br>conductor which reduces pressure to the 2P injector and large injection |
| P1226    | Supply pump system                         |                | Supply pump pressure sensor failure                      | ○          |                                                                         | Immediate                           | Controlled to 3%             | Control stop     |                                                                                                                 |
| P0046    | Supply pump system                         |                | Common rail pressure high pressure (2-3 stage)           | ○          |                                                                         | After 10-OFF                        | Controlled to 75%            | Control stop     |                                                                                                                 |
| P0039    | Supply pump system                         |                | Common rail pressure high pressure (1-2 stage)           | ○          |                                                                         | After 15-OFF                        | Controlled to 75%            | Control stop     |                                                                                                                 |
| P0038    | Supply pump system                         |                | Supply pump solenoid valve failure                       | ○          |                                                                         | After 10-OFF                        | Controlled to 50%            | Control stop     |                                                                                                                 |
| P0036    | Supply pump system                         |                | Supply pump solenoid valve failure                       | ○          |                                                                         | After 15-ON                         | Controlled to 50%            | Control stop     |                                                                                                                 |
| F0034    | Supply pump system                         |                | Supply pump solenoid valve failure                       | ○          |                                                                         | After 15-OFF                        | Controlled to 75%            | Control stop     |                                                                                                                 |
| F0035    | Supply pump system                         |                | Supply pump solenoid valve failure                       | ○          |                                                                         | After 15-ON                         | Controlled to 75%            | Control stop     |                                                                                                                 |

| SME code | System           | Diagnostic code | Function                                      | Checking on | Failure criteria | Parovasy timing | Injection amount restriction | Action at engine | Remarks                                                                                   |
|----------|------------------|-----------------|-----------------------------------------------|-------------|------------------|-----------------|------------------------------|------------------|-------------------------------------------------------------------------------------------|
| P1211    | Injection system | 57              | Injector common 1 failure (24V short circuit) | ○           |                  | After IC-OFF    | No limitation                | Do not stop      |                                                                                           |
| P1214    |                  | 58              | Injector common 2 failure (24V short circuit) | ○           |                  | After IC-OFF    | No limitation                | Do not stop      |                                                                                           |
| P1212    |                  | 59              | Injector common 3 failure (24V short circuit) | ○           |                  | Immediate       | No limitation                | Do not stop      |                                                                                           |
| P1213    |                  | 58              | Injector common 2 failure (24V short circuit) | ○           |                  | Immediate       | No limitation                | Do not stop      |                                                                                           |
| P-212    |                  | 57              | Injector common 1 failure (24V short)         | ○           |                  | Immediate       | No limitation                | Do not stop      |                                                                                           |
| P-215    |                  | 58              | Injector common 2 failure (24V short)         | ○           |                  | Immediate       | No limitation                | Do not stop      |                                                                                           |
| P1201    | Injection system | 51              | Injector 1 disconnection                      | ○           |                  | After IC-OFF    | No limitation                | Do not stop      | Occurs EMTs<br>if<br>Cylinder stops by<br>blowout with<br>one of the doors<br>not inject. |
| P1202    |                  | 52              | Injector 2 disconnection                      | ○           |                  | After IC-OFF    | No limitation                | Do not stop      |                                                                                           |
| P1203    |                  | 53              | Injector 3 disconnection                      | ○           |                  | After IC-OFF    | No limitation                | Do not stop      |                                                                                           |
| P1204    |                  | 54              | Injector 4 disconnection                      | ○           |                  | After IC-OFF    | No limitation                | Do not stop      |                                                                                           |
| P1205    |                  | 55              | Injector 5 disconnection                      | ○           |                  | After IC-OFF    | No limitation                | Do not stop      |                                                                                           |
| P1206    |                  | 56              | Injector 6 disconnection                      | ○           |                  | After IC-OFF    | No limitation                | Do not stop      |                                                                                           |
| P1203    | Injection system | 07              | Connection error #1 between cylinders         | -           |                  | After IC-OFF    | No limitation                | Do not stop      |                                                                                           |
| P1204    |                  | 08              | Connection error #2 between cylinders         | -           |                  | After IC-OFF    | No limitation                | Do not stop      |                                                                                           |
| P1205    |                  | 09              | Connection error #3 between cylinders         | -           |                  | After IC-OFF    | No limitation                | Do not stop      |                                                                                           |
| P1206    |                  | 0A              | Connection error #4 between cylinders         | -           |                  | After IC-OFF    | No limitation                | Do not stop      |                                                                                           |
| P1207    |                  | 0B              | Connection error #5 between cylinders         | -           |                  | After IC-OFF    | No limitation                | Do not stop      |                                                                                           |
| P1208    |                  | 0C              | Connection error #6 between cylinders         | -           |                  | After IC-OFF    | No limitation                | Do not stop      |                                                                                           |
| P1204    | Injection system | 95              | Turbo-boost sensor                            | ○           |                  | Immediate       | Controlled to 57%            | Do not stop      |                                                                                           |
| P1511    |                  | 50              | LCU change circuit connection                 | ○           |                  | After IC-OFF    | Controlled to 56%            | Do not stop      |                                                                                           |
| P1500    |                  |                 | ECU change circuit connection                 | ○           |                  | After IC-OFF    | Controlled to 56%            | Do not stop      |                                                                                           |
| P1505    |                  |                 | Flash ROM connection                          | ○           |                  | Immediate       | Controlled to 75%            | Do not stop      |                                                                                           |
| P1506    |                  | 3               | ECU failure (y hardware connection)           | ○           |                  | Immediate       | Forced shut down             | Stop             |                                                                                           |
| P1507    |                  |                 | IC abnormality for monitoring the CPU         | ○           |                  | Immediate       | Controlled to 75%            | Do not stop      |                                                                                           |
| P-301    | Vehicle system   | 2               | DR card failure                               | ○           |                  | Immediate       | No limitation                | Do not stop      |                                                                                           |
| P1502    |                  | 25              | Pre-heating unit failure                      | ○           |                  | Immediate       | No limitation                | Do not stop      |                                                                                           |
| P1505    |                  | 5               | Main relay failure                            | ○           |                  | Immediate       | No limitation                | Do not stop      |                                                                                           |
| P1219    |                  | 7               | Engine monitoring                             | ○           | At 100% rating   | Immediate       | No limitation                | Do not stop      |                                                                                           |
| P1517    |                  | 45              | Stator switch failure                         | ○           |                  | Immediate       | No limitation                | Do not stop      |                                                                                           |

| SAE code | System         | Diagnosis code | Function               | Check in trip | Failure criteria | Recovery timing | Position without resistor | Action to engine | EGH format | Remarks |
|----------|----------------|----------------|------------------------|---------------|------------------|-----------------|---------------------------|------------------|------------|---------|
| P2540    | Veh ds system  | 26             | Purifier pump failure  | ○             |                  | Immed fire      | No limitation             | Do not stop      | Continue   |         |
| P2626    | Veh ds system  | 5              | Wdr relay failure      | ○             |                  | Immed fire      | No limitation             | Do not stop      | Continue   |         |
| P2019    | Veh ds system  | 7              | Engine over-boost      | ○             | At 30% rating    | Immed fire      | No limitation             | Do not stop      | Continue   |         |
| P2017    | Vehicle system | 45             | Starter switch failure | ○             |                  | Instant fire    | No limitation             | Do not stop      | Continue   |         |

**\* How to output the diagnosis codes**

1. SAE code : The code is output when the failure is checked by the failure diagnosis. Failure code is displayed for present and past cases. Past failures can be deleted only with the failure diagnosis tool.
2. Diagnosis code : Binking times of the engine check lamp is checked. Only the present error is displayed. (Past failures cannot be viewed.)

**Nota.**

When the diagnosis switch is turned OFF (User mode) to check the lighting status of the engine check lamp, the check lamp lights on when the "diagnosis output" failure as mentioned above lock clear. When the diagnosis switch is turned ON the 2-digit code is displayed by the check lamp's binking condition. In this case, if no error is generated, the lamp binks continuously to show that the status is normal.




## (3) Indication of diagnosis codes

(A) For example, the following chart shows the case when the diagnosis codes 32 and 21 are displayed. The display method is based on the blinking intervals of the lamp. First, the first code makes the lamp light on the figure "3" at the 10's place for 0.5 seconds 3 times and lights on 2 times after 1.5 seconds. Next code display makes the lamp light on 2 + 1 times having 4.3 seconds intervals in the same way as the first code, and afterward this sequence will be repeated.

(B) Usually, the lamp does not light on or blink when the system has no abnormality. At this time, if the diagnosis indication connector is connected, the lamp repeats blinking with 0.3 seconds of light-on duration.

**[Example] Display of diagnosis codes**

example 1) When codes 32 and 21 are displayed



example 2) Normality displayed




### 10.5.3 CHECKING BLOWN-OFF DIAGNOSIS LAMPS

The diagnosis lamp is lit up when all the conditions shown below are satisfied.

[Requirements for checking blown-off diagnosis lamps]

- Engine speed : 0 (min)
- Starter switch : ON
- Diagnosis indication connector (CN-446) : Open
- There should be no fault causing either of the diagnosis lamps to be lit up.

10.5.4 ENGINE ECU



10. ELECTRIC SYSTEM

ECU TERMINAL NUMBER

(A)

|    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  |    |    |    |
| 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
| 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |
| 28 | 29 |    |    |    | 30 | 31 | 32 | 33 | 34 |

(B)

|    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  |    | 6  | 7  |    |    |    |    |
| 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 |
| 20 | 21 |    |    | 22 | 23 |    |    | 24 | 25 | 26 | 27 |
| 28 | 29 |    |    | 30 | 31 |    |    | 32 | 33 | 34 | 35 |

(C)

|    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  |    |    |    |
| 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
| 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |
| 28 | 29 |    |    | 30 |    |    |    | 31 | 32 |

(D)

|    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  |    |    | 3  | 4  | 5  | 6  |    |    |    |
| 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 |    |
| 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |
| 28 | 29 | 30 | 31 | 32 |    |    |    | 33 | 34 | 35 |

(E)

|    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  |    |    |    |
| 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
| 18 | 19 |    |    | 20 | 21 | 22 | 23 | 24 | 25 |
| 26 | 27 |    |    | 28 | 29 |    |    | 30 | 31 |

INPUT AND OUTPUT TABLE

| Terminal<br>n. order : 200 | Component A        |             | Component B        |             | Component C        |             | Component D        |             | Component E        |             |        |
|----------------------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------|
|                            | Terminal<br>number | Description | Terminal<br>number | Description | Terminal<br>number | Description | Terminal<br>number | Description | Terminal<br>number | Description |        |
| 1                          | -                  | +S12        | 1                  | +S12        | 1                  | HRT 1       | 1                  | PGD         | 1                  | 1h.04       | 10h.04 |
| 2                          | -                  | -           | 2                  | -           | 2                  | HRT 2       | 2                  | 1h.01       | 2                  | 1h.05       | 10h.05 |
| 3                          | -                  | -           | 3                  | -           | 3                  | CCD1        | 3                  | 1h.02       | 3                  | 1h.05       | 10h.05 |
| 4                          | -                  | -           | 4                  | -           | 4                  | 1h.02       | 4                  | 1h.01       | 4                  | 1h.02       | 10h.02 |
| 5                          | +B                 | NE5C        | 5                  | NE5C        | 5                  | WRL         | 5                  | 1h.03       | 5                  | 1h.03       | 10h.03 |
| 6                          | +B                 | NE7         | 6                  | NE7         | 6                  | MAL2        | 6                  | 1h.05       | 6                  | 1h.05       | 10h.05 |
| 7                          | +B                 | NE1         | 7                  | NE1         | 7                  | +BT1        | 7                  | -           | 7                  | 1h.05       | 10h.05 |
| 8                          | -                  | -           | 8                  | -           | 8                  | -           | -                  | -           | 8                  | -           | -      |
| 9                          | -                  | -           | 9                  | -           | 9                  | -           | -                  | -           | 9                  | -           | -      |
| 10                         | -                  | -           | 10                 | -           | 10                 | -           | -                  | -           | 10                 | -           | -      |
| 11                         | -                  | -           | 11                 | -           | 11                 | -           | -                  | -           | 11                 | -           | -      |
| 12                         | -                  | -           | 12                 | -           | 12                 | -           | -                  | -           | 12                 | -           | -      |
| 13                         | -                  | -           | 13                 | -           | 13                 | 1h.05       | 13                 | -           | 13                 | -           | -      |
| 14                         | -                  | -           | 14                 | -           | 14                 | ST          | 14                 | -           | 14                 | 1h.02       | 10h.02 |
| 15                         | -                  | -           | 15                 | -           | 15                 | -           | -                  | -           | 15                 | 1h.02       | 10h.02 |
| 16                         | -                  | -           | 16                 | -           | 16                 | STIP        | 16                 | -           | 16                 | 1h.02       | 10h.02 |
| 17                         | -                  | -           | 17                 | -           | 17                 | -           | -                  | -           | 17                 | 1h.02       | 10h.02 |
| 18                         | -                  | -           | 18                 | -           | 18                 | -           | -                  | -           | 18                 | -           | -      |
| 19                         | 100V               | 100V-1      | 19                 | -           | 19                 | -           | -                  | 19          | 1h.01              | 1h.01       | 10h.01 |
| 20                         | -                  | -           | 20                 | ACD1        | 20                 | ACD1        | 20                 | 1h.01       | 20                 | 1h.01       | 10h.01 |
| 21                         | ACS1               | ACS1        | 21                 | MODE        | 21                 | MODE        | 21                 | -           | 21                 | -           | -      |
| 22                         | ACS2               | ACS2        | 22                 | SWSS        | 22                 | SWSS        | 22                 | -           | 22                 | -           | -      |
| 23                         | ACS3               | ACS3        | 23                 | ACD2        | 23                 | ACD2        | 23                 | -           | 23                 | -           | -      |
| 24                         | -                  | -           | 24                 | -           | 24                 | -           | -                  | 24          | 1h.01              | 1h.01       | 10h.01 |
| 25                         | -                  | -           | 25                 | -           | 25                 | -           | -                  | 25          | 1h.01              | 1h.01       | 10h.01 |
| 26                         | -                  | -           | 26                 | -           | 26                 | -           | -                  | 26          | 1h.01              | 1h.01       | 10h.01 |
| 27                         | -                  | -           | 27                 | -           | 27                 | -           | -                  | 27          | 1h.01              | 1h.01       | 10h.01 |
| 28                         | -                  | -           | 28                 | -           | 28                 | -           | -                  | 28          | 1h.01              | 1h.01       | 10h.01 |
| 29                         | -                  | -           | 29                 | -           | 29                 | -           | -                  | 29          | 1h.01              | 1h.01       | 10h.01 |
| 30                         | -                  | -           | 30                 | -           | 30                 | -           | -                  | 30          | 1h.01              | 1h.01       | 10h.01 |
| 31                         | -                  | -           | 31                 | -           | 31                 | -           | -                  | 31          | 1h.01              | 1h.01       | 10h.01 |
| 32                         | -                  | -           | 32                 | 1h.01       | 32                 | 1h.01       | 32                 | 1h.01       | 32                 | 1h.01       | 10h.01 |
| 33                         | -                  | -           | 33                 | -           | 33                 | -           | -                  | 33          | 1h.01              | 1h.01       | 10h.01 |
| 34                         | -                  | -           | 34                 | 1h.01       | 34                 | 1h.01       | 34                 | 1h.01       | 34                 | 1h.01       | 10h.01 |
| 35                         | -                  | -           | 35                 | -           | 35                 | -           | -                  | 35          | 1h.01              | 1h.01       | 10h.01 |



---


## **11. LOAD SAFETY DEVICE**





## 11.1 PART NAMES AND FUNCTIONS

### 11.1.1 FRONT VIEW



#### Note


- All numeric values and units in the display in this manual are just examples.
- Units on the display can be changed.  
For details of change procedures, refer to "11.5.7 CHOICE OF LANGUAGE (CKE SERIES ONLY)".

## 11. LOAD SAFETY DEVICE


### 1. DISPLAY

Current status of the crane is displayed

(CKE series)



(CK Series)



### 2. BUZZER (beep--)

Warning buzzers mainly related to overload (including load limit warning) are issued. When the moment ratio is 90% or more, intermittent buzzers are issued, and continuous buzzers are issued when it is 100%.

Intervals of intermittent buzzers are divided into three types. As the moment ratio is greater, the intervals of buzzers become shorter.



| Buzzer types | Buzzers                 |
|--------------|-------------------------|
| Intermittent | beep, beep, beep, ..... |
| Continuous   | beep-----               |

### 3. SPEAKER (peep,peep,peep--)

Overhoist and working area limit warning buzzers are issued. When the boom exceeds the working area limit prenotice point, intermittent buzzers are issued.

When the boom reaches the working area limit stop point or the hook blocks or boom is overhoisted, continuous buzzers are issued. Intervals of intermittent buzzers are divided into three types. As the boom is closer to the stop point, the intervals of buzzers become shorter.



| Buzzer types | Buzzers                 |
|--------------|-------------------------|
| Intermittent | peep, peep, peep, ..... |
| Continuous   | peep-----               |

**Note**

## 1. Buzzers warning overhoist

Buzzers warning boom overhoist are issued when the limit switch is actuated. Buzzers warning hook overhoist are issued when the limit switch is actuated to stop the hook blocks, and the winch lever is set to the "WINCH" position or the boom lever is set to the "LOWER" position.

(No warning buzzer is issued while the levers are set to the "NEUTRAL" positions.)


## 2. Buzzers warning working area limit









Unless the prenotice point is set, warning buzzers are issued when the boom reaches the position 5 degree before or 1 feet or 1 m before the stop point.

---

## 11. LOAD SAFETY DEVICE


### 4. SHEET SWITCH



|                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                              |
|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | <p>Use this switch to change the display colors or decrease figures.</p> <ul style="list-style-type: none"><li>* To change the colors, depress and hold this switch for three seconds or longer.</li></ul>                                                                                                                                                                                   |
|    | <p>Use this switch to alternate between the MAIN and AUX. modes or increase figures.</p> <ul style="list-style-type: none"><li>* To change the current mode, depress and hold this switch for three seconds or longer.</li></ul>                                                                                                                                                             |
|    | <p>Use this switch to display the screen (to darken) or select any intended item.</p> <ul style="list-style-type: none"><li>* To adjust the contrast, depress and hold this switch for three seconds or longer. Then, the brightness of the screen is changed a little every three seconds. To change the brightness extremely, depress and hold it for several tens of seconds.</li></ul>   |
|   | <p>Use this switch to display the screen (to brighten) or select any intended item.</p> <ul style="list-style-type: none"><li>* To adjust the contrast, depress and hold this switch for three seconds or longer. Then, the brightness of the screen is changed a little every three seconds. To change the brightness extremely, depress and hold it for several tens of seconds.</li></ul> |
|  | <p>Use this switch to display or cancel the list of selected items.</p>                                                                                                                                                                                                                                                                                                                      |
|  | <p>Use this switch to decide or execute the selected item.</p>                                                                                                                                                                                                                                                                                                                               |
|  | <p>Use this switch to alternate between the assembly/disassembly or operation modes.</p> <ul style="list-style-type: none"><li>* To change the current mode, depress and hold this switch for three seconds or longer.</li></ul>                                                                                                                                                             |
|  | <p>Use this switch when it is necessary to lower the boom onto the ground at out of angle position (lower limit angle/no rated load) without a load.</p> <ul style="list-style-type: none"><li>* Depress and hold this switch for three seconds or longer for cancellation.</li></ul>                                                                                                        |

## 5. COVER

DO NOT open unless you need to load the memory card or operate the setting and adjusting switches



## 6. MEMORY CARD SLOT


Insert the data memory card here.



## 7. MEMORY CARD

This card contains the data related to the crane capacity


Insert this card into the data card slot unless otherwise specified



## 8. SETTING AND ADJUSTING SWITCHES

These switches are used for upgrading of programs or adjustment on y

DO NOT touch them unless otherwise absolutely necessary.



The dip switches are used to make adjustments. The following chart explains the dip switch functions.

Dip switches








| Dip switches No. |    |    |    |    |    |    |   | Function                                   |
|------------------|----|----|----|----|----|----|---|--------------------------------------------|
| 1                | 2  | 3  | 4  | 5  | 6  | 7  | 8 |                                            |
| ON               | -  | -  | -  | -  | -  | -  | - | Permission of upgrading indication program |
| -                | ON | -  | -  | -  | -  | -  | - | Permission of upgrading control program    |
| -                | -  | ON | -  | -  | -  | -  | - | Permission of writing adjustment value     |
| -                | -  | -  | ON | -  | -  | -  | - | Display of maintenance screen              |
| -                | -  | -  | -  | ON | -  | -  | - | Making LVL function available              |
| -                | -  | -  | -  | -  | -  | ON | - | None                                       |
| -                | -  | -  | -  | -  | ON | -  | - | Initialization of load and trouble records |



[ Procedures and conditions required for change of screens:]








1. When the conditions required for the setup mode are satisfied, press and hold the setup switch for three seconds or longer.

**Note**

1. The boom angle is 15 deg. or less (in the crane mode)
  2. The boom angle is 30 deg. or less (in the lifting crane mode)
  3. The boom angle detector is not connected, and the guy line tension is less than regulation value (about 5 t (11,023 lbs)).
  4. Neither the boom angle detector nor load detector is connected.
- 
2. Press and hold the setup switch for three seconds or longer, or shut down the power supply. Or, fail to satisfy any of the conditions required for the setup mode.
  3. When the  switch is pressed, the items are displayed. When any of them is selected with the  switch, screens in the lower category appear.  
When the  switch is pressed again, those in the upper category appear.
  4. When any of the items is selected with the  switch, screens in the lower category appear, and those in the upper category appear when the  switch is pressed.
  5. When the dip switch No.3 is turned on, they are displayed.
  6. When the dip switch No.1 is turned on, they are displayed.
  7. When the dip switch No.2 is turned on, they are displayed.
  8. When the dip switch No.4 is turned on, they are displayed.
  9. Press the  and  switches at a time, and hold them for three seconds or longer.
  10. In the status (9) above, release the switches.


## 11. LOAD SAFETY DEVICE

---

11. When the  switch is pressed, the next screen appears.
12. When the  mark on the screen is selected and the  switch is pressed, the next screen appears.
13. Only while the  switch is pressed and held, the next screen appears.
14. When the  switch is released, the next screen appears.
15. When the  mark on the screen is selected and the  switch is pressed, the next screen appears.
16. When the setting is completed, the next screen appears.










[CK series]



## 11. LOAD SAFETY DEVICE

---

[Procedures and conditions required for change of screens]


1. When the conditions required for the setup mode are satisfied, press and hold the setup switch for three seconds or longer.
2. Press and hold the setup switch for three seconds or longer or shut down the power supply. Or, fail to satisfy any of the conditions required for the setup mode.
3. When the  switch is pressed, the items are displayed. When any of them is selected with the  switch, screens in the lower category appear.  
When the  switch is pressed again, those in the upper category appear.
4. When any of the items is selected with the  switch, screens in the lower category appear, and those in the upper category appear when the  switch is pressed.
5. When the dip switch No.3 is turned on, they are displayed.
6. When the dip switch No.1 is turned on, they are displayed.
7. When the dip switch No.2 is turned on, they are displayed.
8. When the dip switch No.4 is turned on, they are displayed.
9. Press the  and  switches at a time, and hold them for three seconds or longer.
10. In the status (9) above, release the switches.

---

### Note

1. The boom angle is 15 deg. or less (in the crane mode)
  2. The boom angle is 30 deg. or less (in the luffing crane mode)
  3. The boom angle detector is not connected, and the guy line tension is less than regulation value (about 4.5 t (10,000 lbs)).
  4. Neither the boom angle detector nor load detector is connected.
-

## 11.1.3 DATA TRANSMISSION BETWEEN CONTROLLER AND CARDS



The data card is loaded in the load safety device normally, and data are transmitted as shown below.

## 1. Copying crane data

Crane data for the installed attachment are copied into the flash memory from the data card by carrying out the "crane configuration setup" after the attachment is changed.

(After that, removal of the card will not give any influence on the motion of the machine, since data copied in the flash memory are used for operation.)

## 2. Copying adjustment value (automatic backup)

Whenever adjustment is carried out, adjustment values are stored into the flash memory, and used for operation. However, if the controller is malfunctioned and is replaced with a new one, the conventional adjustment values become unavailable.

Since the flash memory is fixed on the PCB by soldering. Thus, whenever adjustment is performed, data are automatically copied into the data card. If the data card is not loaded, no data is copied, and no display warning it will be provided.


## 11. LOAD SAFETY DEVICE

---

3. Copying adjustment value and history data  
Adjustment values copied during adjustment shown in the step (2) above can be written into the controller by executing out the command. Conventional adjustment values can be used by transferring the copy data that are stored in the data card used into the controller. Arbitrary copying of adjustment values of the controller into the data card and return of adjustment values in the controller to the initial statuses are also available (refer to 11.6.5 VERSION CHECK)
4. Upgrading program for display  
Program for display can be upgraded by turning on the dip switch No.1 and executing the command.
5. Upgrading program for control  
Program for control can be upgraded by turning on the dip switch No.2 and executing the command.








11.1.4 DETAILS OF INDICATORS ON MAIN DISPLAY SCREEN

(IN CASE OF CK series)




| No | Indicator                                  | Details                                                                                                                                                                                                                                                                                                                                                                              |
|----|--------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1  | Moment ratio indicator (bar indicator)     | Moment ratio is indicated from 60 to 126% by the 2%<br>When moment ratio is less than 90%, it is indicated in green color.<br>When it is 90% or more and less than 100%, it is indicated in yellow<br>When it is 100% or more, it is indicated in red.                                                                                                                               |
| 2  | Mode indicator                             | After the  switch is pressed and the 'MAIN' or the 'AUX' mode is selected, the selected mode is indicated.                                                                                                                                                                                                                                                                           |
| 3  | Boom angle indicator                       | Current boom angle is indicated<br>When it is in the range from 0 to 99.9 to 99.9 deg., it is indicated by the 0.1 deg.<br>When it is in the range from -150 to -10 deg., it is indicated by the 1 deg                                                                                                                                                                               |
| 4  | Point height indicator                     | Boom point elevation or jib point elevation is indicated.<br>When it is in the range from -9.9 to 99.9 m, it is indicated by the 0.1 feet<br>When it is in the range from 100 to 999 feet or in the range from -99 to 10 m, it is indicated by the 1.0 feet<br>You can choose whether this item should be displayed or not (Refer to "3.5.1 SETTING SCREEN" of the operation manual) |
| 5  | Moment ratio indicator (digital indicator) | Moment ratio is indicated from 0 to 200% by the 1 %                                                                                                                                                                                                                                                                                                                                  |







## 11. LOAD SAFETY DEVICE

| No. | Indicator                                                                                                                | Details                                                                                                                                                                                                                                                                                                                                             |
|-----|--------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 6   | <p>Actual load indicator</p>            | <p>Actual load is indicated. When it is out of the working area, "—" is indicated.</p> <p>When it is 0 pounds X 1000, "0.0" is indicated.</p> <p>When it is in the range from 0 to 100 pounds X 1000, it is indicated in 0.1 pounds X 1000.</p> <p>When it is in the range from 100 to 999 pounds X 1000, it is indicated in 1.0 pounds X 1000.</p> |
| 7   | <p>Rated load indicator</p>             | <p>Rated load is indicated.</p> <p>When it is out of the working area, "0.0" is indicated.</p> <p>When it is in the range from 0 to 100 pounds X 1000, it is indicated in 0.1 pounds X 1000.</p> <p>When it is in the range from 100 to 999 pounds X 1000, it is indicated in 1.0 pounds X 1000.</p>                                                |
| 8   | <p>Working radius indicator</p>         | <p>Working radius is indicated.</p> <p>When it is in the range from 0 to 100 feet, it is indicated in 0.1 feet.</p> <p>When it is in the range from 100 to 999 feet, it is indicated in 1.0 feet.</p>                                                                                                                                               |
| 9   | <p>Message indicator</p>               | <p>Messages for hazardous or faulty statuses are indicated.</p> <p>For the types and details of the messages, refer to "3.11 INDICATION OF MESSAGE AND ALARM" of the operation manual.</p>                                                                                                                                                          |
| 10  | <p>Crane configuration indicator</p>  | <p>The detailed settings of the crane configuration are displayed.</p> <p>For the settings, refer to "3.6.2 SETTING OF THE CRANE CONFIGURATION" of the operation manual.</p>                                                                                                                                                                        |
| 11  | <p>Jib angle indicator</p>            | <p>Luffing jib angle is indicated.</p> <p>When it is in the range from -9.9 to 99 deg., it is indicated by the 0.1 deg.</p> <p>When it is in the range from -150 to -10 deg., it is indicated by the 1.0 deg.</p>                                                                                                                                   |
| 12  | <p>Jib offset angle indicator</p>     | <p>Jib offset angle is indicated.</p> <p>When it is in the range from -9.9 to 99 deg., it is indicated by the 0.1 deg.</p> <p>When it is in the range from -99 to -10 deg., it is indicated by the 1.0 deg.</p> <p>* This indicator cannot be displayed together with the point height indicator at a time.</p>                                     |









(IN CASE OF CKE series)



\* The indicating unit's depend on the choice done in the steps described in "11.5.7 CHOICE OF LANGUAGE (CKE SERIES ONLY)".

| No. | Indicator                                                                                                                             | Details                                                                                                                                                                                                                                                                     |
|-----|---------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | <p>Moment ratio indicator<br/>(bar indicator)</p>  | <p>Moment ratio is indicated from 60 to 126% by the 2%.</p> <p>When moment ratio is less than 90%, it is indicated in green color.</p> <p>When it is 90% or more and less than 100%, it is indicated in yellow.</p> <p>When it is 100% or more, it is indicated in red.</p> |
| 2   | <p>Mode indicator</p>                              | <p>When the  switch is pressed, the mode changes. The actual load and rated load of the hook at the selected side are displayed.</p>                                                     |
| 3   | <p>Boom angle indicator</p>                        | <p>Current boom angle is indicated.</p> <p>When it is in the range from 0 to 9.9 to 99.9 deg., it is indicated by the 0.1 deg.</p> <p>When it is in the range from -150 to -10 deg., it is indicated by the 1 deg.</p>                                                      |
| 4   | <p>Point height indicator</p>                      | <p>Boom point elevation or jib point elevation is indicated.</p> <p>When it is in the range from -9.9 to 99.9 m, it is indicated by the 0.1 m.</p> <p>When it is in the range from 100 to 999 m or in the range from -99 to 10 m, it is indicated by the 1.0 m.</p>         |
| 5   | <p>Boom length indicator</p>                       | <p>The selected boom length is displayed.</p>                                                                                                                                                                                                                               |


## 11. LOAD SAFETY DEVICE

| No. | Indicator                                                                                                             | Details                                                                                                                                                                                                                                                                                                         |
|-----|-----------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 6   | <p>Actual load indicator</p>         | <p>Actual load is indicated. When it is out of the working area, "—" is indicated.</p> <p>When it is 0 t, "0.0" is indicated.</p> <p>When it is in the range from 0 to 100 t, it is indicated in 0.1 t.</p> <p>When it is in the range from 100 to 999 t, it is indicated in 1.0 t.</p>                         |
| 7   | <p>Rated load indicator</p>          | <p>Rated load is indicated.</p> <p>When it is out of the working area, "0.0" is indicated.</p> <p>When it is in the range from 0 to 100 t, it is indicated in 0.1 t.</p> <p>When it is in the range from 100 to 999 t, it is indicated in 1.0 t.</p>                                                            |
| 8   | <p>Working radius indicator</p>      | <p>Working radius is indicated.</p> <p>When it is in the range from 0 to 100 m, it is indicated in 0.1 m.</p> <p>When it is in the range from 100 to 999 m, it is indicated in 1.0 m.</p>                                                                                                                       |
| 9   | <p>Message indicator</p>             | <p>Messages for hazardous or faulty statuses are indicated.</p> <p>For the types and details of the messages, refer to "3.11 INDICATION OF MESSAGE AND ALARM" of the operation manual.</p>                                                                                                                      |
| 10  | <p>Hook, number of part lines</p>  | <p>The selected type and number of part lines of the hook are displayed.</p>                                                                                                                                                                                                                                    |
| 11  | <p>Jib angle indicator</p>         | <p>Luffing jib angle is indicated.</p> <p>When it is in the range from -9.9 to 99 deg., it is indicated by the 0.1 deg.</p> <p>When it is in the range from -150 to -10 deg., it is indicated by the 1.0 deg.</p>                                                                                               |
| 12  | <p>Jib offset angle indicator</p>  | <p>Jib offset angle is indicated.</p> <p>When it is in the range from -9.9 to 99 deg., it is indicated by the 0.1 deg.</p> <p>When it is in the range from -99 to -10 deg., it is indicated by the 1.0 deg.</p> <p>* This indicator cannot be displayed together with the point height indicator at a time.</p> |
| 13  | <p>Jib length</p>                  | <p>The selected jib length is displayed.</p>                                                                                                                                                                                                                                                                    |



### 11.1.5 REAR VIEW

1. Controller installation holes  
Use 0.59 inch (15 mm) screws (M6) for mounting.
2. CN11M : Power input connector
3. CN12AM : Load Detector (1 to 4) input connector  
Load Detector outputs between 1 and 5 volts.
4. CN12BM : Load Detector (5 to 7) input connector
5. CN13M : Angle Detector (1 to 3) input connector
6. CN14M : Angle Detector (4 to 5) input connector
7. CN15M : Digital input connector
8. CN16M : Digital output connector
9. CN17M : Analogue output connector
10. CN18M : Communication connector



## 11. LOAD SAFETY DEVICE

Chart1. System Input/Output, Connector Designations

| Connector No.       | Pin No. | Signals          | Functions                                 |                                                |  |
|---------------------|---------|------------------|-------------------------------------------|------------------------------------------------|--|
| CN11M               | 1       | Power supply     | Power supply (+24 V)                      | Power supply                                   |  |
|                     | 2       |                  | Power supply for output signal (+24 V)    |                                                |  |
|                     | 3       |                  | Grounding                                 |                                                |  |
| CN12AM<br>(18 pins) | 1       | Load detector 1  | Power supply (+10 V)                      | Boom raising<br>Load detector                  |  |
|                     | 2       |                  | Signal (+)                                |                                                |  |
|                     | 3       |                  | Power supply grounding & signal grounding |                                                |  |
|                     | 4       |                  | Shield grounding                          |                                                |  |
|                     | 5       | Load detector 2  | Power supply (+10 V)                      | Spare load detector 1                          |  |
|                     | 6       |                  | Signal (+)                                |                                                |  |
|                     | 7       |                  | Power supply grounding & signal grounding |                                                |  |
|                     | 8       |                  | Shield grounding                          |                                                |  |
|                     | 9       | Load detector 3  | Power supply (+10 V)                      | Spare load detector 2                          |  |
|                     | 10      |                  | Signal (+)                                |                                                |  |
|                     | 11      |                  | Power supply grounding & signal grounding |                                                |  |
|                     | 12      |                  | Shield grounding                          |                                                |  |
|                     | 13      | Load detector 4  | Power supply (+10 V)                      | Lifting jib<br>Load detector<br>(Lifting only) |  |
|                     | 14      |                  | Signal (+)                                |                                                |  |
|                     | 15      |                  | Power supply grounding & signal grounding |                                                |  |
|                     | 16      |                  | Shield grounding                          |                                                |  |
|                     |         | 17               | Unused                                    |                                                |  |
|                     |         | 18               |                                           |                                                |  |
| CN20M<br>(12 pins)  | 1       | Load detector 5  | Power supply (+10 V)                      | Spare load detector 3                          |  |
|                     | 2       |                  | Signal (+)                                |                                                |  |
|                     | 3       |                  | Power supply grounding & signal grounding |                                                |  |
|                     | 4       |                  | Shield grounding                          |                                                |  |
|                     | 5       | Load detector 6  | Power supply (+10 V)                      | Spare load detector 4                          |  |
|                     | 6       |                  | Signal (+)                                |                                                |  |
|                     | 7       |                  | Power supply grounding & signal grounding |                                                |  |
|                     | 8       |                  | Shield grounding                          |                                                |  |
|                     | 9       | Load detector 7  | Power supply (+10 V)                      | Spare load detector 5                          |  |
|                     | 10      |                  | Signal (+)                                |                                                |  |
|                     | 11      |                  | Power supply grounding & signal grounding |                                                |  |
|                     | 12      |                  | Shield grounding                          |                                                |  |
| CN13M               | 1       | Angle detector 1 | Power supply (+10 V)                      | Boom angle detector                            |  |
|                     | 2       |                  | Signal (+)                                |                                                |  |
|                     | 3       |                  | Power supply grounding & signal grounding |                                                |  |
|                     | 4       |                  | Shield grounding                          |                                                |  |
|                     | 5       | Angle detector 2 | Power supply (+10 V)                      | Spare angle detector 1                         |  |
|                     | 6       |                  | Signal (+)                                |                                                |  |
|                     | 7       |                  | Power supply grounding & signal grounding |                                                |  |
|                     | 8       |                  | Shield grounding                          |                                                |  |
|                     | 9       | Angle detector 3 | Power supply (+10 V)                      | Lifting jib angle detector<br>(Lifting only)   |  |
|                     | 10      |                  | Signal (+)                                |                                                |  |
|                     | 11      |                  | Power supply grounding & signal grounding |                                                |  |
|                     | 12      |                  | Shield grounding                          |                                                |  |
|                     |         | 13               | Unused                                    |                                                |  |
|                     |         | 14               |                                           |                                                |  |
| CN14M               | 1       | Angle detector 4 | Power supply (+10 V)                      | Spare angle detector 2                         |  |
|                     | 2       |                  | Signal (+)                                |                                                |  |
|                     | 3       |                  | Power supply grounding & signal grounding |                                                |  |
|                     | 4       |                  | Shield grounding                          |                                                |  |
|                     | 5       | Angle detector 5 | Power supply (+10 V)                      | Spare angle detector 3                         |  |
|                     | 6       |                  | Signal (+)                                |                                                |  |
|                     | 7       |                  | Power supply grounding & signal grounding |                                                |  |
|                     | 8       |                  | Shield grounding                          |                                                |  |

Chart2. System Input/Output, Connector Designations

| Connector No. | Pin No.                         | Signal                          | Functions                                       |
|---------------|---------------------------------|---------------------------------|-------------------------------------------------|
| CN15M         | 1                               | Contact point input             | Main hook overload                              |
|               | 2                               |                                 | Aux. hook overload                              |
|               | 3                               |                                 | Tower hook overload (Not used)                  |
|               | 4                               |                                 | Boom overload (Backstop 1) (Luffing only)       |
|               | 5                               |                                 | Boom overload (Crane)                           |
|               | 6                               |                                 | Boom overload (Backstop 2)                      |
|               | 7                               |                                 | Luffing jib overload (Luffing only)             |
|               | 8                               |                                 | Fixed jib overload (Not used)                   |
|               | 9                               |                                 | Hook overload stop release                      |
|               | 10                              |                                 | Boom and jib stop release                       |
|               | 11                              |                                 | Overhead stop release                           |
|               | 12                              |                                 | Release switch master key                       |
|               | 13                              |                                 | Boom lift (Luffing only)                        |
|               | 14                              |                                 | Gantry link detect (Not used)                   |
|               | 15                              |                                 | Strut overload (Not used)                       |
|               | 16                              |                                 | Strut overloading (Not used)                    |
|               | 17                              |                                 | Counterweight detect 1 (Option)                 |
|               | 18                              |                                 | Counterweight detect 2 (Option)                 |
|               | 19                              |                                 | Spare                                           |
|               | 20                              |                                 | Gantry cylinder detect (Not used)               |
| CN16M         | 1                               | Drum stop output                | Front drum wind up                              |
|               | 2                               |                                 | Rear drum wind up                               |
|               | 3                               |                                 | Rear drum wind down                             |
|               | 4                               |                                 | Boom drum wind up                               |
|               | 5                               |                                 | Boom drum wind down                             |
|               | 6                               |                                 | Self removal mode                               |
|               | 7                               |                                 | Spare                                           |
|               | 8                               |                                 | Third (Jib) drum wind up                        |
|               | 9                               |                                 | Third (Jib) drum wind down                      |
|               | 10                              |                                 | Room ringing deceleration                       |
|               | 11                              | Others                          | Tower jib raising deceleration (Not used)       |
|               | 12                              |                                 | Tower standing mode (Not used)                  |
|               | 13                              |                                 | Luffing mode (Luffing only)                     |
|               | 14                              |                                 | Tower mode (Not used)                           |
|               | 15                              |                                 | Set up mode                                     |
|               | 16                              |                                 | Luffing jib raising deceleration (Luffing only) |
|               | 17                              |                                 | External indication (Green)                     |
|               | 18                              |                                 | External indication (Yellow)                    |
|               | 19                              |                                 | External indication (Red)                       |
|               | 20                              |                                 | CPU fault signal output                         |
| CN17M         | 1                               | Analog output                   | Tension                                         |
|               | 2                               |                                 | Tension (+) (Not used)                          |
|               | 3                               |                                 | Tension (-) (Not used)                          |
|               | 4                               | Boom angle                      |                                                 |
|               | 5                               | Boom angle (+) (Not used)       |                                                 |
|               | 6                               | Boom angle (-) (Not used)       |                                                 |
|               | 7                               | Jib offset angle                |                                                 |
|               | 8                               | Jib offset angle (+) (Not used) |                                                 |
| 9             | Jib offset angle (-) (Not used) |                                 |                                                 |
| 8             | Vocam                           |                                 |                                                 |
| CN18M         | 1                               | RS232C                          | RXD (1)                                         |
|               | 2                               |                                 | TXD (1)                                         |
|               | 3                               |                                 | GND (1)                                         |
|               | 4                               |                                 | RXD (2)                                         |
|               | 5                               |                                 | TXD (2)                                         |
|               | 6                               |                                 | GND (2)                                         |

## 11. LOAD SAFETY DEVICE

Chart3. System Input/Output (Digital Input)

| Signals |                                          | Operations |                                                     |
|---------|------------------------------------------|------------|-----------------------------------------------------|
| 1)      | Main hook overload                       | Grounded   | → Normal                                            |
|         |                                          | Open       | → Hook overloaded (Anti-two block)                  |
| 2)      | Aux. hook overload                       | Grounded   | → Normal                                            |
|         |                                          | Open       | → Hook overloaded (Anti-two block)                  |
| 3)      | Tower hook overload (Not used)           | Grounded   | → Normal                                            |
|         |                                          | Open       | → Hook overloaded (Anti-two block)                  |
| 4)      | Boom overload (Bascula 1) (Luffing only) | Grounded   | → Normal                                            |
|         |                                          | Open       | → Boom overloaded                                   |
| 5)      | Boom overload (Crane)                    | Grounded   | → Normal                                            |
|         |                                          | Open       | → Boom overloaded                                   |
| 6)      | Boom overload (Bascula 2)                | Grounded   | → Normal                                            |
|         |                                          | Open       | → Boom overloaded                                   |
| 7)      | Luffing jib overload (Luffing only)      | Grounded   | → Normal                                            |
|         |                                          | Open       | → Jib overloaded                                    |
| 8)      | Luffing jib overload (Not used)          | Grounded   | → Normal                                            |
|         |                                          | Open       | → Jib overloaded                                    |
| 9)      | Hook overload stop release               | Grounded   | → Release of automatic stop caused by hook overload |
|         |                                          | Open       | → Non-release                                       |
| 10)     | Boom and jib stop release                | Grounded   | → Release of automatic stop caused by boom overload |
|         |                                          | Open       | → Non-release                                       |
| 11)     | Overload stop release                    | Grounded   | → Release of automatic stop caused by overload      |
|         |                                          | Open       | → Non-release                                       |
| 12)     | Release switch master key                | Grounded   | → Release side                                      |
|         |                                          | Open       | → Lock side                                         |
| 13)     | Boom fix (Luffing only)                  | Grounded   | → Fixed                                             |
|         |                                          | Open       | → Released                                          |
| 14)     | Gantry fire link detect (Not used)       | Grounded   | → Gantry fire link is not connected                 |
|         |                                          | Open       | → Gantry fire link is connected                     |
| 15)     | Shot overload (Not used)                 | Grounded   | → Normal                                            |
|         |                                          | Open       | → Shot overloaded                                   |
| 16)     | Shot overloading (Not used)              | Grounded   | → Normal                                            |
|         |                                          | Open       | → Shot overloaded                                   |
| 17)     | Cy interweight detect 1 (Cy 4mm)         | Grounded   | → With weights                                      |
|         |                                          | Open       | → Without weights                                   |
| 18)     | Cy interweight detect 2 (Cy 6mm)         | Grounded   | → With weights                                      |
|         |                                          | Open       | → Without weights                                   |
| 19)     | Spine                                    |            |                                                     |
| 20)     | Gantry cylinder detect (Not used)        | Grounded   | → Cylinder is connected gantry                      |
|         |                                          | Open       | → Cylinder is not connected gantry                  |

Chart4. System Input/Output (Digital Output)

| Signal                                              | Operations                          | Remarks                                                              |
|-----------------------------------------------------|-------------------------------------|----------------------------------------------------------------------|
| 1) Front drum watch up                              |                                     |                                                                      |
| 2) Rear drum watch up                               | Power is turned → Open              |                                                                      |
| 3) Rear drum watch down                             | Safety area → Output                |                                                                      |
| 4) Boom drum watch up                               | Hazardous area → Open               |                                                                      |
| 5) Boom drum watch down                             |                                     |                                                                      |
| 6) ECP removal mode                                 | Safety removal mode → Output        |                                                                      |
| 7) Open                                             | Others → Open                       |                                                                      |
| 8) Third drum watch up                              | Power is turned OFF → Open          |                                                                      |
| 9) Third drum watch down                            | Safety area → Output                |                                                                      |
| 10) Boom luffing deceleration                       | Hazardous area → Open               | Contact capacity<br>2.5 A/30 VDC<br>(Allowable inrush current: 5 A)  |
| 11) Tower jib missing deceleration (Not used)       | Deceleration area → Output          |                                                                      |
| 12) Tower self-standing mode (Not used)             | Other area → Open                   |                                                                      |
|                                                     | Tower missing posture → Output      |                                                                      |
|                                                     | Others → Open                       |                                                                      |
| 13) Luffing mode (Luffing only)                     | Luffing attachment → Output         |                                                                      |
|                                                     | Others → Open                       |                                                                      |
| 14) Tower mode (Not used)                           | Tower attachment → Output           |                                                                      |
|                                                     | Others → Open                       |                                                                      |
| 15) Set up mode                                     | Set up mode → Output                |                                                                      |
|                                                     | Other → Open                        |                                                                      |
| 16) Luffing jib missing deceleration (Luffing only) | Deceleration area → Output          |                                                                      |
|                                                     | Area → Open                         |                                                                      |
| 17) External indication (green) less than 90%       | Power is turned OFF → Open          | Contact capacity<br>2.5 A/30 VDC<br>(Allowable inrush current: 10 A) |
| 18) External indication (yellow) 90% or more        | Conditions are not satisfied → Open |                                                                      |
| 19) External indication (red) 100% or more          | Conditions are satisfied → Output   |                                                                      |
| 20) CPU fault                                       | CPU is normal → Output              | As per remarks of 1) to 16)                                          |
|                                                     | CPU is faulty → Open                |                                                                      |

Chart5. Output Spares

| Signal                             | Operations             | Remarks                                 |
|------------------------------------|------------------------|-----------------------------------------|
| Guy line tension (Not used)        | 0 to MAX/0 to 5V       |                                         |
| Boom angle output (Not used)       | 0 to +90 deg/0 to 5V   | Output resistance is less than<br>100 Ω |
| Jib offset angle output (Not used) | -90 to +90 deg/0 to 5V |                                         |

# 11. LOAD SAFETY DEVICE

## 11.1.6 ITEMS REQUIRED TO BE EXECUTED FOR REPLACEMENT OF CONTROLLER OR DATA CARD AND INSTRUCTIONS

(In a similar manner to upgrade of program)

Items to be executed and pages including detailed explanations

|                                                          | Reprogramming                    | Adjustment (from 11-57 to 11-60)                               |                       |                                        |                    | Working radius | Backup of adjusting data (from controller to card) | Copying or adjusting data (from card to controller) | Re-input of attachment |
|----------------------------------------------------------|----------------------------------|----------------------------------------------------------------|-----------------------|----------------------------------------|--------------------|----------------|----------------------------------------------------|-----------------------------------------------------|------------------------|
|                                                          |                                  | Angle detector                                                 | Load decode beam coil | No load                                | Load               |                |                                                    |                                                     |                        |
|                                                          | P.11-27 to P.11-33               | P.11-61 to P.11-64                                             |                       | P.11-65 to P.11-72                     | P.11-78 to P.11-77 |                | P.11-84                                            | P.11-82                                             | Operator's Manual      |
| Both controller and data card replaced                   | △<br>(Controller program is old) | ○                                                              | ○                     | △<br>(Load or radius is inappropriate) |                    |                | x                                                  | x                                                   | ○                      |
| Only controller replaced (Existing data card to be used) | △<br>(Controller program is old) | x<br>(Basically unnecessary if adjusting data has been copied) |                       |                                        |                    |                | x                                                  | ○                                                   | ○                      |
| Data card replaced (Existing controller to be used)      | x                                | x                                                              | x                     | x                                      | x                  |                | ○                                                  | x<br>(Strictly prohibited)                          | ○                      |
| Program upgrade                                          | ○                                | x                                                              | x                     | x                                      | x                  |                | x                                                  | x                                                   | x                      |

○ To be implemented necessarily

△ To be implemented if necessary

x Unnecessary

## 11.2 PREPARATION FOR USE

Prior to installation, be sure to correctly identify and verify all the connecting lines. Then connect them to the CN11M to CN18M connectors, on the back of the unit. (The CN-12BM and CN-14M are not connected.)

### 11.3 TURN THE POWER ON

After checking all connections for accuracy. Then turn the power on.

All no misconnection may cause errors and/or cause an alarm to sound. In this case, shut the power off and re-check wiring and the detectors (load detector, angle detector). For further information on handling errors, see "11.7 ERROR CODE (ABNORMALITY DETECTION) AND COUNTERMEASURES".



## 11.4 UPGRADING PROGRAMS

When upgrading the programs in the controller, use the program memory card.

Two types of programs, comprising "indication programs" and "control programs", are stored in the controller. The program memory card for upgrading always contains these two types of programs.

### 11.4.1 PROCEDURES

Open the cover, and press the push button located on the left side of the loading port to partially eject the data memory card. Then, remove the card from the loading port with your fingers.

Check the version on the label attached to the program memory card, and fully insert the card into the loading port.


Use the dip switch located on the left side of the card loading port to enable the upgrading of programs. Turn the dip switch No.1 ON to upgrade indication programs, and turn the dip switch No.2 ON to upgrade control programs.


#### CAUTION

When upgrading both of display programs and control programs, be sure to upgrade the display programs first, and then, upgrade the control programs.


#### Insertion and removal of card

The card can be removed or inserted even when power supply to the controller is turned on, except for the time that the controller accesses the card. Messages including "Reading" or "Transferring" appear during the access. In such a status, DO NOT remove the card.

1. Turn ON the dip switch No.1 or 2 located in the cover. Then, **UP DATE** is displayed on the menu screen. Move the cursor  onto the **UP DATE**, and press the **SET** switch.




CK SERIES




CKE SERIES

2. "THE UPDATE OF THE INDICATION CPU" is displayed if the dip switch No.1 has been turned ON, and "THE UPDATE OF THE CONTROL CPU" is displayed if the dip switch No.2 has been turned ON.
- \* Both of the messages above are displayed in the example of the screen shown below, since both of the dip switches No.1 and 2 are turned ON in this case.

Move the cursor  $\leftarrow$  onto "THE UPDATE OF THE INDICATION CPU", and press the **SET** switch. Then, the indication programs can be upgraded. To upgrade the control programs, move the cursor  $\leftarrow$  onto "THE UPDATE OF THE CONTROL CPU", and press the **SET** switch.



CK SERIES



CKE SERIES

11.4.2 UPGRADING OF INDICATION PROGRAMS

1. Select "THE UPDATE OF THE INDICATION CPU".  
Then, the screen shown below is displayed.



DISPLAY PROGRAM UPDATE OK?  
YES : DOWN            CANCEL : MENU

When upgrading the program, press the switch.

When canceling, press the switch.

The previous screen appears when the switch is pressed.

2. When error messages appear on the screen just after the switch is pressed, the data memory card may be left inserted. In such a case, check the data memory card.

DISPLAY PROGRAM UPDATE OK?  
YES : DOWN            CANCEL : MENU

PROGRAM DATA OPEN  
PROGRAM DATA OPEN ERROR


PUSH ANY KEY TO RESET



## 11. LOAD SAFETY DEVICE

3. If the data memory card is not inserted, the error message of "INSERT PROGRAM CARD & PUSH ANY KEY" appears on the screen just after "THE UPDATE OF THE INDICATION CPU" is selected.

INSERT PROGRAM CARD & PUSH ANY KEY



If the error message above appears even though the data memory card is inserted, imperfect contact may occur. In such a case, remove the data memory card, and re-insert it.


- \* When inserting or removing the card, it is unnecessary to shut the power down. After re-inserting it, press any switch. If the error still cannot be corrected, the controller or the card may be faulty. In such a case, it must be replaced.

4. After the programs in the controller are erased (it takes approx. 30 sec.), new programs in the card are written onto the controller. When the indicated 0 KB is increased to 1023 KB, upgrading is complete. If upgrading is successfully completed, the screen shown below appears.

```
DISPLAY PROGRAM UPDATE OK?
YES:DOWN      CANCEL:MENU
```

```
PROGRAM DATA OPEN
PROGRAM DATA OPEN DETECTED
ERASE EEPROM (about 30sec)
TRANSFER PROGRAM DATA
1023KB
```

```
COMPLETE. PUSH ANY KEY TO RESET
```



When either switch is pressed, the power supply is reset, and the controller is rebooted. Then, upgrading of the indication programs is completed.

### **CAUTION**

DO NOT remove or insert the data memory card while programs in the card are written onto the controller. Otherwise, malfunction will occur.

## 11. LOAD SAFETY DEVICE

### 11.4.3 UPGRADING OF CONTROL PROGRAMS

1. Select "THE UPDATE OF THE CONTROL CPU".  
Then, the screen shown below is displayed.

The program of the control CPU is updated.  
Push ↓ if it is good. Cancellation is to push MENU.

When upgrading the program, press the switch.

When canceling, press the switch.


The previous screen appears when the switch is pressed.

2. When error messages appear on the screen just after the switch is pressed, the data memory card may not be inserted at all, or may be inserted partially or left inserted. In such a case, check the data memory card.

The program of the control CPU is updated.  
Push ↓ if it is good. Cancellation is to push MENU.

Data are being referred to.  
**Program data reference error. Push any switch.**

## Other errors

- Memory elimination error  
Program area in the flash memory in the controller cannot be deleted.  
→ Replace the controller.
  - Memory card read error  
Program cannot be read out from the card  
→ Recheck the card insertion status or replace the card.
  - Writing error  
Program cannot be written into the flash memory in the controller.  
→ Replace the controller.
3. If the intended programs are found in the controller after the  switch is pressed, they are erased first (it takes several seconds for erasure). Then, new programs in the card are written onto the controller. When the indicated 0 KB is increased to 1023 KB, upgrading is complete. If upgrading is successfully completed, the screen shown below appears.

The program of the control CPU is updated.  
Push ↓ if it is good. Cancellation is to push MENU.

Data are being referred to.  
Program data were deleted.  
A program memory is being erased.  
Program data are being transferred.  
128KB

It was completed.  
It is reset. Push any switch.

|                                                                                                                                                |  |                                  |  |
|------------------------------------------------------------------------------------------------------------------------------------------------|--|----------------------------------|--|
| RAT ID                                                                                                                                         |  | 00000000000000000000000000000000 |  |
| CBL                                                                                                                                            |  | 00000000000000000000000000000000 |  |
| B. ANGLE                                                                                                                                       |  | R. P. ELEV.                      |  |
| 00000000000000000000000000000000                                                                                                               |  | 00000000000000000000000000000000 |  |
| PS                                                                                                                                             |  | MAIN                             |  |
| RAT ID                                                                                                                                         |  | 00000000000000000000000000000000 |  |
| ACTUAL LEAD                                                                                                                                    |  | POUNDS 01000                     |  |
| ENTER LOAD                                                                                                                                     |  | POUNDS 01000                     |  |
| RADIOB                                                                                                                                         |  | 100                              |  |
| THE UPDATE OF<br>ELE CONTROL CPU                                                                                                               |  |                                  |  |
| The system of this control CPU is updated.<br>Push ↓ if it is good. Cancellation is to push MENU.                                              |  |                                  |  |
| Data are being referred to.<br>Program data were deleted.<br>A program memory is being erased.<br>Program data are being transferred.<br>128KB |  |                                  |  |
| It was completed.<br>It is reset. Push any switch.                                                                                             |  |                                  |  |

When either switch is pressed, the power supply is reset, and the controller is rebooted.  
Then, upgrading of the control programs is completed.




DO NOT remove or insert the data memory card while programs in the card are written onto the controller. Otherwise, malfunction will occur.

## 11. LOAD SAFETY DEVICE

### 11.5 STATUS CHECK

This controller features various status check functions for easier diagnosis of malfunctions.

Turn ON the dip switch No.4 in the cover. Then, the items to be checked are displayed in the lower half part of the screen as shown below.





11.5.1 SIGNAL CHECK

Statuses of signals input from the sensors and limit switches or those of automatic stop signal output can be checked.

On the "STATUS CHECK" screen, move the cursor → onto the "INPUT AND OUTPUT SIGNAL CONDITION".

and press the **SET** switch. Then, the screen shown below appears.


Statuses of analogue signals from the load cells and angle detectors are displayed on this first displayed screen.

Up to seven load cells and up to five angle detectors can be connected to this controller.



Refer to "Chart1. System Input/Output, Connector Designations" page11-20 for details of connection.

For the cells and sensors that are not connected to the controller, values close to 0.4 are displayed

|             |      |                |      |
|-------------|------|----------------|------|
| LOAD CELL 1 | 1.47 | ANGLE SENSCR 1 | 6.34 |
| LOAD CELL 2 | 0.37 | ANGLE SENSCR 2 | 1.10 |
| LOAD CELL 3 | 0.79 | ANGLE SENSCR 3 | 0.41 |
| LOAD CELL 4 | 0.37 | ANGLE SENSCR 4 | 0.41 |
| LOAD CELL 5 | 0.37 | ANGLE SENSCR 5 | 4.22 |
| LOAD CELL 6 | 0.59 |                |      |
| LOAD CELL 7 | 5.81 |                |      |



## 11. LOAD SAFETY DEVICE

Press the  or  switch once.

Then, the screen shown below appears.

Statuses of input and output of digital signals can be displayed on this screen.


For the designations and functions of signals, refer to "Chart3, System Input/Output (Digital Input)", "Chart4 System Input/Output (Digital Output)" page 11-22, 11-23.

For input digital signals, a "O" mark indicates the grounded status, and a "X" mark indicates the open status.

For output digital signals, a "O" mark indicates the output status, and a "X" mark indicates the non-output status.



- Displayed output signal statuses are decided as a result of software processing on y.
- If the hardware is faulty, the output may not be as shown below

| INPUT |       | OUTPUT |       |
|-------|-------|--------|-------|
| 1: O  | 11: X | 1: O   | 11: X |
| 2: O  | 12: X | 2: O   | 12: X |
| 3: O  | 13: X | 3: O   | 13: O |
| 4: O  | 14: X | 4: O   | 14: X |
| 5: O  | 15: X | 5: O   | 15: X |
| 6: X  | 16: X | 6: O   | 16: X |
| 7: X  | 17: X | 7: O   | 17: O |
| 8: X  | 18: X | 8: O   | 18: X |
| 9: X  | 19: X | 9: O   | 19: X |
| 10: X | 20: X | 10: X  | 20: O |



| INPUT |       | OUTPUT |       |
|-------|-------|--------|-------|
| 1: O  | 11: X | 1: O   | 11: X |
| 2: O  | 12: X | 2: O   | 12: X |
| 3: O  | 13: X | 3: O   | 13: O |
| 4: O  | 14: X | 4: O   | 14: X |
| 5: O  | 15: X | 5: O   | 15: X |
| 6: X  | 16: X | 6: O   | 16: X |
| 7: X  | 17: X | 7: O   | 17: O |
| 8: X  | 18: X | 8: O   | 18: X |
| 9: X  | 19: X | 9: O   | 19: X |
| 10: X | 20: X | 10: X  | 20: O |


## 11.5.2 OPERATION PROGRESS

On the "STATUS CHECK" screen, move the cursor  into the "OPERATION PROGRESS", and press the  switch. Then, the screen shown below appears.

```

FOM 23.62      FR      0.00
FOA 24.00      WHOLE R.L. 11.83
FOR 0.00       WHOLE A.L.  7.47
δM  4.73       WHOLE RAT. 53.56
δA  4.74       MAIN R.L.   11.83
δR  0.00       AUX. R.L.   11.28
F00 0.00       THRD R.L.   0.00
F      58.93      RM      89.30
FM      0.00      RA      82.50
FA      0.00      RR      0.00
C. VOLTAGE 2.80
1101000100110

```



| Symbols          | Details                                                                                                                 |
|------------------|-------------------------------------------------------------------------------------------------------------------------|
| FOM              | Tare weight component during main winch lifting with current radius                                                     |
| FOA              | Tare weight component during aux. winch lifting with current radius                                                     |
| FOR              | Tare weight component during third winch lifting with current radius                                                    |
| δM               | Load coefficient during main winch lifting with current radius                                                          |
| δA               | Load coefficient during aux. winch lifting with current radius                                                          |
| δR               | Load coefficient during third winch lifting with current radius                                                         |
| F00              | Tare weight component other than weight of hook block with current radius (during simultaneous lifting only) (Not used) |
| F                | Raising guy line tension                                                                                                |
| FM               | Main winch wire rope tension (w/ main winch load cell) (Not used)                                                       |
| FA               | Aux. winch wire rope tension (w/ aux. winch load cell) (Not used)                                                       |
| FR               | Third winch wire rope tension (w/ third winch load cell) (Not used)                                                     |
| WHOLE R.L.       | Whole rated load (rated load during selected mode other than simultaneous lifting mode)                                 |
| WHOLE A.L.       | Whole actual load (actual load during selected mode other than simultaneous lifting mode)                               |
| WHOLE RAT.       | Whole moment ratio (value indicated in bar graph)                                                                       |
| MAIN R.L.        | Main winch rated load with current radius on the basis of data                                                          |
| AUX. R.L.        | Aux. winch rated load with current radius on the basis of data                                                          |
| THIRD R.L.       | Third winch rated load with current radius on the basis of data                                                         |
| RM               | Calculated main winch operating radius before correction by radius adjustment                                           |
| RA               | Calculated aux. winch operating radius before correction by radius adjustment                                           |
| RR               | Calculated third winch operating radius before correction by radius adjustment                                          |
| C. VOLTAGE       | Control voltage of liquid crystal                                                                                       |
| 13-digits number | Data judgment code                                                                                                      |

## 11. LOAD SAFETY DEVICE

Example of using operation screen

The actual load  $W$  can be indicated by the formula shown below.

$$\text{Actual load } W = \frac{F - \{F \times k1 + k2\}}{\{\delta \times k3 + k4\}}$$

Labels for the formula:

- $F$ : Hoist guy line tension
- $k1$ : Dead weight component (M.A.R)
- $k2$ : Load-less adjustment value (Span)
- $k3$ : Load-less adjustment value (Shift)
- $k4$ : Some load adjustment value (Shift)
- $\delta$ : Some adjustment value (Span)
- $\delta$ : Load coefficient (M.A.R)

Suppose the values above are indicated shown below and the indicated actual load is 2 t, when a load weighing 5 t is lifted with the main winch.

$$F = 4.97$$

$$FOM = 2.28$$

$$\delta = 1.33$$

If neither load-less adjustment nor some load adjustment is carried out, and factors from  $k1$  to  $k4$  are ignored, the theoretical  $F$  required for the actual load of 5 t can be found by the using the formula above, as shown below

$$F = 5 \times 1.33 + 2.28 = 8.93$$

Where, the actual  $F$  is obviously smaller than the theoretical  $F$ .

Next, the  $F$  can be found by the formula shown below.

$$\text{Hoist guy line tension } F = \frac{\text{Load cell rated capacity} \times \{5 \times (\text{present load cell voltage} - \text{load cell zero adjustment value})\}}{\{\text{Load cell rated voltage} \times \{5 - \text{load cell zero adjustment value}\} \times 0.06355 \times (1.02 \text{ or } 0.98)\}}$$

Labels for the formula:

- Load cell rated capacity: depending on the machine models
- Load cell rated voltage
- present load cell voltage
- load cell zero adjustment value
- 5: freeing rope coefficient (depending on the machine models)
- 0.06355: Correction coefficient for lowering (depending on the machine models)
- 1.02 or 0.98: Correction coefficient for raising (depending on the machine models)

If the load cell zero point adjustment has not been carried out, adjustment value is 1, and the coefficient is 1.02, if lowering is stopped. In such a status, if the load cell voltage is calculated with using the formula above and the values when the  $F$  is 4.97, the present load cell voltage is 1.34 V.

In a similar manner, the load cell voltage is 1.61 V, when the theoretical tension  $F$  is 8.93.

Then, check the load cell voltage on the signal check screen (page 11-35).

If it is close to 1.34 V above, the detected load cell voltage is smaller than the theoretical value. In this case, the load cell may be faulty.




## 11. LOAD SAFETY DEVICE

### 11.5.3 COMMUNICATION DATA

Details of data transmitted from other controllers can be displayed.

Meanings of the numbers in communication data are shown below.

On the "STATUS CHECK" screen, move the cursor  $\leftarrow$  onto the "COMMUNICATION DATA", and press the **SET** switch. Then, the screen shown below appears. Control signals of control levers are used for the output of buzzer sounds or correction of load. Thus, check the communication status if any faults are found in them.




Both digital 3 and digital 4 are spare, and fixed to zero.

If "1" appears in the indicator corresponding to the operated lever, the status is normal. The response may be delayed by approximately a second, depending on the communication status. If only one operation is faulty and the others are normal, check the signals between the pressure sensors and the total controller.


11.5.4 INDICATION OF ADJUSTMENT VALUE


Results of adjustments can be checked

On the "STATUS CHECK" screen, move the cursor  $\rightarrow$

onto the "ADJUSTMENT VALUE", and press the  switch. Then the screen shown below appears (menu screen).

|                           |
|---------------------------|
| ANGLE SENSOR              |
| LOAD CELL ZERO POINT      |
| A LOAD CELL FOR LINE-PULL |
| FO/S (MANUFACTURER)       |
| FO/S (USER)               |
| RADIUS                    |



RAT 0 

(S) 00 00 00 00 00 00

ANGLE S.P. LEV. = 1

|             |        |
|-------------|--------|
| MAIN        |        |
| RATIO       | 3      |
| ACTUAL LOAD | POUNDS |
| RATED LOAD  | POUNDS |
| RADIUS      | ft     |

THE INDICAT. IS OF THE ADJUSTMENT VALUE

|                           |  |
|---------------------------|--|
| ANGLE SENSOR              |  |
| LOAD CELL ZERO POINT      |  |
| A LOAD CELL FOR LINE-PULL |  |
| FO/S (MANUFACTURER)       |  |
| FO/S (USER)               |  |
| RADIUS                    |  |

## 11. LOAD SAFETY DEVICE

### 11.5.4.1 ANGLE SENSOR ADJUSTMENT VALUE

On the "ADJUSTMENT VALUE" screen, move the cursor  $\Rightarrow$  onto the "ANGLE SENSOR", and press the  $\boxed{F7}$  switch. Then, the table showing angle sensor adjustment values appears on the screen

| THE INDICATION OF THE ADJUSTMENT VALUE<br>ANGLE SENSOR |        |        |        |        |        |
|--------------------------------------------------------|--------|--------|--------|--------|--------|
|                                                        | No. 1  | No. 2  | No. 3  | No. 4  | No. 5  |
| SHIFT                                                  | 0.000  | 0.000  | 0.000  | 0.000  | 0.000  |
| SPAN                                                   | 1.000  | 1.000  | 1.000  | 1.000  | 1.000  |
|                                                        | No. 6  | No. 7  | No. 8  | No. 9  | No. 10 |
| SHIFT                                                  | 0.000  | 0.000  | 0.000  | 0.000  | 0.000  |
| SPAN                                                   | 1.000  | 1.000  | 1.000  | 1.000  | 1.000  |
|                                                        | No. 11 | No. 12 | No. 13 | No. 14 | No. 15 |
| SHIFT                                                  | 0.000  | -2.003 | 0.000  | 0.000  | 0.000  |
| SPAN                                                   | 1.000  | 1.061  | 1.000  | 1.000  | 1.000  |

|                                                        |  |        |  |
|--------------------------------------------------------|--|--------|--|
| RATIO                                                  |  | 0.00   |  |
| B. ANGLE                                               |  | 0.00   |  |
| P. ELEV.                                               |  | 11     |  |
| D. H. H.                                               |  | 0.00   |  |
| R. A. 10                                               |  | 0.00   |  |
| ACTUAL LOAD                                            |  | 0.00   |  |
| RATED LOAD                                             |  | 0.00   |  |
| RADIUS                                                 |  | 11     |  |
| THE INDICATION OF THE ADJUSTMENT VALUE<br>ANGLE SENSOR |  |        |  |
| No. 1                                                  |  | No. 2  |  |
| SHIFT 0.000                                            |  | 0.000  |  |
| SPAN 1.000                                             |  | 1.000  |  |
| No. 3                                                  |  | No. 4  |  |
| SHIFT 0.000                                            |  | 0.000  |  |
| SPAN 1.000                                             |  | 1.000  |  |
| No. 5                                                  |  | No. 6  |  |
| SHIFT 0.000                                            |  | 0.000  |  |
| SPAN 1.000                                             |  | 1.000  |  |
| No. 7                                                  |  | No. 8  |  |
| SHIFT 0.000                                            |  | 0.000  |  |
| SPAN 1.000                                             |  | 1.000  |  |
| No. 9                                                  |  | No. 10 |  |
| SHIFT 0.000                                            |  | 0.000  |  |
| SPAN 1.000                                             |  | 1.000  |  |
| No. 11                                                 |  | No. 12 |  |
| SHIFT 0.000                                            |  | -2.003 |  |
| SPAN 1.000                                             |  | 1.061  |  |
| No. 13                                                 |  | No. 14 |  |
| SHIFT 0.000                                            |  | 0.000  |  |
| SPAN 1.000                                             |  | 1.000  |  |
| No. 15                                                 |  | No. 16 |  |
| SHIFT 0.000                                            |  | 0.000  |  |
| SPAN 1.000                                             |  | 1.000  |  |

In this machine No.2 is used as the boom angle detector and No.1 is used as the jib angle detector. While adjustment is not provided, "0.000 (in the lines of SHIFT)" and "1.000 (in the lines of SPAN)" are indicated.



### 11.5.4.2 LOAD CELL ZERO POINT ADJUSTMENT VALUE

On the "ADJUSTMENT VALUE" screen, move the cursor  $\leftarrow$  onto the "LOAD CELL ZERO POINT", and press the  $\boxed{Set}$  switch. Then, the table showing the load cell zero point adjustment values appears.

| THE INDICATION OF THE ADJUSTMENT VALUE<br>LOAD CELL ZERO POINT |       |       |       |       |        |
|----------------------------------------------------------------|-------|-------|-------|-------|--------|
|                                                                | No. 1 | No. 2 | No. 3 | No. 4 | No. 5  |
| iL1 [V]                                                        | 1.015 | 1.000 | 1.000 | 1.000 | 1.000  |
| iL2 [V]                                                        | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |
| iL3 [V]                                                        | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |
| iL4 [V]                                                        | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |
|                                                                | No. 6 | No. 7 | No. 8 | No. 9 | No. 10 |
| iL5 [V]                                                        | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |
| iL6 [V]                                                        | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |
| iL7 [V]                                                        | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |

| RATIO                                                          |       | MAIN  |       |       |        |
|----------------------------------------------------------------|-------|-------|-------|-------|--------|
| RATIO                                                          | 1.1   |       |       |       |        |
| ACTUAL LOAD                                                    |       |       |       |       |        |
| RATED LOAD                                                     |       |       |       |       |        |
| RADIUS                                                         | 1.1   |       |       |       |        |
| THE INDICATION OF THE ADJUSTMENT VALUE<br>LOAD CELL ZERO POINT |       |       |       |       |        |
|                                                                | No. 1 | No. 2 | No. 3 | No. 4 | No. 5  |
| iL1 [V]                                                        | 1.015 | 1.000 | 1.000 | 1.000 | 1.000  |
| iL2 [V]                                                        | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |
| iL3 [V]                                                        | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |
| iL4 [V]                                                        | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |
|                                                                | No. 6 | No. 7 | No. 8 | No. 9 | No. 10 |
| iL5 [V]                                                        | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |
| iL6 [V]                                                        | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |
| iL7 [V]                                                        | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |

In this machine No.1 of the iL1 is used as the boom load cell and No 4 of the iL1 is used as the jib load cell. While adjustment is not provided, "1.000" is indicated.


## 11. LOAD SAFETY DEVICE

### 11.5.4.3 ADJUSTMENT VALUE OF LOAD CELL FOR LINE-PULL

On the "ADJUSTMENT VALUE" screen, move the cursor  $\leftarrow$  onto the "A LOAD CELL FOR LINE-PULL", and press the  $\overline{SE}$  switch. Then, the table showing the adjustment values of load cell for line-pull appears.

THE INDICATION OF THE ADJUSTMENT VALUE  
A LOAD CELL FOR LINE-PULL

|       | M     | A     | R     |
|-------|-------|-------|-------|
| SHIFT | 0.000 | 0.000 | 0.000 |
| SPAN  | 1.000 | 1.000 | 1.000 |



The screenshot shows a terminal-style interface. At the top, there's a 'RATIO' field with a bar graph. Below it are fields for 'ANGLE' and 'ELEV.'. A 'MAIN' menu is visible with options for 'RATIO', 'ACTUAL LOAD', 'RATED LOAD', and 'RATIO'S'. Below the menu is a table titled 'THE INDICATION OF THE ADJUSTMENT VALUE A LOAD CELL FOR LINE-PULL' which matches the table shown in the previous block. An arrow points from this table to the one in the previous block.

M = MAIN, A = AUX., R = THIRD

While adjustment is not provided, "0.000 (in the line of SHIFT)" and "1.000 (in the line of SPAN)" are indicated.

Since this machine is not equipped with this load cell, it can be ignored.

### 11.5.4.4 RESULT OF MANUFACTURE ADJUSTMENTS "NO LOAD" AND "SOME LOAD"

On the "ADJUSTMENT VALUE" screen, move the cursor  $\rightarrow$  onto the "Fo/δ (MANUFACTURER)", and press the SET switch. Then, the table showing the results of manufacturers adjustments, "NO LOAD" and "SOME LOAD", appears on the screen.

{Fo = NO LOAD, δ = SOME LOAD}

THE INDICATION OF THE ADJUSTMENT VALUE Fo/δ (M) GR-1

|          | No. 1 | No. 2 | No. 3 | No. 4 | No. 5 |
|----------|-------|-------|-------|-------|-------|
| BOOM/JIB | 0.000 | 0.000 | 0.000 | 0.000 | 0.000 |
| No SHIFT | 0.000 | 0.000 | 0.000 | 0.000 | 0.000 |
| No SPAN  | 1.000 | 1.000 | 1.000 | 1.000 | 1.000 |
| S. SHIFT | 0.000 | 0.000 | 0.000 | 0.000 | 0.000 |
| S. SPAN  | 1.000 | 1.000 | 1.000 | 1.000 | 1.000 |

|          | No. 6 | No. 7 | No. 8 | No. 9 | No. 10 |
|----------|-------|-------|-------|-------|--------|
| BOOM/JIB | 0.000 | 0.000 | 0.000 | 0.000 | 0.000  |
| No SHIFT | 0.000 | 0.000 | 0.000 | 0.000 | 0.000  |
| No SPAN  | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |
| S. SHIFT | 0.000 | 0.000 | 0.000 | 0.000 | 0.000  |
| S. SPAN  | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |

The screenshot shows the GR-1 screen. At the top, there is a 'RATIO' bar with a scale from 0 to 100. Below it, there are fields for 'A. AND δ', 'A. P. E. S. Y.', and 'Fe'. A 'MAIN' button is visible. Below that, there are four rows: 'RATIO', 'ACTUAL LOAD', 'RATED LOAD', and 'RADIUS', each with a corresponding value field. To the right of these fields are labels: 'R', 'FORMED AT 0.00', 'FORMED AT 0.00', and 'F1'. At the bottom, there is a smaller table titled 'THE INDICATION OF THE ADJUSTMENT VALUE Fo/δ (M) GR-1' with columns for No. 1 to No. 10 and rows for BOOM/JIB, No SHIFT, No SPAN, S. SHIFT, and S. SPAN.

For group No. 1 to 30, adjustment with a load or without load for ten types of boom lengths is possible.

First, the table of group No. 1 is displayed. ("GR-1" can be seen in the upper right side of the screen.) Whenever the  $\rightarrow$  switch is pressed, the screen changes from GR-1 to GR-30.

Whenever the  $\leftarrow$  switch is pressed, screens appear in the following orders: GR-1, GR-30, GR-25, ....

In respect of No. 1 to 10, boom length or Jib length (BOOM/JIB) on which adjustment is conducted, shift and span of adjustment without load (No SHIFT, No SPAN), and shift and span of adjustment with a load (S. SHIFT, S. SPAN) are indicated.

While adjustment is not provided, "0.000 (in the lines of BOOM/JIB, No SHIFT, S. SHIFT)" and "1.000 (in the lines of No SPAN, S. SPAN)" are indicated.

If the lengths of the two or more booms have been already adjusted and the length of the boom that has not been adjusted yet is used, the adjusted two lengths that are closest to it are corrected, and the adjusted length of the boom that has not been adjusted yet is calculated, accordingly.

## 11. LOAD SAFETY DEVICE

### 11.5.4.5 RESULT OF LOAD ADJUSTMENTS "NO LOAD" AND "SOME LOAD"

On the "ADJUSTMENT VALU" screen, move the cursor  $\leftarrow$  onto the "Fct/d (USER)", and press the  $\boxed{SE}$  switch.

Then, the table showing the results of user adjustments, "NO LOAD" and "SOME LOAD", for the selected mode appears on the screen.

THE INDICATION OF THE ADJUSTMENT VALUE  
Fct/d (USER)

|          | M     | A     | R     |
|----------|-------|-------|-------|
| 4b SHIFT | 0.000 | 0.000 | 0.000 |
| 4b SPAN  | 1.000 | 1.000 | 1.000 |
| 3. SHIFT | 0.000 | 0.000 | 0.000 |
| 3. SPAN  | 1.000 | 1.000 | 1.000 |

The screenshot shows a screen with several data fields and a table. At the top, there are fields for "R. ANGLE" and "R. P. FLUX". Below these is a "MANU" label. A large table displays "RATIO", "ACTUAL LOAD", "RATED LOAD", and "RATIO". Below this is another table with the caption "THE INDICATION OF THE ADJUSTMENT VALUE Fct/d (USER)". An arrow points from this table to the one in the previous block.

|          | M     | A     | R     |
|----------|-------|-------|-------|
| 4b SHIFT | 0.000 | 0.000 | 0.000 |
| 4b SPAN  | 1.000 | 1.000 | 1.000 |
| 3. SHIFT | 0.000 | 0.000 | 0.000 |
| 3. SPAN  | 1.000 | 1.000 | 1.000 |

M = MAIN, A = AUX., R = THIRD

While adjustment is not provided, "0.000 (in the lines of SHIFT)" and "1.000 (in the lines of SPAN)" are indicated.

### 11.5.4.6 ADJUSTMENT VALUE OF WORKING RADIUS

On the "ADJUSTMENT VALUE" screen, move the cursor  $\Rightarrow$  onto the "RADIUS", and press the  $\overline{\text{SET}}$  switch. Then, the table showing the adjustment value of working radius appears on the screen.

Adjustment values of group No. 1 to 30 can be displayed on this screen, and the table of group No. 1 to 10 is displayed first. To display the table of groups No. 11 to 20, press the  $\overline{\text{PAGE}}$  switch.

While adjustment is not provided, "0.000 (in the lines of SHIFT)" and "1.000 (in the lines of SPAN)" are indicated.

| INDICATION OF THE ADJUSTMENT VALUE RADIUS |       |       |       |       |        |
|-------------------------------------------|-------|-------|-------|-------|--------|
|                                           | No. 1 | No. 2 | No. 3 | No. 4 | No. 5  |
| SHIFT                                     | 0.000 | 0.000 | 0.000 | 0.000 | 0.000  |
| SPAN                                      | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |
|                                           | No. 6 | No. 7 | No. 8 | No. 9 | No. 10 |
| SHIFT                                     | 0.000 | 0.000 | 0.000 | 0.000 | 0.000  |
| SPAN                                      | 1.000 | 1.000 | 1.000 | 1.000 | 1.000  |

| RATIO                                     |       | %     |       |        |
|-------------------------------------------|-------|-------|-------|--------|
| 10                                        | 20    | 30    | 40    |        |
| RATIO                                     |       |       |       |        |
| ACTUAL LOAD                               |       | POLYD |       |        |
| RATED LOAD                                |       | POLYD |       |        |
| RAC - S                                   |       | 1-    |       |        |
| INDICATION OF THE ADJUSTMENT VALUE RADIUS |       |       |       |        |
| No. 1                                     | No. 2 | No. 3 | No. 4 | No. 5  |
| SHIFT                                     | 0.000 | 0.000 | 0.000 | 0.000  |
| SPAN                                      | 1.000 | 1.000 | 1.000 | 1.000  |
| No. 6                                     | No. 7 | No. 8 | No. 9 | No. 10 |
| SHIFT                                     | 0.000 | 0.000 | 0.000 | 0.000  |
| SPAN                                      | 1.000 | 1.000 | 1.000 | 1.000  |

## 11. LOAD SAFETY DEVICE

### 11.5.4.7 ALTERATION OF ADJUSTED VALUE




When the DIP switch No.3 is turned on while the adjusted values are displayed, alteration of them becomes enabled.





A cursor (light blue) appears.


The title "The indication of the adjustment value" is changed to "The change of the adjustment value", and the color is also changed from light blue to yellow.


| THE CHANGE OF THE ADJUSTMENT VALUE<br>ANGLE SENSOR |        |        |        |        |        |
|----------------------------------------------------|--------|--------|--------|--------|--------|
|                                                    | No. 1  | No. 2  | No. 3  | No. 4  | No. 5  |
| SHIFT                                              | 0.000  | 0.000  | 0.000  | 0.000  | 0.000  |
| SPAN                                               | 1.000  | 1.000  | 1.000  | 1.000  | 1.000  |
|                                                    | No. 6  | No. 7  | No. 8  | No. 9  | No. 10 |
| SHIFT                                              | 0.000  | 0.000  | 0.000  | 0.000  | 0.000  |
| SPAN                                               | 1.000  | 1.000  | 1.000  | 1.000  | 1.000  |
|                                                    | No. 11 | No. 12 | No. 13 | No. 14 | No. 15 |
| SHIFT                                              | 0.000  | 0.000  | 0.000  | 0.000  | 0.000  |
| SPAN                                               | 1.000  | 1.061  | 1.000  | 1.000  | 1.000  |

Adjustment value is changed.  
Push SET if it is good. Cancellation is to push MENU

Move the cursor onto the item to be altered with the  and  switches. To increase the value, use the  switch.

To decrease it, use the  switch. Then, press the  switch. To cancel the alteration, press the  switch before pressing the  switch.

When the  switch is pressed, the message "Alteration of adjusted value is completed." appears.

When the  switch is pressed, the message "Alteration is cancelled." appears.

### 11.5.4.8 DELETION OF ADJUSTED VALUE





When the DIP switches No.3 and No.6 are turned on while the adjusted values are displayed, deletion of them becomes enabled.


A cursor (red) appears.


The title "The indication of the adjustment value" is changed to "The elimination of the adjustment value", and the color is also changed from light blue to red.

| THE ELIMINATION OF THE ADJUSTMENT VALUE<br>ANGLE SENSOR |        |        |        |        |        |
|---------------------------------------------------------|--------|--------|--------|--------|--------|
|                                                         | No. 1  | No. 2  | No. 3  | No. 4  | No. 5  |
| SHIFT                                                   | 0.000  | 0.000  | 0.000  | 0.000  | 0.000  |
| SPAN                                                    | 1.000  | 1.000  | 1.000  | 1.000  | 1.000  |
|                                                         | No. 6  | No. 7  | No. 8  | No. 9  | No. 10 |
| SHIFT                                                   | 0.000  | 0.000  | 0.000  | 0.000  | 0.000  |
| SPAN                                                    | 1.000  | 1.000  | 1.000  | 1.000  | 1.000  |
|                                                         | No. 11 | No. 12 | No. 13 | No. 14 | No. 15 |
| SHIFT                                                   | 0.000  | 0.000  | 0.000  | 0.000  | 0.000  |
| SPAN                                                    | 1.000  | 1.061  | 1.000  | 1.000  | 1.000  |

Adjustment value is changed.  
Push SET if it is good. Cancellation is to push MENU

Move the cursor onto the item to be altered with the  and  switches, and press the  switch. To execute the deletion, press the  switch again.

To cancel the deletion, press the  switch.

When the  switch is pressed, the message "Deletion of adjusted value is completed." appears.

When the  switch is pressed, the message "Deletion is cancelled." appears.

## 11. LOAD SAFETY DEVICE


### 11.5.5 LOAD RECORD

This controller features the function to record the data of hazardous statuses for easier investigation of causes of troubles (load record).

The recording is started when the moment ratio or boom angle exceeds the upper or lower limit values, and data are recorded for ten seconds in total, from the time five seconds before the peak to the time four seconds after the peak every second.

On the "ADJUSTMENT VALUE" screen, move the cursor  $\Rightarrow$  onto the "LOAD RECORD", and press the **SET** switch. Then, the load records can be checked.

Unit record (records for 10 seconds) is displayed in two pages. To scroll down the page, press the **↓** key, and press the **↑** key to scroll up the page. Up to 200 units of records (400 pages) are available.



Page  
1P

```

0/ 8/ 1 18: 6: 8 1100400100110 2 1 0 A
0% 0.0P 0.0P 0.0ft 103% 17.5P 17.0P 37.4ft
0% 0.0P 0.0P 0.0ft 103% 40.8deg- 8.6deg
0000000 0000000 0000000 0000000 1000000 49.4deg
    
```

Four seconds after the peak of moment ratio

```

0/ 8/ 1 18: 6: 7 1100400100110 2 1 0 A
0% 0.0P 0.0P 0.0ft 105% 17.5P 17.0P 37.4ft
0% 0.0P 0.0P 0.0ft 105% 40.8deg- 8.6deg
0000000 0000000 0000000 0000000 1000000 49.4deg
    
```

Three seconds after the peak of moment ratio

```

0/ 8/ 1 18: 6: 6 1100400100110 2 1 0 A
0% 0.0P 0.0P 0.0ft 106% 17.5P 17.0P 37.4ft
0% 0.0P 0.0P 0.0ft 106% 40.8deg- 8.6deg
0000000 0000000 0000000 0000000 1000000 49.4deg
    
```

Two seconds after the peak of moment ratio

```

0/ 8/ 1 18: 6: 5 1100400100110 2 1 0 A
0% 0.0P 0.0P 0.0ft 112% 17.5P 17.0P 37.4ft
0% 0.0P 0.0P 0.0ft 112% 40.8deg- 8.6deg
0000000 0000000 0000000 0000000 1000000 49.4deg
    
```

One second after the peak of moment ratio

```

0/ 8/ 1 18: 6: 4 1100400100110 2 1 0 A
0% 0.0P 0.0P 0.0ft 116% 17.5P 17.0P 37.4ft
0% 0.0P 0.0P 0.0ft 116% 40.8deg- 8.6deg
0000000 0000000 0000000 0000000 1000000 49.4deg
    
```

Peak of moment ratio



```

0/ 8/ 1 18: 6: 3 1100400'00110 2 1 0 A
  0% 0.0P 0.0P 0.0ft 116% 17.5P 17.0P 37.4ft
  0% 0.0P 0.0P 0.0ft 116% 40.8deg- 8.6deg
0000000 0000000 0000000 0000000 1000000 49.4deg } A second before
the peak of moment ratio

0/ 8/ 1 18: 6: 2 1100400'00110 2 1 0 A
  0% 0.0P 0.0P 0.0ft 116% 17.5P 17.0P 37.4ft
  0% 0.0P 0.0P 0.0ft 116% 40.8deg- 8.6deg
0000000 0000000 0000000 0000000 1000000 49.4deg } Two seconds before
the peak of moment ratio

0/ 8/ 1 18: 6: 1 1100400'00110 2 1 0 A
  0% 0.0P 0.0P 0.0ft 116% 17.5P 17.0P 37.4ft
  0% 0.0P 0.0P 0.0ft 116% 40.8deg- 8.6deg
0000000 0000000 0000000 0000000 1000000 49.4deg } Three seconds before
the peak of moment ratio

0/ 8/ 1 18: 6: 0 1100400'00110 2 1 0 A
  0% 0.0P 0.0P 0.0ft 116% 17.5P 17.0P 37.4ft
  0% 0.0P 0.0P 0.0ft 116% 40.8deg- 8.6deg
0000000 0000000 0000000 0000000 1000000 49.4deg } Two seconds before
the peak of moment ratio

0/ 8/ 1 18: 5: 59 1100400'00110 2 1 0 A
  0% 0.0P 0.0P 0.0ft 110% 17.5P 17.0P 37.4ft
  0% 0.0P 0.0P 0.0ft 110% 40.8deg- 8.6deg
0000000 0000000 0000000 0000000 1000000 49.4deg } A second before
the peak of moment ratio
    
```

**Meanings of numerals**

P=POUNDSX100  
'f' is indicated when the indicated unit is feet.  
'm' is indicated when the indicated unit is meter.

| DATE        | TIME              | DATA CODE        | No. OF PART LINE<br>(1st/2nd/3rd) | MODE       |                  |                |            |
|-------------|-------------------|------------------|-----------------------------------|------------|------------------|----------------|------------|
| 0/ 8/ 1     | 18: 6: 3          | 11004001001'0    | 2 1 0                             | A          |                  |                |            |
| RATIO (M)   | ACTUAL LOAD (M)   | RATED LOAD (M)   | RADIUS (A)                        | RATIO (A)  | ACTUAL LOAD (A)  | RATED LOAD (A) | RADIUS (A) |
| 0%          | 0.0P              | 0.0P             | 0.0ft                             | 103%       | 17.5P            | 17.0P          | 37.4ft     |
| RATIO (3rd) | ACTUAL LOAD (3rd) | RATED LOAD (3rd) | RADIUS (3rd)                      | ALL-RATIO  | BOOM ANGLE       |                | JIB ANGLE  |
| 0%          | 0.0P              | 0.0P             | 0.0ft                             | 103%       | 40.8deg-         |                | 8.6deg     |
| 0000000     | 0000000           | 0000000          | 0000000                           | 1000000    | 49.4deg          |                |            |
| 1-1 to 1-7  | 2-1 to 2-7        | 3-1 to 3-7       | 4-1 to 4-7                        | 5-1 to 5-7 | Jib offset angle |                |            |

## 11. LOAD SAFETY DEVICE


| No. |                | Signal                            | Signal level                                |                              |
|-----|----------------|-----------------------------------|---------------------------------------------|------------------------------|
| 1-1 | Limit switch   | Luffing jib LS                    | 0 : Normal<br>1 : Overhoist                 |                              |
| 1-2 |                | Boom backstop LS (1)              |                                             |                              |
| 1-3 |                | Boom overhoist LS (Crane)         |                                             |                              |
| 1-4 |                | Boom backstop LS (2)              |                                             |                              |
| 1-5 |                | Anti-two block LS (tower)         |                                             |                              |
| 1-6 |                | Anti-two block LS (aux.)          |                                             |                              |
| 1-7 |                | Anti-two block LS (main)          |                                             |                              |
| 2-1 |                | Gantry fix link LS (Not used)     | 0 : Un-connection 1 : Connection            |                              |
| 2-2 | Release switch | Boom fix SW                       | 1 : Fix position 0 : Normal position        |                              |
| 2-3 |                | Master key SW                     | 1 : Release position<br>0 : Normal position |                              |
| 2-4 |                | Over load release SW              |                                             |                              |
| 2-5 |                | Boom overhoist release SW         |                                             |                              |
| 2-6 |                | Anti-two block release SW         |                                             |                              |
| 2-7 |                | Fixed jib overhoist LS (Not used) | 0 : Normal 1 : Overhoist                    |                              |
| 3-1 | Limit switch   | Not used                          | 1 : Contact 0 : Un-contact                  |                              |
| 3-2 |                | Gantry cylinder LS (Not used)     |                                             |                              |
| 3-3 |                | Not used                          |                                             |                              |
| 3-4 |                | Counterweight detect 2 (Option)   |                                             |                              |
| 3-5 |                | Counterweight detect 1 (Option)   |                                             |                              |
| 3-6 |                | Strut overlowering LS (Not used)  |                                             | 0 : Normal                   |
| 3-7 |                | Strut overhoist LS (Not used)     |                                             | 1 : Overhoist (Overlowering) |
| 4-1 | Operation      | Third drum lower                  | 1 : Operation<br>0 : Neutral                |                              |
| 4-2 |                | Third drum lower                  |                                             |                              |
| 4-3 |                | Rear drum hoist                   |                                             |                              |
| 4-4 |                | Rear drum hoist                   |                                             |                              |
| 4-5 |                | Front drum lower                  |                                             |                              |
| 4-6 |                | Front drum hoist                  |                                             |                              |
| 4-7 |                | Communication                     |                                             |                              |
| 5-1 |                | Not used                          | 1 : Trouble 0 : Normal                      |                              |
| 5-2 | Operation      | Not used                          | 1 : Operation<br>0 : Neutral                |                              |
| 5-3 |                | Jib drum lower                    |                                             |                              |
| 5-4 |                | Jib drum hoist                    |                                             |                              |
| 5-5 |                | Boom drum lower                   |                                             |                              |
| 5-6 |                | Boom drum hoist                   |                                             |                              |
| 5-7 |                |                                   |                                             |                              |

11.5.6 TROUBLE RECORD

On the "STATUS CHECK" screen, move the cursor  $\rightarrow$  onto the "TROUBLE RECORD", and press the  $\overline{\text{ENT}}$  switch.

Then, the screen shown below appears  
 Past ten trouble records (trouble No. and dates of trouble occurrence) are displayed on this screen.  
 Trouble No. means message No. For details, refer to the message list of page 11-88.  
 When the number of trouble records exceeds ten, the oldest data is erased.

| TROUBLE No. | DATE            |
|-------------|-----------------|
| 36          | 2000. 711. 1643 |
| 44          | 2000. 711. 1642 |
| 0           | 2000. 0 0 0 0   |
| 0           | 2000. 0 0 0 0   |
| 0           | 2000. 0 0 0 0   |
| 0           | 2000. 0 0 0 0   |
| 0           | 2000. 0 0 0 0   |
| 0           | 2000. 0 0 0 0   |
| 0           | 2000. 0 0 0 0   |
| 0           | 2000. 0 0 0 0   |



## 11. LOAD SAFETY DEVICE

### ERASING TROUBLE RECORDS

Previous trouble records can be erased prior to use of the controller together with other machines.

While trouble records are displayed, turn the dip switch No.6 ON.


Then, the messages shown below appear. To erase

the records, press the **SET** switch. To cancel erasing,

press the **MENU** switch.

| TROUBLE No. | DATE             |
|-------------|------------------|
| 36          | 2000. 7 11. 1843 |
| 44          | 2000. 7 11. 1842 |
| 0           | 2000. 0 0. 0 0   |
| 0           | 2000. 0 0. 0 0   |
| 0           | 2000. 0 0. 0 0   |
| 0           | 2000. 0 0. 0 0   |
| 0           | 2000. 0 0. 0 0   |
| 0           | 2000. 0 0. 0 0   |
| 0           | 2000. 0 0. 0 0   |
| 0           | 2000. 0 0. 0 0   |


Data are erased.  
Push SET if it is good. Cancellation is to push MENU.



Press the **SET** switch. Then, all the trouble records are erased, and the screen returns to the initial status.



| TROUBLE No. | DATE           |
|-------------|----------------|
| 0           | 2000. 0 0. 0 0 |
| 0           | 2000. 0 0. 0 0 |
| 0           | 2000. 0 0. 0 0 |
| 0           | 2000. 0 0. 0 0 |
| 0           | 2000. 0 0. 0 0 |
| 0           | 2000. 0 0. 0 0 |
| 0           | 2000. 0 0. 0 0 |
| 0           | 2000. 0 0. 0 0 |
| 0           | 2000. 0 0. 0 0 |
| 0           | 2000. 0 0. 0 0 |


Data are erased.




After erasing, turn off the dip switch No.6.

## 11.5.7 CHOICE OF LANGUAGE (CKE SERIES ONLY)

On the "STATUS CHECK" screen, move the cursor  onto "言語 LANGUAGE", and press the  switch. Then, the screen shown below appears.

For CK series Model, move the cursor onto the "LNG (ft-lbs)" and press the  switch.

For CKE series Model, move the cursor onto the "ENG (m-t)" and press the  switch



## 11. LOAD SAFETY DEVICE

### 11.5.8 LOAD RECORD (LOAD RECORD IN THE MAIN MENU)

#### Erasing load records

Previous load records can be erased prior to use of the controller together with other machines.

While load records are displayed (both of records displayed in the order of moment ratio and those displayed in the order of date are acceptable), turn the dip switch No.6 ON

Then, the messages shown below appear. To erase

the records, press the **SET** switch. To cancel erasing,

press the **REV** switch

#### LOAD RECORD (RECENT VALUE)

↑↓ = Next page

| RATIO | RADIUS | BODM | JIB | MODE | DATE            |
|-------|--------|------|-----|------|-----------------|
| 24    | 43     | 100  | 2   | M    | 2000. 711. 1531 |
| 34    | 43     | 100  | 2   | M    | 2000. 711. 1523 |
| 97    | 43     | 100  | 2   | M    | 2000. 711. 1523 |
| 58    | 43     | 100  | 2   | M    | 2000. 711. 1623 |
| 148   | 95     | 100  | 2   | M    | 2000. 711. 1429 |
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0  |
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0  |
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0  |
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0  |
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0  |

Data are erased.

Push SET if it is load. Cancellation is to push MENU.

Press the **SET** switch. Then, the records are erased and the screen is reset as shown below

#### LOAD RECORD (MAX. VALUE)

↑↓ = Next page

| RATIO | RAD US | BODM | JIB | MODE | DATE           |
|-------|--------|------|-----|------|----------------|
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0 |
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0 |
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0 |
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0 |
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0 |
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0 |
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0 |
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0 |
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0 |
| 0     | 0      | 0    | 0   |      | 2000. 0 0. 0 0 |

Data are erased.

After erasing, turn off the dip switch No.6.

## 11.6 ADJUSTMENTS



Prior to adjustment, be sure to check the items below.

1. Input crane configuration
2. Main/jib lifting selection


In this section, the adjustment of sensors installed to the crane and various coefficients, and other functions are described.

### 11.6.1 REMOVING THE INNER PANEL

The dip switches that are needed for adjustment are located when you remove cover.

Take off 2 (1) screws shown below to remove the cover.

Do not lose the cover or the screws.



## 11. LOAD SAFETY DEVICE

### 11.8.2 ADJUSTMENT

When the menu screen is displayed, turn ON the dip switch No.3 of the controller.

Then, the "ADJUSTMENT" screen is displayed.

CK SERIES

CKE SERIES

Move the cursor  $\Rightarrow$  onto the "ADJUSTMENT", and press the **SET** switch. Then, the screen shown below appears.



Move the cursor  $\rightarrow$  onto the "MANUFACTURER ADJUSTMENT", and press the **SET** switch.  
Then, the screen shown below appears.

#### MANUFACTURE ADJUSTMENT

|                                 |                                                                                                                                                                                                                                                                                                     |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ANGLE SENSOR ADJUSTMENT         | This adjustment should be performed when the indicated angle is different from the actual angle or the angle detector is replaced.<br>(Adjustment should be performed within the specified range. If the adjusted value is out of the range, the adjustment is invalid.)                            |
| LOAD CELL ZERO POINT ADJUSTMENT | This adjustment should be performed if the output voltage is deviated when no load is applied to the load cell.<br>(Adjustment should be performed within the specified range. If the adjusted value is out of the range, the adjustment is invalid.)                                               |
| LOAD-LESS ADJUSTMENT            | This adjustment should be performed if the indicated actual load is excessively deviated when a light load such as a hook is lifted.<br>(Adjustment should be performed within the specified range. If the adjusted value is out of the range, the adjustment is invalid.)                          |
| SOME LOAD ADJUSTMENT            | This adjustment should be performed if the indicated actual load is excessively deviated when a load is lifted after the load-less adjustment is carried out.<br>(Adjustment should be performed within the specified range. If the adjusted value is out of the range, the adjustment is invalid.) |
| LVL ADJUSTMENT                  | Automatic stop points (alarm points) can be changed                                                                                                                                                                                                                                                 |
| RADIUS ADJUSTMENT               | This adjustment should be performed if the indicated working radius is excessively different from the actual working radius<br>(Adjustment should be performed within the specified range. If the adjusted value is out of the range, the adjustment is invalid.)                                   |

## 11. LOAD SAFETY DEVICE

---

Since limitations are provided for these adjustments, they cannot be compensated when the adjusted values are excessively deviated. In such a case, ensure that the sensors are free from any fault, crane configuration is input correctly, and adjustment procedures are appropriate.


### LOAD ADJUSTMENT

This adjustment is intended for emergency, and there is no limitation of adjustment values. It is valid for adjusted attachments only. After the attachments are changed, it is invalid.

|                      |                                                                                                                                                   |
|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| LOAD-LESS ADJUSTMENT | This adjustment should be performed when "LOAD-LESS ADJUSTMENT" of MANUFACTURE ADJUSTMENT is rejected. It is valid for adjusted attachments only. |
| LOAD-LESS ADJUSTMENT | This adjustment should be performed when "SOME LOAD ADJUSTMENT" of MANUFACTURE ADJUSTMENT is rejected. It is valid for adjusted attachments only. |

11.6.2.1 ANGLE SENSOR ADJUSTMENT


Move the cursor  $\rightarrow$  onto the "ANGLE SENSOR ADJUSTMENT", and press the  $\overline{\text{SET}}$  switch. Then, the screen shown below appears.



If the boom and the jib are equipped with the angle sensors, several choices are displayed

1. Move the cursor  $\rightarrow$  onto the intended angle sensor (angle sensor to be adjusted), raise the boom close to the upper limit, and press the  $\overline{\text{SET}}$  switch. Then, the screen shown below appears.

Fill it to the actual boom angle with  $\uparrow$ , and push SET.  
[ 69. 7] deg



## 11. LOAD SAFETY DEVICE

2. Measure the actual boom angle with a level or an angle gauge, enter the measured boom angle in the

[ ] on the screen, and press the **SET** switch. Then, the screen shown below appears.

Push SET after you make an actual boom angle choice at more than 25deg.

| MAIN        |                   |
|-------------|-------------------|
| RATED       | 19 M              |
| ACTUAL LOAD | 7.3 POUNDS @1000  |
| RATED LOAD  | 38.1 POUNDS @1000 |
| RADIUS      | 37.9 ft           |

THE ADJUSTMENT OF THE LOWER BOOM ANGLE SENSOR.  
FIT IT TO THE ACTUAL BOOM ANGLE WITH ← AND PUSH SET.  
C. 04. 13deg  
Push SET after you make an actual boom angle choice at more than 25deg.

3. After lowering the boom by 25 deg. or more, stop it and press the **SET** switch. Then, the screen shown below appears.

### Note

Angle of 25 deg. is just a guideline for lowering the boom, and this guideline should not be necessarily observed. However, remember that the adjustment is effective if the boom is lowered with an angle as large as possible.

Fit it to the actual boom angle with ← and push SET.  
[ 40. 5] deg

| MAIN        |                   |
|-------------|-------------------|
| RATED       | 2 M               |
| ACTUAL LOAD | 0.3 POUNDS @1000  |
| RATED LOAD  | 13.8 POUNDS @1000 |
| RADIUS      | 79.7 ft           |

THE ADJUSTMENT OF THE LOWER BOOM ANGLE SENSOR.  
FIT IT TO THE ACTUAL BOOM ANGLE WITH ← AND PUSH SET.  
C. 04. 13deg  
Push SET after you make an actual boom angle choice at more than 25deg.  
FIT IT TO THE ACTUAL BOOM ANGLE WITH ← AND PUSH SET.  
C. 04. 13deg

4. Measure the actual boom angle with a level or an angle gauge. enter the measured boom angle in the [ ] on the screen, and press the  $\overline{\text{SET}}$  switch


In this case, the maximum angle is adjusted first and the minimum angle is adjusted next  
Of course, the reverse order is also acceptable.

5. When the adjustment is successfully completed, messages shown below are displayed (numerals in [ ] are changed whenever adjustment is complete).

Press the  $\overline{\text{SET}}$  switch. Then, the screen returns to that before the adjustment is performed.

Adjustment menu will Push SET.

ANGLE TO ADJUST [ 89. 7]deg [ 40. 5]deg  
VOLTAGE [ 5. 88] Y [ 3. 87] Y






11.6.2.2 LOAD CELL ZERO POINT ADJUSTMENT

Errors in output voltage (10 V) when no load is applied to the load cell can be adjusted


- 1 Move the cursor → onto the "LOAD CELL ZERO POINT ADJUSTMENT", and press the **SET** switch. Then, the screen shown below appears.



- 2 For the crane with several load cells, number of load cells is displayed on this screen. Move the cursor → onto the load cell item you intend to adjust, and press the **SET** switch. Then, the screen shown below appears.

Note the tension applied to the load cell becomes zero.  
Push SET if it is good.

ZERO OFFSET VALUE OF LOAD CELL [ 0.05 ] Y



## 11. LOAD SAFETY DEVICE

- Decrease the tension applied to the load cell by removing the load cell completely or loosening the wire rope as far as possible. When this step is complete, press the **[SET]** switch.
- When the displayed load cell voltage is not in the range from 0.8 to 1.2 V, the load cell is judged to be faulty and the adjustment is rejected. In such a case, replace the load cell.
- When the adjustment is successfully completed, the screen shown below appears. Press the **[SET]** switch is to return to the previous screen.

Make the tension applied to the load cell become a zero.

Push SET if it is good.

Adjustment went well. Push SET

ZERO OFFSET VALUE OF LOAD CELL [ 1.05] V

|                                                                                                                       |  |                 |  |
|-----------------------------------------------------------------------------------------------------------------------|--|-----------------|--|
| RATIO                                                                                                                 |  | [ 0.00 ]        |  |
| W. ANGLE                                                                                                              |  | [ 0.00 ]        |  |
| W. P. ELEV.                                                                                                           |  | [ 0.00 ]        |  |
| RATIO                                                                                                                 |  | [ 0.00 ]        |  |
| ACTUAL LOAD                                                                                                           |  | [ 0.00 ] POUNDS |  |
| RATED LOAD                                                                                                            |  | [ 0.00 ] POUNDS |  |
| RADIUS                                                                                                                |  | [ 0.00 ] FT     |  |
| <b>THE ADJUSTMENT OF THE ROOM LOAD CELL</b>                                                                           |  |                 |  |
| Make the tension applied to the load cell become a zero.<br>Push SET if it is good.<br>Adjustment went well. Push SET |  |                 |  |
| ZERO OFFSET VALUE OF LOAD CELL [ 1.05] V                                                                              |  |                 |  |

- When the adjustment is not successfully completed, the screen shown below appears. Ensure that no tension is applied to the load cell, and re-perform the adjustment.

Adjustment is failed.

Push SET after you reconfirm whether the tension applied to the load cell is a zero.

ZERO OFFSET VALUE OF LOAD CELL [ 1.47] V

|                                                                                                                                                                                                      |  |                 |  |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|-----------------|--|
| RATIO                                                                                                                                                                                                |  | [ 0.00 ]        |  |
| W. ANGLE                                                                                                                                                                                             |  | [ 0.00 ]        |  |
| W. P. ELEV.                                                                                                                                                                                          |  | [ 0.00 ]        |  |
| RATIO                                                                                                                                                                                                |  | [ 0.00 ]        |  |
| ACTUAL LOAD                                                                                                                                                                                          |  | [ 0.00 ] POUNDS |  |
| RATED LOAD                                                                                                                                                                                           |  | [ 0.00 ] POUNDS |  |
| RADIUS                                                                                                                                                                                               |  | [ 0.00 ] FT     |  |
| <b>THE ADJUSTMENT OF THE ROOM LOAD CELL</b>                                                                                                                                                          |  |                 |  |
| Make the tension applied to the load cell become a zero.<br>Push SET if it is good.<br>Adjustment is failed.<br>Push SET after you reconfirm whether the tension applied to the load cell is a zero. |  |                 |  |
| ZERO OFFSET VALUE OF LOAD CELL [ 1.47] V                                                                                                                                                             |  |                 |  |




## 11.8.2.3 LOAD-LESS ADJUSTMENT &amp; SOME LOAD ADJUSTMENT

**LOAD-LESS ADJUSTMENT.....** When this item is selected, tare weight component, including boom weight can be adjusted. Select this item if the actual load is not identical to the displayed load when a light load weighing as same as the hook block is lifted.

**SOME LOAD ADJUSTMENT.....** When this item is selected, load component can be adjusted. Select this item, if error that occurs when a heavy load is lifted is greater than that occurs when a light load weighing as same as the hook block is lifted.

When "LOAD LESS ADJUSTMENT" is selected, the following screen appears.






You place a load onto a hook. Push SET after you check a number inside the parentheses with the hook weight with

1.1. 01F0UNGS+1000

Enter the weight of the hook block.

The current lifted load must be the load of the hook block only.

Adjust the value in [ ] to the weight of hook block. The entered value is decreased with the  switch, and increased with the  switch.


After the adjustment, press the  switch. Then, the next screen appears.

- If the two hooks are used, enter the sum of their weights.

## 11. LOAD SAFETY DEVICE

Adjust the load at the maximum boom angle point, minimum boom angle point, and arbitrary five points between them. To start the adjustment, stop the boom at an arbitrary point, and press the **SET** switch,

### Input point



- 1 First, raise the boom to the point near the maximum boom angle (75 deg. to 80 deg ), and press the **SET** switch

Value close to the maximum boom angle

Push SET after you make a boom or jib a maximum angle

|                       |      |              |         |
|-----------------------|------|--------------|---------|
| BOOM ID               |      |              |         |
| UD                    |      |              |         |
| A. ASG1               |      | A. S. In Cr. |         |
| 78.8%                 | 10.4 |              |         |
| P.A.M.                |      |              |         |
| BOOM ID               | 3    |              |         |
| ACTUAL LOAD           | 2.0  | POUNDS       | AT 100% |
| EXACT LOAD            | 89.2 | POUNDS       | AT 100% |
| MAX LB                | 23.0 | %            |         |
| LOAD-LESS POSITIONING |      |              |         |

The only load ever a load free BT after you check a load free the manufacturer's lift the load safety is 100%.

1. 1. of maximum load

Push SET after you make a boom or jib a maximum angle


2. Then, the load can be adjusted at zero to five points to the minimum boom angle point. Lower the boom to arbitrary points, stop it, and press the **SET** switch.

The maximum and minimum boom angle points are absolutely necessary for this adjustment, and five points between them can be set arbitrarily or omitted (there is no rule of the number of points, and intervals of points).

However, note that fine adjustment is possible when many points are set in the boom angle range as wide as possible.


To omit the points set arbitrarily, press the **▽** switch. Then, the message instructing to lower the boom to the minimum boom angle is displayed.

It can be adjusted in 0-5 points between the minimum angle from the maximum and a. Push SET after you make it stop in each point. Push **↓** when you exit the middle.




For example,

- When the boom is lowered to 70 deg. and stopped as the first arbitrary point, and the **SET** switch is pressed, the message informing that the first point is recorded appears.




## 11. LOAD SAFETY DEVICE

- Next, when the boom is lowered to 60 deg. and stopped as the second arbitrary point, and the **SET** switch is pressed, the message informing that the second point is recorded appears



- When the fifth points are recorded after other arbitrary points are set in similar manners, the message instructing to adjust the boom angle to the minimum and press the **SET** switch. The same message appears even when the **SET** switch is pressed to omit arbitrary points.



- When the **SET** switch is pressed after the boom is lowered to the point near the minimum angle, adjustment results are displayed

The message shown below appears if the adjustment is normally completed.

However, figures in [ ] may be changed according to situations

Adjustment went well. Push SET.

```

FO ADJUSTMENT INCLINATION K1 : 0.878]
FO ADJUSTMENT SHIFT      K2 : 0.178]

```

The screenshot shows the crane's LCD display. At the top, it displays 'LOAD LOSS ADJUSTMENT' and a table with columns 'RA' and 'RA-H'. The table contains values for 'RA-10', 'RA-15', 'RA-20', and 'RA-25'. Below the table, there is a block of Japanese text and a 'LOAD LOSS ADJUSTMENT' section with a table of values for 'RA' and 'RA-H'.

- If the adjustment is not normally completed, the message instructing of re-adjustment is displayed as shown below
- The displayed adjustment results are cancelled if this message appears

Adjustment is failure. Push SET, and adjust it again.

```

FO ADJUSTMENT INCLINATION K1 : 9.999]
FO ADJUSTMENT SHIFT      K2 : 99.999]

```

The screenshot shows the crane's LCD display. At the top, it displays 'LOAD LOSS ADJUSTMENT' and a table with columns 'RA' and 'RA-H'. The table contains values for 'RA-10', 'RA-15', 'RA-20', and 'RA-25'. Below the table, there is a block of Japanese text and a 'LOAD LOSS ADJUSTMENT' section with a table of values for 'RA' and 'RA-H'.


If the lengths of the two or more booms have been already adjusted and the length of the boom that has not been adjusted yet is used, the adjusted two lengths that are closest to it are corrected, and the adjusted length of the boom that has not been adjusted yet is calculated accordingly.

## 11. LOAD SAFETY DEVICE

### When "SOME LOAD ADJUSTMENT" is selected

Only the first procedure and the adjustment result of the "SOME LOAD ADJUSTMENT" are different from those of the "LOAD-LESS ADJUSTMENT". Other procedures and displays are identical.

- First, lift a load of which weight is already known, and adjust the displayed value in [ ] to the lifted load (lifted load includes the weights of hook block and wire rope).



Here the load which weight is understood about. Push SET after you select a number inside the parenthesis with the hook weight with + -.

Enter the lifted load.

- Adjustment procedures are identical to those of the "LOAD-LESS ADJUSTMENT".
- The adjustment results are displayed on the bottom of the screen as shown below.




& ADJUSTMENT INCLINATION K3 [ ]

& ADJUSTMENT SHIFT K4 [ ]

- Adjustment for luffing crane  
For main lifting, adjust in a similar manner shown 11.6.2.3 LOAD-LESS ADJUSTMENT & SOME LOAD ADJUSTMENT.  
For jib lifting, fix the boom angle, and adjust by modifying the jib angle in a similar manner shown 11.6.2.3 LOAD-LESS ADJUSTMENT & SOME LOAD ADJUSTMENT.

### 11.6.2.4 LVL ADJUSTMENT (LVL SETTING)

LVL means the level of moment ratio that the machine is automatically stopped and the alarm is issued. It is usually set at 100%, and can be altered in the range from 90 to 110%.

- Increase or decrease the LVL with the  or  switch to the intended value, and press the  switch


#### Note

LVL adjustment is available only while the dip switch No 5 is in the "ON" status. When it is in the "OFF" status, the moment ratio level that the machine is automatically stopped and the alarm is issued is set to 105% as usual.

Set up the load rate which makes it stop automatically.  
It can be set up in 90-110% of the ranges.

[100] %

← → : Increase or Decrease  
SET : Setting completion




## 11. LOAD SAFETY DEVICE

### LVL Function

The following drawings are some examples of LVL function.


#### 1. When the LVL function is OFF.



If the loading ratio is 105% or more while the LVL function is not actuated, operation toward the hazardous side is automatically stopped. Note that hysteresis of 5% must be considered for restoration from the automatic stop status. When the loading ratio is returned to 100%, the automatic stop status is cancelled.

When the loading ratio is 90% or more, intermittent alarm sounds are emitted. Continuous alarm sounds are emitted when the loading ratio is 100% or more.


#### 2. When the LVL function is ON and set to 90%.



If the loading ratio is 90% or more, operation toward the hazardous side is automatically stopped. The machine is restored from the automatic stop status when the loading ratio is less than 85%. When the loading ratio is 90%, continuous alarm sounds are emitted. No forecasting sound (intermittent sound) will be emitted.



3. When the LVL function is ON and set to 110%.



When LVL is set at 110%, the figure above applies.

Please note the following points.

- LVL is also affected by the work area limit parameters. It operates by referencing the smaller value set by the Load Setting switch in "Setting the Work Area Limit Values".
- The LVL operational lag (hysteresis) is -5%.
- The load ratio is not affected by LVL function.
- When the loading ratio is 90%, forecasting sounds (intermittent sounds) are emitted. Alarm sounds (continuous sounds) are emitted when the loading ratio is 100% (not affected by the LVL function).


## 11. LOAD SAFETY DEVICE

### 11.6.2.5 RADIUS ADJUSTMENT

When the deflection of the boom causes the difference between the indicated radius and the actual radius, perform this adjustment.


1. Adjust the boom angle close to the maximum angle.

Move the cursor  onto the "RADIUS ADJUST-


MENT", and press the  switch. Then, the screen shown below appears.

Fit I to the actual working radius with  $\leftarrow$  +, and push SET.


[ 37. 0] ft



Measure the actual radius with a measuring tape, and


enter it in the [ ] on the screen, and press the  switch.

2. Adjust the boom angle close to the minimum angle


and press the  switch. Then, the screen shown below appears.


Push SET after you make a radius change.  
Fit II to the actual working radius with  $\leftarrow$  +, and push SET.

[ 71. 9] ft




Measure the actual radius with a measuring tape, and

enter it in the [ ] on the screen, and press the  switch.

- When the adjustment is successfully completed, the screen shown below appears. To return to the previous screen, press the  switch.

Adjustment successful. Push SET.

RADIUS ADJUSTMENT INCLINATION [ 1. 003]  
 RADIUS ADJUSTMENT SHIFT [ 0. 696]



- If the adjustment is failed, the messages shown below appear. In such a case, retry it.


Adjustment is failure. Push SET, and adjust again.  
 RADIUS ADJUSTMENT INCLINATION [1.003]  
 RADIUS ADJUSTMENT SHIFT [-9.999]

## 11. LOAD SAFETY DEVICE


### 11.6.3 LOAD ADJUSTMENT

Perform the user adjustment only when the load detector should be temporarily adjusted if it is faulty and the indicated load differs from the actual load. In this adjustment, no limitation is provided for the adjustment values. If the setup of the crane status is altered, the adjustment values are deleted, and they are returned to operation based on the adjustment values provided by manufactures. This adjustment should be used as the temporary measure for emergency.

1. When the dip switch No.3 of the controller is turned on, selection items for the "Adjustment" appear on the screen.




CK SERIES




CKE SERIES


2. When the cursor is moved onto the "Adjustment" and the **SET** switch is pressed, the screen shown below appears



3. When the cursor is moved onto the "Load adjustment" and the **SEL** switch is pressed, the screen shown below appears.



4. When the **SF** switch is pressed next, the screen shown below appears. Procedures of "LOAD-LESS ADJUSTMENT" and "SOME LOAD ADJUSTMENT" are the same as those of the "Manufacturers adjustment".




## 11. LOAD SAFETY DEVICE

### 11.6.4 ADJUSTMENT DATA COPY (INITIALIZATION)


The manufacture adjustment values are stored in the flash memory in the controller, and used for actual operation. They can be copied down into the data card in case of disorder of the controller.

Even if a controller is replaced with a new controller, re-adjustment is unnecessary if the copied data of adjustment values in the used data card are written on the new controller.



- 1 Turn the dip switch No.3 ON. Then, the "ADJUSTMENT DATA" is added to the menus and displayed.



CK SERIES



CKE SERIES

Move the cursor  onto the "ADJUSTMENT DATA", and press the  switch. Then, the screen shown below appears.

|                                |  |                                       |  |  |  |  |  |  |  |                                                              |  |  |  |  |  |  |  |  |  |              |  |
|--------------------------------|--|---------------------------------------|--|--|--|--|--|--|--|--------------------------------------------------------------|--|--|--|--|--|--|--|--|--|--------------|--|
| RATIO (%)                      |  | [Progressive bar graph from 0 to 100] |  |  |  |  |  |  |  |                                                              |  |  |  |  |  |  |  |  |  |              |  |
| 9 ANGLE                        |  |                                       |  |  |  |  |  |  |  | 9 P ELEV.                                                    |  |  |  |  |  |  |  |  |  |              |  |
| d <sub>sp</sub>                |  |                                       |  |  |  |  |  |  |  | ft                                                           |  |  |  |  |  |  |  |  |  |              |  |
| RATIO                          |  |                                       |  |  |  |  |  |  |  | MAIN                                                         |  |  |  |  |  |  |  |  |  | N            |  |
| ACTUAL LOAD                    |  |                                       |  |  |  |  |  |  |  |                                                              |  |  |  |  |  |  |  |  |  | POUNDS #1000 |  |
| RATED LOAD                     |  |                                       |  |  |  |  |  |  |  |                                                              |  |  |  |  |  |  |  |  |  | POUNDS #1000 |  |
| RADIUS                         |  |                                       |  |  |  |  |  |  |  |                                                              |  |  |  |  |  |  |  |  |  | ft           |  |
| ADJUSTMENT DATA                |  |                                       |  |  |  |  |  |  |  |                                                              |  |  |  |  |  |  |  |  |  |              |  |
| READING OF THE ADJUSTMENT DATA |  |                                       |  |  |  |  |  |  |  | It is read out after the fraction and old vs new is read!    |  |  |  |  |  |  |  |  |  |              |  |
| WRITING OF THE ADJUSTMENT DATA |  |                                       |  |  |  |  |  |  |  |                                                              |  |  |  |  |  |  |  |  |  |              |  |
| ADJUSTMENT DATA INITIALIZATION |  |                                       |  |  |  |  |  |  |  | It is initialized after the fraction and old vs new is read! |  |  |  |  |  |  |  |  |  |              |  |
| ↑ ↓ : Choice                   |  |                                       |  |  |  |  |  |  |  |                                                              |  |  |  |  |  |  |  |  |  |              |  |
| SET : To the choice screen     |  |                                       |  |  |  |  |  |  |  |                                                              |  |  |  |  |  |  |  |  |  |              |  |

Following three functions are available :

|                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| READING OF THE<br>ADJUSTMENT DATA | This command allows transmission of all the adjustment values in the original data card after the controller is replaced with a new one. Copied data in the data card can be read out and written into the flash memory in the controller. When this item is selected data of adjustment values stored in the flash memory are erased and replaced with new data. Ensure that the stored data may be replaced with new data before selecting this item. |
| WRITING OF THE<br>ADJUSTMENT DATA | This command allows backup of all the adjustment values in the controller into a new data card after the old data card is replaced with a new one. Data of adjustment values in the flash memory can be copied in the data card. They usually are copied automatically when any adjustment is performed. Select this item when you need to copy them in other cases.                                                                                    |
| ADJUSTMENT DATA<br>INITIALIZATION | Data of adjustment values in the flash memory can be initialized.                                                                                                                                                                                                                                                                                                                                                                                       |


## 11. LOAD SAFETY DEVICE

### 11.5.4.1 READING OF THE ADJUSTMENT DATA

Move the cursor  $\rightarrow$  onto the "READING OF THE ADJUSTMENT DATA", and press the  $\boxed{\text{ENT}}$  switch. Then, the screen shown below appears.

Copy data in the memory card are written inside the controller. Data until now are erased because it is replaced in the inside data of the controller after the practice.

Push  $\downarrow$  if you carry it out. And, push MENU if you stop it. (Keep pushing  $\downarrow$  for more than three seconds.)



To execute this job, press and hold the  $\boxed{\downarrow}$  switch for three seconds or longer. To cancel it, press the  $\boxed{\text{MENU}}$  switch.

When this job is successfully completed, the screen shown below appears.

To return to the previous screen, press the  $\boxed{\text{SET}}$  switch.


Copy data in the memory card are written inside the controller. Data until now are erased because it is replaced in the inside data of the controller after the practice.

Push  $\downarrow$  if you carry it out. And, push MENU if you stop it. (Keep pushing  $\downarrow$  for more than three seconds.)

An adjustment data area is being loaded up.  
It is beginning to read adjustment data.

**It is being transferred to the memory.**  
It is being kept in the flash memory.

It was completed. Push SET.






If error messages shown below appear on the screen after the execution of this job, the data card may not be fully inserted. In such a case, make sure that the card is securely inserted, and then, retry the execution.

Copy data in the memory card are written inside the controller. Data until now are erased because it is replaced in the inside data of the controller after the practice.

Push ↓ if you carry it out Ans. push MENU if you stop it. (Keep pushing ↓ for more than three seconds.)

An adjustment data area is being locked up.

**Adjustment data area reference error.**



## 11. LOAD SAFETY DEVICE

### 11.6.4.2 WRITING OF ADJUSTMENT DATA

Move the cursor  $\rightarrow$  onto the "WRITING OF THE ADJUSTMENT DATA", and press the  $\boxed{\text{SET}}$  switch. Then, the screen shown below appears

Data inside the controller are copied on the memory card.  
Push  $\downarrow$  if you carry it out. And, push MENU if you stop  
it. (Keep pushing  $\downarrow$  for more than three seconds.)

To execute this job, press and hold the  $\boxed{\downarrow}$  switch for three seconds or longer. To cancel it, press the  $\boxed{\text{MENU}}$  switch. The previous screen appears.

When this job is successfully completed, the screen shown below appears.

To return to the previous screen, press the  $\boxed{\text{SET}}$  switch.

It was completed. Push SET


If **error** messages similar to those on the screen of the "WRITING OF THE ADJUSTMENT DATA", make sure that the card is securely inserted, and then, retry the execution.

11.6.4.3 INITIALIZATION OF ADJUSTMENT DATA

Move the cursor > onto the "ADJUSTMENT DATA

INITIALIZATION", and press the **SET** switch. Then the screen shown below appears.

All adjustment data inside the controller are initialized. All the adjustment data until now are erased after the practice.  
 Push ↓ if you carry it out. And, push MENU if you stop it. (Keep pushing ↓ for more than three seconds.)




To execute this job, press and hold the **↓** switch for three seconds or longer. To cancel it, press the **MENU** switch. The previous screen appears.

When this job is successfully completed, the screen shown below appears.

To return to the previous screen, press the **SET** switch.

All adjustment data inside the controller are initialized. All the adjustment data until now are erased after the practice.  
 Push ↓ if you carry it out. And, push MENU if you stop it. (Keep pushing ↓ for more than three seconds.)  
 During the data elimination,





It was completed. Push SET

## 11. LOAD SAFETY DEVICE


### 11.6.5 VERSION CHECK

Versions of "indication program" "control program", and "data" can be displayed by the step shown below.

When both the  and  switches are pressed for three seconds or longer at a time, display of versions is started.

The previous screen reappears when they are released.

(Version screen can be accessed from any screen.)



\* Versions and P/No. shown in the left figure are some example. Actually displayed versions may differ from them.

## 11.7 ERROR CODE (ABNORMALITY DETECTION) AND COUNTERMEASURES

When an abnormality is detected, error messages are displayed in the message display window. Some abnormalities may cause lamp displays too. The machine will stop and a steady alarm sound comes on. The auto-stop mechanism can be bypassed by using the Overhoist Release switch, but the alarm sound will continue

- Status display (1/2)

| Message (CK series)                                  | CODE (CKE series) | Buzzer     | Display conditions (machine status)                                            |
|------------------------------------------------------|-------------------|------------|--------------------------------------------------------------------------------|
| (1) Out of angle.                                    | (J001)            | Peep       | Out of capacity set range                                                      |
| (2) Stop by the hook overhoist is canceled           | (J002)            | -          | The hook overhoist automatic stop release switch is actuated.                  |
| (3) Stop by the boom/jib overhoist is canceled.      | (J003)            |            | Input from the boom/jib raising stop cancel switch is detected.                |
| (4) Stop by the overload is canceled.                | (J004)            |            | Overload status is canceled.                                                   |
| (5) Overload condition                               | (J005)            | Beep       | The loading ratio exceeds the specified level.                                 |
| (6) Head wind is strong.                             | (J006)            | -          | The head wind load alarm is issued                                             |
| (7) Boom is lowered too much.                        | (J007)            | Beep       | The boom is out of the maximum working radius area                             |
| (8) Boom is raised too much.                         | (J008)            | Peep       | The boom is out of the minimum working radius area                             |
| (9) Jib is lowered too much.                         | (J009)            | Beep       | The jib is out of the maximum working radius range.                            |
| (10) Jib is raised too much.                         | (J010)            | Peep       | The jib is within the minimum working radius range.                            |
| (11) Boom is lowered too much.                       | (J011)            | Beep       | The main boom angle is smaller than the lower limit.                           |
| (12) Boom is raised too much.                        | (J012)            | Peep       | The main boom angle exceeds the upper limit.                                   |
| (13) Jib is lowered too much.                        | (J013)            | Beep       | The jib offset angle exceeds the upper limit.                                  |
| (14) Jib is raised too much.                         | (J014)            | Peep       | The jib offset angle is smaller than the lower limit.                          |
| (17) Hook overhoist.                                 | (J017)            | Peep       | The main hook overhoist limit switch is actuated.                              |
| (18) Hook overhoist.                                 | (J018)            | Peep       | The aux. hook overhoist limit switch is actuated.                              |
| (21) Boom overhoist.                                 | (J021)            | Peep       | The boom overhoist limit switch (boom foot, backstop No. 1) is actuated.       |
| (22) Jib overhoist                                   | (J022)            | Peep       | The jib overhoist limit switch is activated.                                   |
| (24) Overload forecast.                              | (J024)            | Beep, Beep | Loading ratio is 90% or more, and lower than the specified level.              |
| (25) Reached the setup value of the load limitation. | (J025)            | Beep       | Lifting load exceeds the lifting load limit value set by operator              |
| (26) Reached 90% of the load limitation value.       | (J026)            | Beep, Beep | Lifting load exceeds 90% of the lifting load limit value set by operator.      |
| (27) Boom angle reached upper limitation value.      | (J027)            | Peep       | The boom reaches the boom angle upper limit point (stop point) set by operator |
| (28) Boom angle reached lower limitation value.      | (J028)            | Peep       | The boom reaches the boom angle lower limit point (stop point) set by operator |
| (29) Jib angle reached upper limitation value        | (J029)            | Peep       | The jib reaches the jib angle upper limit point (stop point) set by operator   |

## 11. LOAD SAFETY DEVICE

### • Status display (2/2)

| Message (CK Series)                                 | CODE (CKE series) | Buzzer | Display conditions (machine statuses)                                         |
|-----------------------------------------------------|-------------------|--------|-------------------------------------------------------------------------------|
| (30) Jib angle reached lower limitation value.      | (J030)            | Peep-  | The jib reaches the jib angle lower limit point (stop point) set by operator. |
| (31) Working radius reached limitation value.       | (J031)            | Peep-  | The boom reaches the working radius limit point (stop point) set by operator. |
| (32) Boom point elevation reached limitation value. | (J032)            | Peep-  | The boom reaches the boom height limit point (stop point) set by operator.    |
| (33) Jib point elevation reached limitation value.  | (J033)            | Peep-  | The jib height reaches the limit value (stop point) preset by the operator.   |
| (56) Check mode (Overload condition)                | (J056)            | Beep-  | In the overload check mode.                                                   |
| (60) Boom overhoist                                 | (J060)            | Peep-  | The boom overhoist limit switch (second backstop) is activated.               |

When any fault occurs, the corresponding error message is displayed on the message display. If any error code for the load detector and the boom angle detector is issued, the machine is automatically stopped, and the buzzer sounds are emitted. Note that cancellation by using the release switch of the load safety device is enabled.

### • Error message

| Detected fault                                                                  | Required condition of detection                                                                                                          | Message contents (CK series)          | CODE (CKE series) | Alarm sound |
|---------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------|-------------------|-------------|
| No corresponding data is present in the M/L data storage area in the controller |                                                                                                                                          | (34) Wrong code number setup          | (E034)            | Beep        |
| Faulty load detector for crane                                                  | 0.45 V or less, or 6.20 V or more                                                                                                        | (36) Faulty boom hoist load detector  | (E036)            | Beep        |
| Faulty load detector for tower                                                  | 0.45 V or less, or 6.20 V or more                                                                                                        | (38) Faulty jib hoist load detector   | (E038)            | Beep        |
| Faulty boom angle detector                                                      | 0.5 V or less                                                                                                                            | (44) Faulty lower boom angle detector | (E044)            | Beep        |
| Faulty jib angle detector                                                       | 0.5 V or less                                                                                                                            | (47) Faulty lower jib angle detector  | (E047)            | Beep        |
| Communication data cannot be received from the total controller                 | 1. It takes for five seconds or more from the receipt of STX to that of the next STX.<br>2. BCC faults occur for ten times continuously. | (57) Faulty communication             | (E057)            | -           |

## 11.8 CONTROL OUTPUT

### 1. Controller output signal (Type No.01)

#### STC type crane (main boom only, with aux. sheave and fixed jib) - (3-drums type)

|                        |                       |                                                     | Digital indication       |                               |                         |                            |                     |                           |               |                          |                    |                              |                     |      |      |
|------------------------|-----------------------|-----------------------------------------------------|--------------------------|-------------------------------|-------------------------|----------------------------|---------------------|---------------------------|---------------|--------------------------|--------------------|------------------------------|---------------------|------|------|
|                        |                       |                                                     | Boom angle<br>(3-digits) | Point elevation<br>(3-digits) | Jib angle<br>(3-digits) | Moment ratio<br>(3-digits) |                     | Actual load<br>(3-digits) |               | Rated load<br>(3-digits) |                    | Working radius<br>(4-digits) |                     |      |      |
|                        |                       |                                                     |                          |                               |                         | * CK series only           |                     | Main                      | Aux.          | Main                     | Aux.               | Main                         | Aux.                | Main | Aux. |
|                        |                       |                                                     |                          |                               |                         | Main                       | Aux.                |                           |               |                          |                    |                              |                     |      |      |
| Power OFF              |                       |                                                     | —                        | Not indicated                 | —                       | Not indicated              | Not indicated       | Not indicated             | Not indicated | Not indicated            | Not indicated      | Not indicated                | Not indicated       |      |      |
| Allowable working area |                       |                                                     | 01                       | Indicated                     | Indicated               | Indicated                  | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated           |      |      |
| Load                   | Main/Aux. single mode | Overload prenotice                                  | 11                       | Indicated                     | Indicated               | —                          | Indicated in yellow | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated           |      |      |
|                        |                       | Overload                                            | 12                       | Indicated                     | Indicated               | —                          | Indicated in red    | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated           |      |      |
|                        |                       | Main hook max. load set point (area limitation)     | 19                       | Indicated                     | Indicated               | —                          | Indicated in red    | Indicated                 | Indicated     | Indicated in green       | Indicated          | Indicated                    | Indicated           |      |      |
|                        |                       | Aux. hook max. load set point (area limitation)     | 20                       | Indicated                     | Indicated               | —                          | Indicated           | Indicated in red          | Indicated     | Indicated                | Indicated in green | Indicated                    | Indicated           |      |      |
|                        |                       | Boom over-lowering                                  | 31                       | Indicated in red              | Indicated               | —                          | ---                 | ---                       | ---           | 0.0                      | 0.0                | Indicated in red             | Indicated in red    |      |      |
|                        |                       | Boom over-raising                                   | 32                       | Indicated in red              | Indicated               | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated           |      |      |
| Radius                 |                       | Main hook radius excess (area limitation prenotice) | 33                       | Indicated                     | Indicated               | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated in yellow          | Indicated           |      |      |
|                        |                       | Main hook radius excess (area limitation alarm)     | 34                       | Indicated                     | Indicated               | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated in yellow          | Indicated           |      |      |
|                        |                       | Aux. hook radius excess (area limitation prenotice) | 35                       | Indicated                     | Indicated               | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated in yellow |      |      |
|                        |                       | Aux. hook radius excess (area limitation alarm)     | 36                       | Indicated                     | Indicated               | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated in yellow |      |      |
| Angle                  |                       | Boom over-lowering (area limitation prenotice)      | 41                       | Indicated in yellow           | Indicated               | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated           |      |      |
|                        |                       | Boom over-lowering (area limitation alarm)          | 42                       | Indicated in yellow           | Indicated               | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated           |      |      |
|                        |                       | Boom over-raising (area limitation prenotice)       | 43                       | Indicated in yellow           | Indicated               | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated           |      |      |
|                        |                       | Boom over-raising (area limitation alarm)           | 44                       | Indicated in yellow           | Indicated               | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated           |      |      |
| Elevation              |                       | Point elevation (area limitation prenotice)         | 61                       | Indicated in yellow           | Indicated in yellow     | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated           |      |      |
|                        |                       | Point elevation (area limitation alarm)             | 62                       | Indicated in yellow           | Indicated in yellow     | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated           |      |      |
| Limit switch           |                       | Main hook overhoist                                 | 71                       | Indicated                     | Indicated               | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated           |      |      |
|                        |                       | Aux. hook overhoist                                 | 72                       | Indicated                     | Indicated               | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated           |      |      |
|                        |                       | Boom overhoist                                      | 74                       | Indicated in red              | Indicated               | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated in red             | Indicated in red    |      |      |
|                        |                       | Jib overhoist                                       | 75                       | Indicated                     | Indicated               | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated in red             | Indicated in red    |      |      |
| Others                 |                       | Head wind alarm                                     | 81                       | Indicated                     | Indicated               | —                          | Indicated           | Indicated                 | Indicated     | Indicated                | Indicated          | Indicated                    | Indicated           |      |      |
|                        |                       | Attachment self-standing and stowing                | 91                       | Indicated                     | Indicated               | —                          | ---                 | ---                       | ---           | 0.0                      | 0.0                | Indicated                    | Indicated           |      |      |
|                        |                       | Attachment assembly and disassembly                 | 92                       | Indicated                     | Indicated               | —                          | ---                 | ---                       | ---           | ---                      | ---                | ---                          | ---                 |      |      |

# 11. LOAD SAFETY DEVICE

|                        |                                                     | Code               | Whole moment ratio (bar indication)<br>(3-digits) | Mode indication     |                  | Alarm output |              |                         |                         |                         |   |   |
|------------------------|-----------------------------------------------------|--------------------|---------------------------------------------------|---------------------|------------------|--------------|--------------|-------------------------|-------------------------|-------------------------|---|---|
|                        |                                                     |                    |                                                   | Main                | Aux.             | Alarm output |              |                         | Alarm output conditions | Alarm cancel conditions |   |   |
|                        |                                                     |                    |                                                   |                     |                  | Alarm sounds | Messages     | Voice alarms            |                         |                         |   |   |
| Over-load              | Over-rost                                           | Over-load          | Over-rost                                         | Over-load           | Over-rost        | Messages     | Voice alarms | Alarm output conditions | Alarm cancel conditions |                         |   |   |
| Power OFF              | —                                                   | Not indicated      | Not indicated                                     | Not indicated       | Not issued       | Not issued   | —            | —                       | —                       | —                       |   |   |
| Allowable working area | 01                                                  | Indicated          | Indicated                                         | Indicated           | Not issued       | Not issued   | —            | —                       | —                       | —                       |   |   |
| Load                   | Main/Aux. single mode                               | Overload prenotice | 11                                                | Indicated in yellow | Indicated        | Indicated    | Intermittent | —                       | (24)                    | 11                      | K | B |
|                        |                                                     | Overload           | 12                                                | Indicated in red    | Indicated        | Indicated    | Continuous   | —                       | (5)                     | 2                       | L | C |
|                        | Main hook max. load set point (area limitation)     | 19                 | Indicated                                         | Indicated           | Indicated        | Intermittent | —            | (5)                     | 2                       | L                       | C |   |
|                        | Aux. hook max. load set point (area limitation)     | 20                 | Indicated                                         | Indicated           | Indicated        | Intermittent | —            | (5)                     | 2                       | L                       | C |   |
| Radius                 | Boom over-lowering                                  | 31                 | Entirely indicated in red                         | Indicated           | Indicated        | Continuous   | —            | (7)                     | 4                       | N                       | D |   |
|                        | Boom over-raising                                   | 32                 | Indicated                                         | Indicated           | Indicated        | —            | Continuous   | (8)                     | 5                       | M                       | D |   |
|                        | Main hook radius excess (area limitation prenotice) | 33                 | Indicated                                         | Indicated           | Indicated        | —            | Intermittent | —                       | —                       | M                       | J |   |
|                        | Main hook radius excess (area limitation alarm)     | 34                 | Indicated                                         | Indicated           | Indicated        | —            | Continuous   | (31)                    | 14                      | M                       | J |   |
|                        | Aux. hook radius excess (area limitation prenotice) | 35                 | Indicated                                         | Indicated           | Indicated        | —            | Intermittent | —                       | —                       | M                       | J |   |
|                        | Aux. hook radius excess (area limitation alarm)     | 36                 | Indicated                                         | Indicated           | Indicated        | —            | Continuous   | (31)                    | 14                      | M                       | J |   |
| Angle                  | Boom over-lowering (area limitation prenotice)      | 41                 | Indicated                                         | Indicated           | Indicated        | —            | Intermittent | —                       | —                       | M                       | D |   |
|                        | Boom over-lowering (area limitation alarm)          | 42                 | Indicated                                         | Indicated           | Indicated        | —            | Continuous   | (28)                    | 13                      | M                       | D |   |
|                        | Boom over-raising (area limitation prenotice)       | 43                 | Indicated                                         | Indicated           | Indicated        | —            | Intermittent | —                       | —                       | M                       | D |   |
|                        | Boom over-raising (area limitation alarm)           | 44                 | Indicated                                         | Indicated           | Indicated        | —            | Continuous   | (27)                    | 13                      | M                       | D |   |
| Elevation              | Point elevation (area limitation prenotice)         | 61                 | Indicated                                         | Indicated           | Indicated        | —            | Intermittent | —                       | —                       | M                       | J |   |
|                        | Point elevation (area limitation alarm)             | 62                 | Indicated                                         | Indicated           | Indicated        | —            | Continuous   | (32)                    | 15                      | M                       | J |   |
| Limit switch           | Main hook overhoist                                 | 71                 | Indicated                                         | Indicated in red    | Indicated in red | —            | Continuous   | (17)                    | 10                      | P                       | A |   |
|                        | Aux. hook overhoist                                 | 72                 | Indicated                                         | Indicated in red    | Indicated in red | —            | Continuous   | (18)                    | 10                      | P                       | A |   |
|                        | Boom overhoist                                      | 74                 | Indicated                                         | Indicated           | Indicated        | —            | Continuous   | (21)                    | 5                       | Q                       | A |   |
|                        | Jib overhoist                                       | 75                 | Indicated                                         | Indicated           | Indicated        | —            | Continuous   | (23)                    | 10                      | Q                       | A |   |
| Others                 | Head wind alarm                                     | 81                 | Indicated                                         | Indicated           | Indicated        | —            | —            | (6)                     | 3                       | —                       | — |   |
|                        | Attachment self-standing and slowing                | 91                 | Entirely indicated in red                         | Indicated           | Indicated        | —            | —            | (1)                     | —                       | —                       | — |   |
|                        | Attachment assembly and disassembly                 | 92                 | —                                                 | —                   | —                | Not issued   | Not issued   | —                       | —                       | —                       | — |   |



|                        |                                                      |                     | Crane control output |           |             |              |         |     |           |   | External indicator output                               |                         |               |                   |              |
|------------------------|------------------------------------------------------|---------------------|----------------------|-----------|-------------|--------------|---------|-----|-----------|---|---------------------------------------------------------|-------------------------|---------------|-------------------|--------------|
|                        |                                                      |                     | Automatic stop       |           |             |              |         |     |           |   | Conditions required for restoration from automatic stop |                         | <90%<br>Green | 90%<LVL<br>Yellow | LVL ≤<br>Red |
|                        |                                                      |                     | Winch 1              |           | Winch 2     |              | Winch 3 |     | Raising 1 |   | Restriction                                             | Compulsory cancellation |               |                   |              |
|                        |                                                      |                     | Main winch           | Aux winch | Third winch | Boom raising |         | Up  | Down      |   |                                                         |                         |               |                   |              |
|                        |                                                      |                     | Up                   | Down      | Up          | Up           | Down    |     |           |   |                                                         |                         |               |                   |              |
| Power OFF              |                                                      |                     | —                    | OFF       | OFF         | OFF          | OFF     | OFF | —         | — | OFF                                                     | OFF                     | OFF           |                   |              |
| Allowable working area |                                                      |                     | 01                   | ON        | ON          | ON           | ON      | ON  | —         | — | ON                                                      | OFF                     | OFF           |                   |              |
| Load                   | Main/Aux. single mode                                | Overload prevention | 11                   | —         | —           | —            | —       | —   | —         | — | OFF                                                     | ON                      | OFF           |                   |              |
|                        |                                                      | Overload            | 12                   | OFF       | OFF         | ON           | OFF     | ON  | OFF       | F | Z                                                       | OFF                     | OFF           | ON                |              |
|                        | Main hook max. load set point (area limitation)      |                     | 19                   | OFF       | OFF         | ON           | OFF     | ON  | OFF       | F | Z                                                       | OFF                     | OFF           | ON                |              |
|                        | Aux. hook max. load set point (area limitation)      |                     | 20                   | OFF       | OFF         | ON           | OFF     | ON  | OFF       | F | Z                                                       | OFF                     | OFF           | ON                |              |
| Radius                 | Boom over-lowering                                   |                     | 31                   | OFF       | OFF         | ON           | OFF     | ON  | OFF       | D | Z                                                       | —                       | —             |                   |              |
|                        | Boom over-raising                                    |                     | 32                   | —         | —           | —            | —       | OFF | ON        | D | T                                                       | —                       | —             |                   |              |
|                        | Main hook radius excess (area limitation prevention) |                     | 33                   | —         | —           | —            | —       | —   | —         | — | —                                                       | —                       | —             |                   |              |
|                        | Main hook radius excess (area limitation alarm)      |                     | 34                   | —         | —           | —            | —       | —   | OFF       | J | Z                                                       | —                       | —             |                   |              |
|                        | Aux. hook radius excess (area limitation prevention) |                     | 35                   | —         | —           | —            | —       | —   | —         | — | —                                                       | —                       | —             |                   |              |
|                        | Aux. hook radius excess (area limitation alarm)      |                     | 36                   | —         | —           | —            | —       | —   | OFF       | J | Z                                                       | —                       | —             |                   |              |
| Angle                  | Boom over-lowering (area limitation prevention)      |                     | 41                   | —         | —           | —            | —       | —   | —         | — | —                                                       | —                       | —             |                   |              |
|                        | Boom over-lowering (area limitation alarm)           |                     | 42                   | —         | —           | —            | —       | —   | OFF       | D | Z                                                       | —                       | —             |                   |              |
|                        | Boom over-raising (area limitation prevention)       |                     | 43                   | —         | —           | —            | —       | —   | —         | — | —                                                       | —                       | —             |                   |              |
|                        | Boom over-raising (area limitation alarm)            |                     | 44                   | —         | —           | —            | —       | OFF | —         | D | Z                                                       | —                       | —             |                   |              |
| Elevation              | Point elevation (area limitation prevention)         |                     | 61                   | —         | —           | —            | —       | —   | —         | — | —                                                       | —                       | —             |                   |              |
|                        | Point elevation (area limitation alarm)              |                     | 62                   | —         | —           | —            | —       | OFF | —         | J | Z                                                       | —                       | —             |                   |              |
| Limit switch           | Main hook hook overhoist                             |                     | 71                   | OFF       | OFF         | ON           | OFF     | ON  | OFF       | A | S                                                       | —                       | —             |                   |              |
|                        | Aux. hook hook overhoist                             |                     | 72                   | OFF       | OFF         | ON           | OFF     | ON  | OFF       | A | S                                                       | —                       | —             |                   |              |
|                        | Boom overhoist                                       |                     | 74                   | OFF       | OFF         | ON           | OFF     | OFF | ON        | A | R                                                       | —                       | —             |                   |              |
|                        | Jib overhoist                                        |                     | 75                   | ON        | OFF         | ON           | ON      | ON  | OFF       | A | R                                                       | —                       | —             |                   |              |
| Others                 | Head wind alarm                                      |                     | 81                   | —         | —           | —            | —       | —   | —         | — | —                                                       | ON                      | OFF           | OFF               |              |
|                        | Attachment self-standing and stowing                 |                     | 91                   | (ON)      | (ON)        | ON           | (ON)    | ON  | ON        | A | S                                                       | OFF                     | OFF           | ON                |              |
|                        | Attachment assembly and disassembly                  |                     | 92                   | ON        | ON          | ON           | ON      | ON  | ON        | — | —                                                       | OFF                     | OFF           | ON                |              |

## 11. LOAD SAFETY DEVICE

---

### Notes

- (1) Symbols "-" shown on the columns of alarm sounds, crane control output, and external indication output in the table above indicate that the corresponding items are not the subjects of control.
- (2) In the columns of the crane control output (automatic stop) and external indication output, "OFF" indicates the stop status, and "ON" indicates the operable status.
- (3) In respect of automatic stop, priority is given in the following order : condition No.92, 71 to 75, 91, 01 to 62 (except for 81).
- (4) Point elevation is indicated only when the indication is requested on the setting screen.

### Details of alarm and automatic stop condition symbols

- (a) When the status is cancelled, the machine immediately restores automatically.
- (b) When the moment ratio is decreased to 89.5%, the status is cancelled (automatically restored).
- (c) When the moment ratio is decreased by 0.5% from the overload automatic start point, the status is cancelled (automatically restored).
- (d) When the boom is returned to the safety side by 0.4 deg. or more from the limit angle, the status is cancelled (automatically restored).
- (e) When the boom is returned to the safety side by 2.0 deg. or more from the limit angle, the status is cancelled (automatically restored).
- (f) When the moment ratio is decreased by 5.0% from the overload automatic stop point, the status is cancelled (automatically restored).
- (g) Blank
- (h) Blank
- (i) Blank
- (j) When the radius or elevation is returned by 0.1 m (0.1 feet) to the safety side from the prenotice set radius or height, the status is cancelled (automatically restored).
- (k) Alarm is issued when the moment ratio is 90% or more.
- (l) Alarm is issued when the moment ratio exceeds the LVL.
- (m) Alarm is issued when the set values are exceeded and the machine is operated in hazardous directions.
- (n) Alarm is issued when the boom angle exceeds the limit angle.

- (o) Blank
- (p) Alarm is issued when overhoist occurs and the machine is operated in hazardous directions
- (q) Alarm is issued when overhoist occurs
- (r) The status cannot be cancelled whatever cancel switch is operated.
- (s) Automatic stop is cancelled only while the hook overhoist cancel switch is operated.
- (t) Automatic stop is cancelled only while the boom overhoist cancel switch is operated.
- (u) Blank
- (v) Blank
- (w) Blank
- (x) Blank
- (y) Blank
- (z) Automatic stop is cancelled only while the overload cancel switch is operated.

# 11. LOAD SAFETY DEVICE

## 2. Controller output signal (Type No C3)

### Luffing crane (main, auxiliary, boom, luffing jib) - (4-drums type)

| Signal       | Description                                     | No.                 | Digital indication   |                          |                            |                     |                                          |                  |                     |
|--------------|-------------------------------------------------|---------------------|----------------------|--------------------------|----------------------------|---------------------|------------------------------------------|------------------|---------------------|
|              |                                                 |                     | Beam angle (Digital) | Beam elevation (Digital) | Jib offset angle (Digital) | Jib angle (Digital) | Moment into (Digital) (C4-circuits only) |                  |                     |
|              |                                                 |                     |                      |                          |                            |                     | Max                                      | Min              | Age                 |
| Power OFF    |                                                 | 0                   | Not indicated        | Not indicated            | Not indicated              | Not indicated       | Not indicated                            | Not indicated    | Not indicated       |
| Load         | 4-locale warning time                           | 07                  | Not indicated        | Not indicated            | Not indicated              | Not indicated       | Not indicated                            | Not indicated    | Not indicated       |
|              | Main/auxiliary crane mode                       | 11                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated in yellow                      |                  |                     |
|              |                                                 | Overload protection | 12                   | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated in red |                     |
|              | Main/auxiliary crane mode (overload protection) | 21                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated in yellow                      | Indicated        | Indicated           |
|              | Main/auxiliary crane mode (overload protection) | 22                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated in red                         | Indicated        | Indicated           |
|              | Main/auxiliary crane mode (overload protection) | 23                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated in yellow                      | Indicated        | Indicated           |
|              | Main/auxiliary crane mode (overload protection) | 24                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated in red                         | Indicated        | Indicated           |
|              | Main/auxiliary crane mode (overload protection) | 25                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated in yellow |
|              | Main/auxiliary crane mode (overload protection) | 26                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated in red    |
|              | Main/auxiliary crane mode (overload protection) | 27                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
| Radius       | Beam overloading (overload alarm)               | 31                  | Indicated in red     | Indicated                | Indicated                  | Indicated           | ---                                      | ---              | ---                 |
|              | Beam overloading (overload alarm)               | 32                  | Indicated in red     | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 33                  | Indicated            | Indicated                | Indicated                  | Indicated           | ---                                      | ---              | ---                 |
|              | Beam overloading (overload alarm)               | 34                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 35                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 36                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 37                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 38                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 39                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 40                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
| Angle        | Beam overloading (overload alarm)               | 41                  | Indicated in yellow  | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 42                  | Indicated in yellow  | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 43                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 44                  | Indicated in red     | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 45                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 46                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 47                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 48                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 49                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 50                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
| Forward      | Beam overloading (overload alarm)               | 51                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 52                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 53                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 54                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 55                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 56                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 57                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 58                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 59                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 60                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
| Limit switch | Beam overloading (overload alarm)               | 71                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 72                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 73                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 74                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
| Others       | Beam overloading (overload alarm)               | 75                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 76                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |
|              | Beam overloading (overload alarm)               | 77                  | Indicated            | Indicated                | Indicated                  | Indicated           | Indicated                                | Indicated        | Indicated           |

|                                      |                                         |                                           | Digital Indicators |               |               |                    |                     |               |                       |                  |                  |                  |                  |
|--------------------------------------|-----------------------------------------|-------------------------------------------|--------------------|---------------|---------------|--------------------|---------------------|---------------|-----------------------|------------------|------------------|------------------|------------------|
|                                      |                                         |                                           | Actual load (kg/t) |               |               | Rated load (kg/t)  |                     |               | Working status (kg/t) |                  |                  |                  |                  |
|                                      |                                         |                                           | Min                | Lim           | Max           | Min                | Lim                 | Max           | Min                   | Lim              | Max              |                  |                  |
| *Note: CEI                           |                                         |                                           | —                  | Not indicated | Not indicated | Not indicated      | Not indicated       | Not indicated | Not indicated         | Not indicated    | Not indicated    | Not indicated    | Not indicated    |
| Automatic working area               |                                         |                                           | 71                 | Not indicated | Not indicated | Not indicated      | Not indicated       | Not indicated | Not indicated         | Not indicated    | Not indicated    | Not indicated    | Not indicated    |
| Load                                 | Main hook max. load (at rated speed)    | Rated parameter                           | 71                 | Indicated     |               |                    | Indicated           |               |                       | Indicated        |                  |                  |                  |
|                                      |                                         | Overload                                  | 72                 | Indicated     |               |                    | Indicated           |               |                       | Indicated        |                  |                  |                  |
|                                      | Main hook max. load (at rated speed)    | 71                                        | Not indicated      | Not indicated | Not indicated | Indicated in green | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | Main hook max. load (at rated speed)    | 72                                        | Indicated          | Indicated     | Indicated     | Indicated in green | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | AS hook max. load (at rated speed)      | 73                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated in yellow | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | AS hook max. load (at rated speed)      | 74                                        | Not indicated      | Not indicated | Not indicated | Indicated          | Indicated in green  | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | AS hook max. load (at rated speed)      | 75                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | AS hook max. load (at rated speed)      | 76                                        | Not indicated      | Not indicated | Not indicated | Indicated          | Indicated in green  | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | Radius                                  | Boom overloading (only for main drum)     | 31                 | ---           | ---           | ---                | 0.0                 | 0.0           | 0.0                   | Indicated in red | Indicated in red | Indicated in red | Indicated in red |
|                                      |                                         | Boom low limit angle (only for main drum) | 32                 | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        | Indicated        |
| AS overloading (only for AS drum)    |                                         | 33                                        | ---                | ---           | ---           | 0.0                | 0.0                 | 0.0           | Indicated in red      | Indicated in red | Indicated in red | Indicated in red |                  |
| AS hook max. load (at rated speed)   |                                         | 34                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
| Main hook max. load (at rated speed) |                                         | 35                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated in yellow   | Indicated        | Indicated        | Indicated        |                  |
| Main hook max. load (at rated speed) |                                         | 36                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated in yellow   | Indicated        | Indicated        | Indicated        |                  |
| AS hook max. load (at rated speed)   |                                         | 37                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated in yellow   | Indicated        | Indicated        | Indicated        |                  |
| AS hook max. load (at rated speed)   |                                         | 38                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated in yellow   | Indicated        | Indicated        | Indicated        |                  |
| AS hook max. load (at rated speed)   |                                         | 39                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
| AS hook max. load (at rated speed)   |                                         | 40                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
| Angle                                | Boom overloading (only for AS drum)     | 41                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | Boom overloading (only for AS drum)     | 42                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | Boom overloading (only for AS drum)     | 43                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | Boom overloading (only for AS drum)     | 44                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | AS overloading (only for AS drum)       | 45                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | AS overloading (only for AS drum)       | 46                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | AS overloading (only for AS drum)       | 47                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | AS overloading (only for AS drum)       | 48                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | Boom low limit angle (only for AS drum) | 49                                        | Indicated          | Indicated     | Indicated     | Indicated          | 0.0                 | 0.0           | 0.0                   | Indicated        | Indicated        | Indicated        |                  |
|                                      | Boom up limit angle (only for AS drum)  | 50                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
| Lift status                          | AS hook max. load (at rated speed)      | 61                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | Main hook max. load (at rated speed)    | 62                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | Main hook max. load (at rated speed)    | 71                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | AS hook max. load (at rated speed)      | 72                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | Boom overloading (AS)                   | 73                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | Boom overloading (AS)                   | 74                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | AS overloading                          | 75                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | Boom overloading                        | 76                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | AS overloading                          | 77                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | Boom overloading                        | 78                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
| Others                               | Hoist winch stop                        | 87                                        | Indicated          | Indicated     | Indicated     | Indicated          | Indicated           | Indicated     | Indicated             | Indicated        | Indicated        | Indicated        |                  |
|                                      | Attachment self-locking and stop        | 89                                        | ---                | ---           | ---           | 0.0                | 0.0                 | 0.0           | Indicated             | Indicated        | Indicated        | Indicated        |                  |
| Attachment assembly and disassembly  |                                         |                                           | 92                 | ---           |               |                    | ---                 |               |                       | ---              |                  |                  |                  |

11. LOAD SAFETY DEVICE

|                         |                                                               |                                                               | Alarms<br>message<br>code<br>(1000000) | Alarm indication |                  |                  | Alarm output      |                       |            |                 |
|-------------------------|---------------------------------------------------------------|---------------------------------------------------------------|----------------------------------------|------------------|------------------|------------------|-------------------|-----------------------|------------|-----------------|
|                         |                                                               |                                                               |                                        | Alarm output     |                  |                  | Over load<br>stop | Over-<br>heat<br>trip | Messages   | Error<br>number |
|                         |                                                               |                                                               |                                        | Minor            | Major            | Alarm            |                   |                       |            |                 |
| Power OFF               |                                                               |                                                               | 00                                     | Not<br>indicated | Not<br>indicated | Not<br>indicated | Not<br>issued     | Not<br>issued         | —          | —               |
| Alarm (12 working stop) |                                                               |                                                               | 01                                     | Indicated        | Indicated        | Indicated        | Not issued        | Not issued            | —          | —               |
| Laser                   | Main hook max load limit point (area limitation control stop) | 02                                                            | Indicated or stopped                   | Indicated        | Indicated        | Indicated        | Intermittent      | —                     | (24)       | 11              |
|                         |                                                               | 03                                                            | Indicated or stopped                   | Indicated        | Indicated        | Indicated        | Intermittent      | —                     | (25)       | 2               |
|                         | 21                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | Intermittent     | —                 | (24)                  | 11         |                 |
|                         | 22                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | Intermittent     | —                 | (25)                  | 2          |                 |
|                         | 27                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | Intermittent     | —                 | (24)                  | 11         |                 |
| Robot                   | Main hook max load limit point (area limitation control stop) | 23                                                            | Indicated                              | Indicated        | Indicated        | Indicated        | Intermittent      | —                     | (24)       | 11              |
|                         |                                                               | 24                                                            | Indicated                              | Indicated        | Indicated        | Indicated        | Intermittent      | —                     | (25)       | 2               |
|                         | 25                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | Intermittent     | —                 | (24)                  | 11         |                 |
|                         | 26                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | Intermittent     | —                 | (25)                  | 2          |                 |
|                         | 31                                                            | Initially, not indicated in case of stop                      | Indicated                              | Indicated        | Indicated        | Intermittent     | —                 | (24)                  | 4          |                 |
|                         | 32                                                            | Initially, not indicated in case of stop                      | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (18)                  | 5          |                 |
|                         | 33                                                            | Initially, not indicated in case of stop                      | Indicated                              | Indicated        | Indicated        | Continuous       | —                 | (17)                  | 5          |                 |
|                         | 34                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (14)                  | 7          |                 |
|                         | 35                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Intermittent      | —                     | —          |                 |
|                         | 38                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (11)                  | 14         |                 |
| Angle                   | Main hook max load limit point (area limitation control stop) | 37                                                            | Indicated                              | Indicated        | Indicated        | Indicated        | Intermittent      | —                     | —          | —               |
|                         |                                                               | 38                                                            | Indicated                              | Indicated        | Indicated        | Indicated        | —                 | Continuous            | (11)       | 14              |
|                         | 39                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Intermittent      | —                     | —          |                 |
|                         | 40                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (21)                  | 14         |                 |
|                         | 41                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Intermittent      | —                     | —          |                 |
|                         | 42                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (24)                  | 13         |                 |
|                         | 43                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Intermittent      | —                     | —          |                 |
|                         | 44                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (27)                  | 13         |                 |
|                         | 45                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Intermittent      | —                     | —          |                 |
|                         | 46                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (30)                  | 13         |                 |
| At New / Limit switch   | Main hook max load limit point (area limitation control stop) | 47                                                            | Indicated                              | Indicated        | Indicated        | Indicated        | —                 | Intermittent          | —          | —               |
|                         |                                                               | 48                                                            | Indicated                              | Indicated        | Indicated        | Indicated        | —                 | Continuous            | (20)       | 13              |
|                         | 49                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Intermittent      | —                     | —          |                 |
|                         | 50                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (15)                  | 4          |                 |
|                         | 51                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (12)                  | 5          |                 |
|                         | 52                                                            | Initially, not indicated in case of stop                      | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (14)                  | 7          |                 |
|                         | 53                                                            | Initially, not indicated in case of stop                      | Indicated                              | Indicated        | Indicated        | Intermittent     | —                 | (17)                  | 6          |                 |
|                         | 61                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Intermittent      | —                     | —          |                 |
|                         | 62                                                            | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (32)                  | 15         |                 |
|                         | Others                                                        | Main hook max load limit point (area limitation control stop) | 63                                     | Indicated        | Indicated        | Indicated        | Indicated         | —                     | Continuous | (17)            |
| 64                      |                                                               |                                                               | Indicated                              | Indicated        | Indicated        | Indicated        | —                 | Continuous            | (18)       | 10              |
| 65                      |                                                               | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (21)                  | 7          |                 |
| 66                      |                                                               | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (19)                  | 5          |                 |
| 67                      |                                                               | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (22)                  | 7          |                 |
| 68                      |                                                               | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Continuous        | (33)                  | —          |                 |
| 69                      |                                                               | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | Intermittent      | (35)                  | —          |                 |
| 70                      |                                                               | Indicated                                                     | Indicated                              | Indicated        | Indicated        | —                | —                 | (16)                  | 3          |                 |
| 71                      | Initially, not indicated in case of stop                      | Indicated                                                     | Indicated                              | Indicated        | —                | —                | (11)              | —                     |            |                 |
| 72                      | —                                                             | —                                                             | —                                      | —                | Not issued       | Not issued       | —                 | —                     |            |                 |

|                                                 |                                                 |                                                 | Alarm stop 1                                    |    | Crane control stop 1 |               |         |     |      |               |      |               |     |
|-------------------------------------------------|-------------------------------------------------|-------------------------------------------------|-------------------------------------------------|----|----------------------|---------------|---------|-----|------|---------------|------|---------------|-----|
|                                                 |                                                 |                                                 |                                                 |    | Automatic stop       |               |         |     |      |               |      |               |     |
|                                                 |                                                 |                                                 |                                                 |    | Watch 1              |               | Watch 2 |     |      | Hoist-Lower 1 |      | Raising/Low 2 |     |
|                                                 |                                                 |                                                 |                                                 |    | Stop<br>watch        | Full<br>watch | Over    | Up  | Down | Up            | Down |               |     |
| Power OFF                                       |                                                 |                                                 | -                                               | -  | OFF                  | OFF           | OFF     | OFF | OFF  | OFF           | OFF  |               |     |
| At stop working stop                            | 01                                              |                                                 |                                                 |    | ON                   | ON            | ON      | ON  | ON   | ON            | ON   |               |     |
| Load                                            | Main/Aux. An-<br>tistruck mode                  | Overload protection                             | 11                                              | A  | B                    | -             | -       | -   | -    | -             | -    | -             |     |
|                                                 |                                                 | OverLoad                                        | 12                                              | -  | C                    | OFF           | OFF     | ON  | ON   | OFF           | ON   | OFF           |     |
|                                                 | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 21 | K                    | B             | -       | -   | -    | -             | -    | -             |     |
|                                                 |                                                 |                                                 | Main hook load stop (load protection structure) | 22 | -                    | C             | OFF     | OFF | ON   | ON            | OFF  | ON            | OFF |
|                                                 |                                                 |                                                 | Main hook load stop (load protection structure) | 23 | K                    | B             | -       | -   | -    | -             | -    | -             | -   |
|                                                 |                                                 |                                                 | Main hook load stop (load protection structure) | 24 | -                    | C             | OFF     | OFF | ON   | ON            | OFF  | ON            | OFF |
| Stack                                           | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 25                                              | K  | B                    | -             | -       | -   | -    | -             | -    |               |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 26                                              | -  | C                    | OFF           | OFF     | ON  | ON   | OFF           | ON   | OFF           |     |
|                                                 | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 31                                              | M  | D                    | OFF           | OFF     | ON  | ON   | OFF           | ON   | OFF           |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 32                                              | M  | D                    | ON            | ON      | ON  | OFF  | ON            | ON   | ON            |     |
|                                                 | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 33                                              | M  | D                    | OFF           | OFF     | ON  | ON   | OFF           | ON   | OFF           |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 34                                              | M  | D                    | ON            | ON      | ON  | ON   | ON            | OFF  | ON            |     |
|                                                 | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 35                                              | M  | J                    | -             | -       | -   | -    | -             | -    | -             |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 36                                              | M  | J                    | -             | -       | -   | -    | OFF           | -    | OFF           |     |
|                                                 | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 37                                              | M  | J                    | -             | -       | -   | -    | -             | -    | -             |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 38                                              | M  | J                    | -             | -       | -   | -    | -             | -    | -             |     |
| Amp                                             | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 39                                              | M  | J                    | -             | -       | -   | -    | -             | -    | -             |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 40                                              | M  | J                    | -             | -       | -   | -    | -             | -    | OFF           |     |
|                                                 | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 41                                              | M  | D                    | -             | -       | -   | -    | -             | -    | -             |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 42                                              | M  | D                    | -             | -       | -   | -    | -             | OFF  | -             |     |
|                                                 | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 43                                              | M  | D                    | -             | -       | -   | -    | -             | -    | -             |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 44                                              | M  | D                    | -             | -       | -   | OFF  | -             | -    | -             |     |
|                                                 | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 45                                              | M  | D                    | -             | -       | -   | -    | -             | -    | -             |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 46                                              | M  | D                    | -             | -       | -   | -    | -             | -    | OFF           |     |
|                                                 | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 47                                              | M  | D                    | -             | -       | -   | -    | -             | -    | -             |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 48                                              | M  | D                    | -             | -       | -   | -    | -             | -    | ON            |     |
| Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 49                                              | M                                               | D  | OFF                  | OFF           | ON      | ON  | OFF  | -             | -    |               |     |
|                                                 | Main hook load stop (load protection structure) | 50                                              | M                                               | D  | ON                   | ON            | ON      | OFF | ON   | -             | -    |               |     |
| Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 51                                              | K                                               | D  | -                    | -             | -       | ON  | ON   | ON            | ON   |               |     |
|                                                 | Main hook load stop (load protection structure) | 52                                              | K                                               | D  | OFF                  | OFF           | ON      | OFF | ON   | ON            | OFF  |               |     |
| Ladder                                          | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 53                                              | M  | J                    | -             | -       | -   | -    | -             | -    | -             |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 54                                              | M  | J                    | -             | -       | -   | OFF  | -             | ON   | -             |     |
| Ab hook:<br>structure                           | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 71                                              | F  | A                    | OFF           | OFF     | ON  | ON   | OFF           | ON   | OFF           |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 72                                              | F  | A                    | OFF           | OFF     | ON  | ON   | ON            | ON   | OFF           |     |
|                                                 | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 73                                              | D  | A                    | ON            | ON      | ON  | OFF  | ON            | ON   | ON            |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 74                                              | D  | A                    | OFF           | OFF     | ON  | OFF  | ON            | ON   | ON            |     |
|                                                 | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 75                                              | D  | A                    | OFF           | OFF     | ON  | ON   | ON            | ON   | ON            |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 76                                              | D  | A                    | OFF           | OFF     | ON  | ON   | ON            | ON   | ON            |     |
| Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 77                                              | D                                               | A  | ON                   | ON            | ON      | ON  | OFF  | OFF           | ON   |               |     |
|                                                 | Main hook load stop (load protection structure) | 78                                              | D                                               | A  | ON                   | ON            | ON      | OFF | ON   | ON            | OFF  |               |     |
| Others                                          | Main hook load stop (load protection structure) | Main hook load stop (load protection structure) | 81                                              | -  | -                    | -             | -       | -   | -    | -             | -    | -             |     |
|                                                 |                                                 | Main hook load stop (load protection structure) | 82                                              | -  | -                    | ON            | ON      | ON  | ON   | ON            | ON   | ON            |     |

# 11. LOAD SAFETY DEVICE

|                                                    | Code                                                  | Functions required for termination from a limited stop |         |                | Original activation output |        |     |    |
|----------------------------------------------------|-------------------------------------------------------|--------------------------------------------------------|---------|----------------|----------------------------|--------|-----|----|
|                                                    |                                                       | Master-Function                                        | Control |                | Green                      | Yellow | Red |    |
|                                                    |                                                       |                                                        | Control | Emergency stop |                            |        |     |    |
| Power OFF                                          |                                                       |                                                        |         | OFF            | OFF                        | OFF    |     |    |
| Always working area                                | 01                                                    |                                                        | -       | ON             | OFF                        | OFF    |     |    |
| Load                                               | Main hook load sensor (overload)                      | 11                                                     | -       | -              | OFF                        | ON     | OFF |    |
|                                                    |                                                       | 12                                                     | F       | Z              | OFF                        | OFF    | ON  |    |
|                                                    | Main hook max. load (no. of crane limitation periods) | 21                                                     | -       | -              | OFF                        | ON     | OFF |    |
|                                                    |                                                       | 22                                                     | E       | Z              | OFF                        | OFF    | ON  |    |
|                                                    | Main hook max. load (no. of crane limitation periods) | 23                                                     | -       | -              | OFF                        | ON     | OFF |    |
|                                                    |                                                       | 24                                                     | E       | Z              | OFF                        | OFF    | ON  |    |
|                                                    | Aux. hook and set point (area limitation periods)     | 25                                                     | -       | -              | OFF                        | ON     | OFF |    |
|                                                    |                                                       | 26                                                     | F       | Z              | OFF                        | OFF    | ON  |    |
|                                                    | Radius                                                | Boom overloading (only for main hook)                  | 31      | U              | Z                          | OFF    | OFF | ON |
|                                                    |                                                       |                                                        | 32      | O              | T                          | -      | -   | -  |
| Jib overloading (only for jibs II)                 |                                                       | 33                                                     | E       | Z              | OFF                        | OFF    | ON  |    |
|                                                    |                                                       | 34                                                     | O       | T              | -                          | -      | -   |    |
| Main hook radius (no. of crane limitation periods) |                                                       | 35                                                     | -       | -              | -                          | -      | -   |    |
|                                                    |                                                       | 36                                                     | J       | Z              | -                          | -      | -   |    |
| Jib hook radius (no. of crane limitation periods)  |                                                       | 37                                                     | -       | -              | -                          | -      | -   |    |
|                                                    |                                                       | 38                                                     | J       | Z              | -                          | -      | -   |    |
| Height                                             |                                                       | Main hook height (no. of crane limitation periods)     | 40      | J              | Z                          | -      | -   | -  |
|                                                    |                                                       |                                                        | 41      | -              | -                          | -      | -   | -  |
|                                                    | Jib height (no. of crane limitation periods)          | 42                                                     | D       | Z              | -                          | -      | -   |    |
|                                                    |                                                       | 43                                                     | -       | -              | -                          | -      | -   |    |
|                                                    | Main hook height (no. of crane limitation periods)    | 44                                                     | D       | Z              | -                          | -      | -   |    |
|                                                    |                                                       | 45                                                     | -       | -              | -                          | -      | -   |    |
|                                                    | Jib height (no. of crane limitation periods)          | 46                                                     | D       | Z              | -                          | -      | -   |    |
|                                                    |                                                       | 47                                                     | -       | -              | -                          | -      | -   |    |
|                                                    | Main hook height (no. of crane limitation periods)    | 48                                                     | D       | Z              | -                          | -      | -   |    |
|                                                    |                                                       | 49                                                     | H       | Z              | OFF                        | OFF    | ON  |    |
| Jib height (no. of crane limitation periods)       | 50                                                    | D                                                      | -       | -              | -                          | -      |     |    |
|                                                    | 51                                                    | H                                                      | -       | -              | -                          | -      |     |    |
| Main hook height (no. of crane limitation periods) | 52                                                    | U                                                      | Z       | OFF            | OFF                        | ON     |     |    |
|                                                    | 53                                                    | -                                                      | -       | -              | -                          | -      |     |    |
| Jib height (no. of crane limitation periods)       | 54                                                    | -                                                      | -       | -              | -                          | -      |     |    |
|                                                    | 55                                                    | -                                                      | -       | -              | -                          | -      |     |    |
| Lift hook                                          | Main hook overhaul                                    | 71                                                     | A       | S              | -                          | -      | -   |    |
|                                                    |                                                       | 72                                                     | A       | S              | -                          | -      | -   |    |
|                                                    | Jib overhaul                                          | 73                                                     | A       | T              | -                          | -      | -   |    |
|                                                    |                                                       | 74                                                     | A       | H              | -                          | -      | -   |    |
|                                                    | Main hook overhaul                                    | 75                                                     | A       | R              | -                          | -      | -   |    |
|                                                    |                                                       | 76                                                     | A       | R              | -                          | -      | -   |    |
|                                                    | Jib overhaul                                          | 77                                                     | A       | R              | -                          | -      | -   |    |
|                                                    |                                                       | 78                                                     | A       | R              | -                          | -      | -   |    |
|                                                    | Main hook overhaul                                    | 79                                                     | -       | -              | ON                         | OFF    | OFF |    |
|                                                    |                                                       | 80                                                     | -       | -              | ON                         | OFF    | ON  |    |
| Overhaul assembly and disassembly                  | 81                                                    | -                                                      | -       | OFF            | OFF                        | ON     |     |    |
|                                                    | 82                                                    | -                                                      | -       | OFF            | OFF                        | ON     |     |    |



**Notes**

- (1) Symbols "-" shown on the columns of alarm sounds and crane control output, in the table above indicate that the corresponding items are not the subjects of control.
- (2) In the columns of the crane control output (automatic stop), "OFF" indicates the stop status, and "ON" indicates the operable status.
- (3) From No. 01 to 76 shown in the table above, priority is given to OFF of conditions other than the drum control output over ON.
- (4) Priority is given in the following order : condition No.92, 71 to 78, 91, 11 to 62

**Details of alarm and automatic stop condition symbols**

- (a) When the status is cancelled, the machine immediately restores automatically.
- (b) When the moment ratio is decreased to 89.5%, the status is cancelled (automatically restored).
- (c) When the moment ratio is decreased by 0.5% from the overload automatic start point, the status is cancelled (automatically restored).
- (d) When the boom is returned to the safety side by 0.4 deg. or more from the limit angle, the status is cancelled (automatically restored).
- (e) When the boom is returned to the safety side by 2.0 deg. or more from the limit angle, the status is cancelled (automatically restored).
- (f) When the moment ratio is decreased by 5.0% from the overload automatic stop point, the status is cancelled (automatically restored).
- (g) Blank
- (h) Blank
- (i) Blank
- (j) When the radius or elevation is returned by 0.1 m (0.1 feet) to the safety side from the prenotice set radius or height, the status is cancelled (automatically restored).
- (k) Alarm is issued when the moment ratio is 90% or more.
- (l) Alarm is issued when the moment ratio exceeds the LVL.
- (m) Alarm is issued when the set values are exceeded and the machine is operated in hazardous directions.
- (n) Alarm is issued when the boom angle exceeds the limit angle.
- (o) Blank

## 11. LOAD SAFETY DEVICE

---

- (p) Alarm is issued when overhoist occurs and the machine is operated in hazardous directions.
- (q) Alarm is issued when overhoist occurs.
- (r) The status cannot be cancelled whatever cancel switch is operated.
- (s) Automatic stop is cancelled only while the hook overhoist cancel switch is operated.
- (t) Automatic stop is cancelled only while the boom overhoist cancel switch is operated.
- (u) Blank
- (v) Blank
- (w) Blank
- (x) Blank
- (y) Blank
- (z) Automatic stop is cancelled only while the overload cancel switch is operated.

## 11.9 RELEASES




When an operation has been auto stopped, the release functions are as explained in the following chart.

### 11.9.1 RELEASE FUNCTION

#### 11.9.1.1 CRANE RELEASE CHART

Set the master key to the "RELEASE" position.  
If it is set to the "LOCK" position, any release is disabled.

Standard Crane Release Chart






| Stop Condition                                                                                                                         | Release Switch Operation | Boom  |      | Hook Hoist Up |           |       |
|----------------------------------------------------------------------------------------------------------------------------------------|--------------------------|-------|------|---------------|-----------|-------|
|                                                                                                                                        |                          | Raise | Down | Main          | Auxiliary | Third |
| <br>Hook Overhoist<br>(Main)                          | No Operation             | O     | X    | X             | X         | X     |
|                                                                                                                                        | Hook overhoist           | O     | O    | O             | O         | O     |
|                                                                                                                                        | Boom overhoist           | O     | X    | X             | X         | X     |
|                                                                                                                                        | Overload                 | O     | X    | X             | X         | X     |
|                                                                                                                                        | Hook & Boom              | O     | O    | O             | O         | O     |
|                                                                                                                                        | Hook & Overload          | O     | O    | O             | O         | O     |
|                                                                                                                                        | Boom & Overload          | O     | X    | X             | X         | X     |
|                                                                                                                                        | All three                | O     | O    | O             | O         | O     |
| <br>Hook Overhoist<br>(Aux.)                        | No Operation             | O     | X    | X             | X         | X     |
|                                                                                                                                        | Hook overhoist           | O     | O    | O             | O         | O     |
|                                                                                                                                        | Boom overhoist           | O     | X    | X             | X         | X     |
|                                                                                                                                        | Overload                 | O     | X    | X             | X         | X     |
|                                                                                                                                        | Hook & Boom              | O     | O    | O             | O         | O     |
|                                                                                                                                        | Hook & Overload          | O     | O    | O             | O         | O     |
|                                                                                                                                        | Boom & Overload          | O     | X    | X             | X         | X     |
|                                                                                                                                        | All three                | O     | O    | O             | O         | O     |
| <br>Overload<br>Boom Low Limit Angle<br>(Stop type) | No Operation             | O     | X    | X             | X         | X     |
|                                                                                                                                        | Hook overhoist           | O     | X    | X             | X         | X     |
|                                                                                                                                        | Boom overhoist           | O     | X    | X             | X         | X     |
|                                                                                                                                        | Overload                 | O     | O    | O             | O         | O     |
|                                                                                                                                        | Hook & Boom              | O     | X    | X             | X         | X     |
|                                                                                                                                        | Hook & Overload          | O     | O    | O             | O         | O     |
|                                                                                                                                        | Boom & Overload          | O     | O    | O             | O         | O     |
|                                                                                                                                        | All three                | O     | O    | O             | O         | O     |

\* The hook lowering is always possible.

O : Can move X: Cannot move

# 11. LOAD SAFETY DEVICE






Standard Crane Release Chart

| Stop Condition                                                                                                                  | Release Switch Operation | Boom  |      | Hook Hoist Up |           |      |
|---------------------------------------------------------------------------------------------------------------------------------|--------------------------|-------|------|---------------|-----------|------|
|                                                                                                                                 |                          | Raise | Down | Main          | Auxiliary | Thrd |
| Overload Boom low limit angle (Alarm type)<br> | No Operation             | O     | O    | O             | O         | O    |
|                                                                                                                                 | Hook overhoist           | O     | O    | O             | O         | O    |
|                                                                                                                                 | Boom overhoist           | O     | O    | O             | O         | O    |
|                                                                                                                                 | Overload                 | O     | O    | O             | O         | O    |
|                                                                                                                                 | Hook & Boom              | O     | O    | O             | O         | O    |
|                                                                                                                                 | Hook & Overload          | O     | O    | O             | O         | O    |
|                                                                                                                                 | Boom & Overload          | O     | O    | O             | O         | O    |
|                                                                                                                                 | All three                | O     | O    | O             | O         | O    |
| Boom up limit angle (Controlled by LMI)<br>    | No Operation             | X     | O    | O             | O         | O    |
|                                                                                                                                 | Hook overhoist           | X     | O    | O             | O         | O    |
|                                                                                                                                 | Boom overhoist           | O     | O    | O             | O         | O    |
|                                                                                                                                 | Overload                 | X     | O    | O             | O         | O    |
|                                                                                                                                 | Hook & Boom              | O     | O    | O             | O         | O    |
|                                                                                                                                 | Hook & Overload          | X     | O    | O             | O         | O    |
|                                                                                                                                 | Boom & Overload          | O     | O    | O             | O         | O    |
|                                                                                                                                 | All three                | O     | O    | O             | O         | O    |
| Boom overhoist (Limit switch)<br>             | No Operation             | X     | O    | X             | X         | X    |
|                                                                                                                                 | Hook overhoist           | X     | O    | X             | X         | X    |
|                                                                                                                                 | Boom overhoist           | X     | O    | X             | X         | X    |
|                                                                                                                                 | Overload                 | X     | O    | X             | X         | X    |
|                                                                                                                                 | Hook & Boom              | X     | O    | X             | X         | X    |
|                                                                                                                                 | Hook & Overload          | X     | O    | X             | X         | X    |
|                                                                                                                                 | Boom & Overload          | X     | O    | X             | X         | X    |
|                                                                                                                                 | All three                | X     | O    | X             | X         | X    |
| Overload (200%)<br>                          | No Operation             | O     | X    | X             | X         | X    |
|                                                                                                                                 | Hook overhoist           | O     | X    | X             | X         | X    |
|                                                                                                                                 | Boom overhoist           | O     | X    | X             | X         | X    |
|                                                                                                                                 | Overload                 | O     | X    | X             | X         | X    |
|                                                                                                                                 | Hook & Boom              | O     | X    | X             | X         | X    |
|                                                                                                                                 | Hook & Overload          | O     | X    | X             | X         | X    |
|                                                                                                                                 | Boom & Overload          | O     | X    | X             | X         | X    |
|                                                                                                                                 | All three                | O     | X    | X             | X         | X    |
| Crane jib overhoist (Option)<br>             | No Operation             | O     | X    | O             | X         | O    |
|                                                                                                                                 | Hook overhoist           | O     | X    | O             | X         | O    |
|                                                                                                                                 | Boom overhoist           | O     | X    | O             | X         | O    |
|                                                                                                                                 | Overload                 | O     | X    | O             | X         | O    |
|                                                                                                                                 | Hook & Boom              | O     | X    | O             | X         | O    |
|                                                                                                                                 | Hook & Overload          | O     | X    | O             | X         | O    |
|                                                                                                                                 | Boom & Overload          | O     | X    | O             | X         | O    |
|                                                                                                                                 | All three                | O     | X    | O             | X         | O    |

\* The hook lowering is always possible.






O : Can move X: Cannot move

Lifting Crane Release Chart (Main 1/2)






| Stop Condition                                                                                                                     | Release Switch Operation | Boom  |      | Jib   |      | Hook Hoist Up |           |
|------------------------------------------------------------------------------------------------------------------------------------|--------------------------|-------|------|-------|------|---------------|-----------|
|                                                                                                                                    |                          | Raise | Down | Raise | Down | Main          | Auxiliary |
| Hook overhoist<br>(Main)<br>                      | No Operation             | ○     | X    | ○     | X    | X             | X         |
|                                                                                                                                    | Hook overhoist           | ○     | ○    | ○     | ○    | ○             | ○         |
|                                                                                                                                    | Boom overhoist           | ○     | X    | ○     | X    | X             | X         |
|                                                                                                                                    | Overload                 | ○     | X    | ○     | X    | X             | X         |
| Hook overhoist<br>(Auxiliary)<br>                 | No Operation             | ○     | X    | ○     | X    | X             | X         |
|                                                                                                                                    | Hook overhoist           | ○     | ○    | ○     | ○    | ○             | ○         |
|                                                                                                                                    | Boom overhoist           | ○     | X    | ○     | X    | X             | X         |
|                                                                                                                                    | Overload                 | ○     | X    | ○     | X    | X             | X         |
| Overload<br>                                     | No Operation             | ○     | X    | ○     | X    | X             | X         |
|                                                                                                                                    | Hook overhoist           | ○     | X    | ○     | X    | X             | X         |
|                                                                                                                                    | Boom overhoist           | ○     | X    | ○     | X    | X             | X         |
|                                                                                                                                    | Overload                 | ○     | ○    | ○     | ○    | ○             | ○         |
| Boom up limit angle<br>(Controlled by LMI)<br>  | No Operation             | X     | ○    | ○     | ○    | ○             | ○         |
|                                                                                                                                    | Hook overhoist           | X     | ○    | ○     | ○    | ○             | ○         |
|                                                                                                                                    | Boom overhoist           | ○     | ○    | ○     | ○    | ○             | ○         |
|                                                                                                                                    | Overload                 | X     | ○    | ○     | ○    | ○             | ○         |
| Boom low limit angle<br>(Controlled by LMI)<br> | No Operation             | ○     | X    | ○     | X    | X             | X         |
|                                                                                                                                    | Hook overhoist           | ○     | X    | ○     | X    | X             | X         |
|                                                                                                                                    | Boom overhoist           | ○     | X    | ○     | X    | X             | X         |
|                                                                                                                                    | Overload                 | ○     | ○    | ○     | ○    | ○             | ○         |

11. LOAD SAFETY DEVICE

Luffing Crane Release Chart (Main 2/2)






| Stop Condition                                                                                                                      | Release Switch Operation | Boom  |      | Jib   |      | Hook Hoist Up |           |
|-------------------------------------------------------------------------------------------------------------------------------------|--------------------------|-------|------|-------|------|---------------|-----------|
|                                                                                                                                     |                          | Raise | Down | Raise | Down | Main          | Auxiliary |
| Boom overhoist<br>(Backstop No.1 L/S)<br>          | No Operation             | X     | 0    | 0     | 0    | 0             | 0         |
|                                                                                                                                     | Hook overhoist           | X     | 0    | 0     | 0    | 0             | 0         |
|                                                                                                                                     | Boom overhoist           | 0     | 0    | 0     | 0    | 0             | 0         |
|                                                                                                                                     | Overload                 | X     | 0    | 0     | 0    | 0             | 0         |
| Boom overhoist<br>(Backstop No.2 L/S)<br>          | No Operation             | X     | 0    | X     | 0    | X             | X         |
|                                                                                                                                     | Hook overhoist           | X     | 0    | X     | 0    | X             | X         |
|                                                                                                                                     | Boom overhoist           | X     | 0    | X     | 0    | X             | X         |
|                                                                                                                                     | Overload                 | X     | 0    | X     | 0    | X             | X         |
| Jib up, limit angle<br>(Small offset angle)<br>   | No Operation             | 0     | X    | X     | 0    | 0             | 0         |
|                                                                                                                                     | Hook overhoist           | 0     | X    | X     | 0    | 0             | 0         |
|                                                                                                                                     | Boom overhoist           | 0     | 0    | 0     | 0    | 0             | 0         |
|                                                                                                                                     | Overload                 | 0     | X    | X     | 0    | 0             | 0         |
| Jib low, limit angle<br>(Large offset angle)<br> | No Operation             | X     | 0    | 0     | X    | X             | X         |
|                                                                                                                                     | Hook overhoist           | X     | 0    | 0     | X    | X             | X         |
|                                                                                                                                     | Boom overhoist           | X     | 0    | 0     | X    | X             | X         |
|                                                                                                                                     | Overload                 | 0     | 0    | 0     | 0    | 0             | 0         |
| Jib overhoist L/S<br>                            | No Operation             | 0     | X    | X     | 0    | X             | X         |
|                                                                                                                                     | Hook overhoist           | 0     | X    | X     | 0    | X             | X         |
|                                                                                                                                     | Boom overhoist           | 0     | X    | X     | 0    | X             | X         |
|                                                                                                                                     | Overload                 | 0     | X    | X     | 0    | X             | X         |

Luffing Crane Release Chart (Jib 1/2)

| Stop Condition                                                                                                                      | Release Switch Operation | Boom  |      | Jib   |      | Hook Hoist Up |           |
|-------------------------------------------------------------------------------------------------------------------------------------|--------------------------|-------|------|-------|------|---------------|-----------|
|                                                                                                                                     |                          | Raise | Down | Raise | Down | Main          | Auxiliary |
| Hook overhoist<br>(Main)<br>                       | No Operation             | ○     | ×    | ○     | ×    | ×             | ×         |
|                                                                                                                                     | Hook overhoist           | ○     | ○    | ○     | ○    | ○             | ○         |
|                                                                                                                                     | Boom overhoist           | ○     | ×    | ○     | ×    | ×             | ×         |
|                                                                                                                                     | Overload                 | ○     | ×    | ○     | ×    | ×             | ×         |
| Hook overhoist<br>(Auxiliary)<br>                  | No Operation             | ○     | ×    | ○     | ×    | ×             | ×         |
|                                                                                                                                     | Hook overhoist           | ○     | ○    | ○     | ○    | ○             | ○         |
|                                                                                                                                     | Boom overhoist           | ○     | ×    | ○     | ×    | ×             | ×         |
|                                                                                                                                     | Overload                 | ○     | ×    | ○     | ×    | ×             | ×         |
| Overload<br>                                      | No Operation             | ○     | ×    | ○     | ×    | ×             | ×         |
|                                                                                                                                     | Hook overhoist           | ○     | ×    | ○     | ×    | ×             | ×         |
|                                                                                                                                     | Boom overhoist           | ○     | ×    | ○     | ×    | ×             | ×         |
|                                                                                                                                     | Overload                 | ○     | ○    | ○     | ○    | ○             | ○         |
| Boom up. limit angle<br>(Controlled by LMI)<br>  | No Operation             | ×     | ○    | ○     | ○    | ○             | ○         |
|                                                                                                                                     | Hook overhoist           | ×     | ○    | ○     | ○    | ○             | ○         |
|                                                                                                                                     | Boom overhoist           | ○     | ○    | ○     | ○    | ○             | ○         |
|                                                                                                                                     | Overload                 | ×     | ○    | ○     | ○    | ○             | ○         |
| Boom low. limit angle<br>(Controlled by LMI)<br> | No Operation             | ○     | ×    | ○     | ○    | ×             | ×         |
|                                                                                                                                     | Hook overhoist           | ○     | ×    | ○     | ○    | ×             | ×         |
|                                                                                                                                     | Boom overhoist           | ○     | ×    | ○     | ○    | ×             | ×         |
|                                                                                                                                     | Overload                 | ○     | ○    | ○     | ○    | ○             | ○         |

# 11. LOAD SAFETY DEVICE

LuTing Crane Release Chart (Jib 2/2)

| Stop Condition                                                                                                                            | Release Switch Operation | Boom  |      | Jib   |      | Hook Hoist Up |           |
|-------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|-------|------|-------|------|---------------|-----------|
|                                                                                                                                           |                          | Raise | Down | Raise | Down | Main          | Auxiliary |
| <b>Boom overhoist</b><br>(Backstop No.1 L/S)<br>         | No Operation             | X     | 0    | 0     | 0    | 0             | 0         |
|                                                                                                                                           | Hook overhoist           | X     | 0    | 0     | 0    | 0             | 0         |
|                                                                                                                                           | Boom overhoist           | 0     | 0    | 0     | 0    | 0             | 0         |
|                                                                                                                                           | Overload                 | X     | 0    | 0     | 0    | 0             | 0         |
| <b>Boom overhoist</b><br>(Backstop No.2 L/S)<br>         | No Operation             | X     | 0    | X     | 0    | X             | X         |
|                                                                                                                                           | Hook overhoist           | X     | 0    | X     | 0    | X             | X         |
|                                                                                                                                           | Boom overhoist           | X     | 0    | X     | 0    | X             | X         |
|                                                                                                                                           | Overload                 | X     | 0    | X     | 0    | X             | X         |
| <b>Jib up. limit angle</b><br>(Controlled by LMI)<br>   | No Operation             | 0     | 0    | X     | 0    | 0             | 0         |
|                                                                                                                                           | Hook overhoist           | 0     | 0    | X     | 0    | 0             | 0         |
|                                                                                                                                           | Boom overhoist           | 0     | 0    | 0     | 0    | 0             | 0         |
|                                                                                                                                           | Overload                 | 0     | 0    | X     | 0    | 0             | 0         |
| <b>Jib low. limit angle</b><br>(Controlled by LMI)<br> | No Operation             | 0     | X    | 0     | X    | X             | X         |
|                                                                                                                                           | Hook overhoist           | 0     | X    | 0     | X    | X             | X         |
|                                                                                                                                           | Boom overhoist           | 0     | X    | 0     | X    | X             | X         |
|                                                                                                                                           | Overload                 | 0     | 0    | 0     | 0    | 0             | 0         |
| <b>Jib overhoist L/S</b><br>                           | No Operation             | 0     | X    | X     | 0    | X             | X         |
|                                                                                                                                           | Hook overhoist           | 0     | X    | X     | 0    | X             | X         |
|                                                                                                                                           | Boom overhoist           | 0     | X    | X     | 0    | X             | X         |
|                                                                                                                                           | Overload                 | 0     | X    | X     | 0    | X             | X         |



## 11.9.1.2 ALARM SOUND

## 1. Crane

○ emitted (Peep--) Δ emitted (Beep) X : not emitted

| Condition                      | Operation                   |                 |               |                 |              |                |            |            |
|--------------------------------|-----------------------------|-----------------|---------------|-----------------|--------------|----------------|------------|------------|
|                                | Main winch up               | Main winch down | Aux. winch up | Aux. winch down | 3rd winch up | 3rd winch down | Boom raise | Boom lower |
| Hook overhoist (main)          | ○                           | X               | ○             | X               | ○            | X              | X          | ○          |
| Hook overhoist (Jib / aux.)    | ○                           | X               | ○             | X               | ○            | X              | X          | ○          |
| Boom upper limit angle         | X                           | X               | X             | X               | X            | X              | ○          | X          |
| Boom overhoist (L /sw)         | ○ : regardless of operation |                 |               |                 |              |                |            |            |
| Overload                       | Δ : regardless of operation |                 |               |                 |              |                |            |            |
| Crane jib overhoist (Not used) | ○ : regardless of operation |                 |               |                 |              |                |            |            |

- When any hazardous condition occurs, and any circle is found in the line of the hazardous condition in the table above, alarm sounds are emitted.

## 2. Luffing

○ emitted (Peep--) Δ emitted (Beep-) X : not emitted

| Condition                  | Operation                   |                 |               |                 |            |            |           |           |
|----------------------------|-----------------------------|-----------------|---------------|-----------------|------------|------------|-----------|-----------|
|                            | Main winch up               | Main winch down | Aux. winch up | Aux. winch down | Boom raise | Boom lower | Jib raise | Jib lower |
| Hook overhoist (main)      | ○                           | X               | ○             | X               | X          | ○          | X         | ○         |
| Hook overhoist (Jib/aux.)  | ○                           | X               | ○             | X               | X          | ○          | X         | ○         |
| Boom upper limit angle     | X                           | X               | X             | X               | ○          | X          | X         | X         |
| Jib upper limit angle      | X                           | X               | X             | X               | X          | X          | ○         | X         |
| Boom overhoist (No.1 L/sw) | ○ : regardless of operation |                 |               |                 |            |            |           |           |
| Boom overhoist (No.2 L/sw) | ○ : regardless of operation |                 |               |                 |            |            |           |           |
| Jib overhoist (L/sw)       | ○ : regardless of operation |                 |               |                 |            |            |           |           |
| Boom low. limit angle      | Δ : regardless of operation |                 |               |                 |            |            |           |           |
| Jib low. limit angle       | Δ : regardless of operation |                 |               |                 |            |            |           |           |
| Overload                   | Δ : regardless of operation |                 |               |                 |            |            |           |           |

- When any hazardous condition occurs, and any circle is found in the line of the hazardous condition in the table above, alarm sounds are emitted.

## 11. LOAD SAFETY DEVICE

### 11.9.1.3 EXTERNAL INDICATOR LAMPS IN RELEASE CONDITION

The overload external indicator lamps are forcibly lit to indicate the moment ratio of 100% or more by the release switch.

| Release condition                               | External indicator |                      |               |
|-------------------------------------------------|--------------------|----------------------|---------------|
|                                                 | to 90% (green)     | 90% to 100% (yellow) | 100% to (red) |
| Normal condition                                | ○                  | X                    | X             |
| Hook overhoist                                  | X                  | X                    | ○             |
| Overload                                        | X                  | X                    | ○             |
| Boom overhoist                                  | X                  | X                    | ○             |
| Hook overhoist and overload                     | X                  | X                    | ○             |
| Hook overhoist and boom overhoist               | X                  | X                    | ○             |
| Overload and boom overhoist                     | X                  | X                    | ○             |
| Hook overhoist, overload,<br>and boom overhoist | X                  | X                    | ○             |
| Master key                                      | X                  | X                    | ○             |

#### Alarm sounds

1. For the hook overhoist, boom upper limit angle, and jib upper limit angle, alarm sounds are emitted only when the operation toward the hazardous side is performed while the machine is in the hazardous condition.  
Even when the machine is in the hazardous condition, the alarm sounds are not emitted when the operation toward the safe side is performed or the lever is at the neutral position.
2. For the overload, boom lower limit angle, jib lower limit angle, boom overhoist (limit switch), and jib overhoist (limit switch), the alarm sounds are emitted regardless of the lever operation when the machine is in the hazardous condition.  
The alarm sounds cannot be cancelled.

## 11.10 MECHANICAL SPECIFICATION


### 11.10.1 ENVIRONMENTAL PERFORMANCE PARAMETERS

|                               |                                                                                                                                                         |                                                                                         |
|-------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|
| Power :                       | DC24V battery (20 - 32V)                                                                                                                                |                                                                                         |
| Capable temperature :         | -20 to 70 °C<br>(However, since the LC display temperature limit is 0 to 40 deg., when the temperature is outside of this range, it may not be visible) |                                                                                         |
| Storage temp. :               | -40 to 80 °C.                                                                                                                                           |                                                                                         |
| Humidity :                    | 95%                                                                                                                                                     |                                                                                         |
| Protective structure :        | Outdoor elements                                                                                                                                        | Water proofed, sealed structures                                                        |
|                               | Inside elements                                                                                                                                         | Dust proofed (no sealed structures)                                                     |
| Vibration proof :             | 39 m/s <sup>2</sup> 33 Hz X, Y, Z (2 hours each)                                                                                                        |                                                                                         |
| Shock proof :                 | 196 m/s <sup>2</sup> 15 to 19 sec. X, Y, Z (3 times each)                                                                                               |                                                                                         |
| Electronic "Noise" Proofing : | No mechanical damage with DC 1000V 1μS added while the power is on.<br>No mechanical malfunction with DC 700V 100ns added while the power is on.        |                                                                                         |
| Item locations :              | Outdoor                                                                                                                                                 | Detector link, angle changers, connecting cables, transit boxes etc. (outdoor elements) |
|                               | Oper. cabin                                                                                                                                             | Controllers etc. (inside elements)                                                      |

## 11. LOAD SAFETY DEVICE



### 11.10.2 LOAD CELL (CRANE)

|                                    |                                                                              |
|------------------------------------|------------------------------------------------------------------------------|
| Model name :                       | LTP-S-100-KNSA7                                                              |
| Detective capacity:                | Guy-cable support power                                                      |
| Rated capacity :                   | 10 ton (98.07KN)                                                             |
| Load capacity :                    | 150%                                                                         |
| Output voltage :                   | with no load $1V \pm 0.01V$ (at shipping)<br>with rated load $5V \pm 0.040V$ |
| Power source :                     | DC9V $\pm 15V$ (under 30 mA)                                                 |
| Output resistance                  | Appr. under 100 $\Omega$                                                     |
| Insulated resistance :             | 500M $\Omega$ / above 25VDC                                                  |
| Non-Linearity :                    | $\pm 1\%$ RO                                                                 |
| Hysteresis :                       | $\pm 1\%$ RO                                                                 |
| Temperature compensation range :   | -30°C + 65°C                                                                 |
| Temperature capacity :             | -35°C to + 75°C                                                              |
| Temperature effect at zero point : | $\pm 0.1\%$ RO/C                                                             |
| Temperature effect at output :     | $\pm 0.1\%$ RO/C                                                             |
| Output cable                       | None<br>apex classification 5P water proof plug AE770L14-05P                 |
| Vibration proof :                  | 69.6 m/s 33Hz up/down for 4 hours and left/right, front/back for 2 hours.    |
| Shock proof :                      | 245 m/s. 15mS X,Y, Z (3 times each)                                          |
| Water proof :                      | Conforms to IP67 or equivalent (JIS C0920 non-sealing type)                  |
| Durability :                       | $5 \times 10^6$ times                                                        |
| Noise proof :                      | DC700V 100ns                                                                 |
| Total integrity :                  | $\geq 9\%$ RO                                                                |
| Weight :                           | About 6 kg                                                                   |



## 11.10.3 ANGLE SENSOR

|                            |                                                               |
|----------------------------|---------------------------------------------------------------|
| Model name :               | MLA-901A-**C                                                  |
| Detection capacity         | Boom angle against ground                                     |
| Valid operating range      | 0 to $\pm 90$ degree                                          |
| Operation range :          | 360 deg. endless                                              |
| Rated output sensitivity . | 0.255V/V $\pm 0.5\%$                                          |
| Input voltage :            | 10V                                                           |
| Input resistance :         | 50k $\Omega \pm 5\%$                                          |
| Output resistance :        | (25000 + 141.6 X $\theta$ ) $\Omega \pm 5\%$                  |
| Detecting accuracy :       | $\pm 1$ deg.                                                  |
| Initial imbalance :        | Set with $\pm 5$ deg.                                         |
| Insulate resistance :      | 100M $\Omega / 50$ VDC                                        |
| Output cable :             | Cable fire crolobran cable 0.5mm <sup>2</sup> X 4             |
| Cable analysis :           | Bending radius : R100, Tensile strength : 8kg                 |
| Cable apex :               | 5P water proof plug AE776L14-05S+MT12-14-MS3180-14CAL         |
| Control method :           | Oil damper                                                    |
| Monitor :                  | With outside weight 0deg., 30deg., 60deg., 90deg. Monitorable |
| Case material :            | Plastic (Toshiba premix AP-902S)                              |
| Surface treatment :        | Non, stripe (Black)                                           |
| Temperature range :        | -20 to 70°C                                                   |
| Store temp. :              | -40 to 80°C                                                   |
| Weight :                   | appr. 1.2kg (main body), appr. 65g/m (cable)                  |



A-C Resistance : 50K $\Omega$   
 A-B Resistance (R) : 25000+141.6X $\theta$

## 11. LOAD SAFETY DEVICE

---

### 11.10.4 CONTROLLER

#### 11.10.4.1 MODEL NAME

LSD-1500A

#### 11.10.4.2 SYSTEM INPUT/OUTPUT

1. Load input 1 to 7

|                          |                                                                                                         |
|--------------------------|---------------------------------------------------------------------------------------------------------|
| Corresponding transducer | Voltage output type load transducer                                                                     |
| Input range              | From 1 to 5 V (from 0 to rated load)<br>Faulty when the load is 130% or more, or -10% or less of rating |
| Frequency characteristic | 2 Hz                                                                                                    |
| Detective resolution     | 0.03%RD                                                                                                 |
| Detective precision      | ±0.1%RD                                                                                                 |
| Input connector          | CN12M 1-174961-1                                                                                        |

2. Angle input 1 to 4

|                          |                                                                                   |
|--------------------------|-----------------------------------------------------------------------------------|
| Corresponding transducer | Potentiometer type jib angle transducer                                           |
| Input range              | From 0.75 to 7.83 V<br>(Error occurs when it is 8.08 V or more or 0.45 V or less) |
| Frequency characteristic | 1 Hz                                                                              |
| Detective resolution     | 0.07 deg.                                                                         |
| Detective precision      | ±0.2 deg                                                                          |
| Others                   | Disconnection detective function                                                  |
| Input connector          | Input 1 to 3: CN13M 1-179019-1<br>Input 4: CN14M 1-174957-1 (Common to input 5)   |

3. Angle input 5

|                          |                                                                                  |
|--------------------------|----------------------------------------------------------------------------------|
| Input range              | From 0.75 to 9.25 V<br>(Error occurs when it is 9.5 V or more or 0.45 V or less) |
| Frequency characteristic | 1 Hz                                                                             |
| Detective resolution     | 0.08 deg.                                                                        |
| Detective precision      | ±0.3 deg                                                                         |
| Others                   | Disconnection detective function                                                 |
| Input connector          | CN14M 1-174957-1 (Common to input 4)                                             |

4. Digital input 1 to 20

|                      |                                                                                                                                                                                                                                                                                            |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Input type           | No-voltage contact (ON : Grounded, OFF : Open)                                                                                                                                                                                                                                             |
| Input judgment level | ON when the contact resistance is 500 Ω or less (when the power supply voltage is 24 V, and the contact current is 14 mA)<br>ON when it is approximately 200 Ω or less under the power supply voltage of 20 V, or it is approximately 1 kΩ or less under the power supply voltage of 32 V. |
| Input connector      | CN15M 1-174960-1                                                                                                                                                                                                                                                                           |

5. Digital output 1 to 20
- |                           |                                                         |
|---------------------------|---------------------------------------------------------|
| Output type               | Relay contact (ON : 24 V, OFF : Open)                   |
| Rated current capacity    | 2.5A                                                    |
| Allowable rush-in current | 5 A or less. Output for indicator lamp is 10 A or less. |
| Others                    | Short-circuit protection                                |
| Input connector           | CN16M 1-174960-1                                        |
6. Analogue output 1 to 3
- |                     |                                                                                                                                                       |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| Output range        | 1. Tension : From 0 to 5 V (from 0 to 100%)<br>2. Boom angle : From 0 to 5 - (from 0 to 90 deg.)<br>3. Jib angle : From 0 to 5 V (from -90 to 90deg.) |
| Resolution          | 5 mV or less                                                                                                                                          |
| Precision           | ± 0.5% from indicated value                                                                                                                           |
| Data upgrading time | 0.2 sec. or shorter                                                                                                                                   |
| Input connector     | CN16M 1-174955-1                                                                                                                                      |
7. Serial communication 1
- |                         |                                                                                                |
|-------------------------|------------------------------------------------------------------------------------------------|
| Application             | Data communication with controller (for details of communication, refer to the separate sheet) |
| Interface               | Conforms to RS-232C                                                                            |
| Baud rate               | 9600BPS                                                                                        |
| Start bit               | 1                                                                                              |
| Data bit                | 8                                                                                              |
| Parity bit              | 1 (even number)                                                                                |
| Stop bit                | 1                                                                                              |
| Communication connector | CN18M 1-174954 (Common to communication 2)                                                     |
8. Serial communication 2
- |                         |                                            |
|-------------------------|--------------------------------------------|
| Application             | Data transmission to PC (hysteresis data)  |
| Interface               | Conforms to RS-232C                        |
| Baud rate               | 19200BPS                                   |
| Start bit               | 1                                          |
| Data bit                | 8                                          |
| Parity bit              | 1 (even number)                            |
| Stop bit                | 1                                          |
| Communication connector | CN18M 1-174954 (Common to communication 1) |
9. Sound output
- |                       |                                |
|-----------------------|--------------------------------|
| Application           | Overhaul alarm and voice alarm |
| Output sound pressure | 75 dB (A) at 1m                |

## 11. LOAD SAFETY DEVICE

---

### 10. Alarm output

|                       |                 |
|-----------------------|-----------------|
| Application           | Overload alarm  |
| Output sound pressure | 75 dB (A) at 1m |

#### 11.10.4.3 MONITOR DISPLAY

|              |                                                                                 |
|--------------|---------------------------------------------------------------------------------|
| Element used | 7 2 type STN semipermeable color liquid crystal<br>640x480 dots vertically used |
|--------------|---------------------------------------------------------------------------------|

#### 11.10.4.4 OPERATION SWITCH

|             |                                                                                                                                               |
|-------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| Seat switch | 8 key switches<br>Upward, downward, leftward, and rightward arrow keys, MLNU key, SET key, assembly and disassembly key, and slowing mode key |
| Dip switch  | 8 switches<br>Program upgrading permission, manufacturer's adjustment permission, and other spare switches                                    |

#### 11.10.4.5 INTERNAL PROCESSING SYSTEM

|                   |                                         |
|-------------------|-----------------------------------------|
| CPU               | H8/3048 (CONTROL), H8/2633 (INDICATION) |
| Control frequency | 200 mS or less                          |

#### 11.10.4.6 MEMORY

|               |                                                                                                                                                |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| Flash memory  | Capacity : 2 MB<br>Application : Storage of programs, adjustment values, set values, display data, load hysteresis, and selected capacity data |
| One-time PROM | Capacity : 128 KB<br>Application : Storage of sound data                                                                                       |
| S-RAM         | Capacity : 512 Kbit<br>Application : For operation                                                                                             |





**11.10.4.7 EXTERNAL STORAGE ELEMENT**

|             |                                                                                                                                                                                                                 |
|-------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Smart media | Capacity : 4MB or 8MB<br>Application : Storage of capacity data, adjustment values, and set values<br>Format : Only for this unit<br>(Reading and writing with the PC is performed through the special adaptor) |
|-------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**11.10.4.8 OTHERS**


|                              |                                                                                                                                       |
|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| Clock and calendar functions | Back-up with the super capacitor<br>Charged when the power is supplied. Back-up for approx. one month is possible when fully charged. |
|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|

11.11 EXTERNAL DIMENSIONS




11.12 ELECTRIC SCHEMATIC DIAGRAM

11.12.1 CRANE TYPE



# 11. LOAD SAFETY DEVICE

## 11.12.2 LUFFING TYPE




### 11.13 CONTROLLER MALFUNCTION EMERGENCY MEASURES

When the controller is malfunctioned, as an emergency measure, set the M/L bypass switch in the left side stand to the "crane bypass" or "luffing bypass" position depending on the attachment used.

Then, immediately repair the controller. Though all the operations become possible by performing the step above, the indication, warning, and stop functions (overhaul limit function is available) are still unavailable.

#### **⚠ DANGER**

While the load safety device controller functions correctly, the bypass circuit is not actuated even when the M/L bypass switch is set to the "bypass" position.



### 11.14 LOAD SAFETY DEVICE CHECK PROCEDURES

#### 1. Check of working radius indication

- (1) Display the appropriate working radius within the working area in the boom lowering direction in the indicator.
- (2) Measure the working radius with a measuring tape, and check that it is the same as the indicated working radius.

#### 2. Check of load indication

- (1) Lift a load of which correct weight is known.
- (2) Check that the load (lifted load + hook weight + sling weight) is the same as the indicated actual load.


---

## **12. GAUGE CLUSTER**





12.1 CONFIGURATION OF DISPLAY



### 12.2 PRIORITY

1. All the display items are divided into seven groups, A to G.  
The priority is given to them in the alphabetical order, A (highest) to G (lowest).
2. While the items in higher priority groups are displayed on the screen of the gauge cluster, the items in lower priority groups are not displayed.  
For example, while the "M/L stop release" (in the group A) is displayed on the screen, the "self check function" (in the group E) is not displayed. The items in lower priority groups are displayed after the display of the items in higher priority groups is ended.
3. When some items in the same group are required to be displayed, they are displayed by turns.
4. The normal display is replaced by the display of the items in higher priority groups, since the normal display has the lowest priority. It can be forcibly displayed with flashing by pushing the zero switch, and holding it for 5 seconds or longer.

| Priority | No.                         | Display items                                   | Input signal for local controller *1                                              |                                            | Detection condition |               | Input delay *2 | Buzzer alarm *3 |
|----------|-----------------------------|-------------------------------------------------|-----------------------------------------------------------------------------------|--------------------------------------------|---------------------|---------------|----------------|-----------------|
|          |                             |                                                 | Disappeared from screen                                                           | Displayed on screen                        | Standstill (H/G)    | Running (L/G) |                |                 |
| A        | 1                           | CPD MECHANICAL FAILURE (H-1)                    | Normal communication                                                              | Faulty communication                       | O                   | G             | -              | G               |
|          | 2                           | M/L STOP RELEASE (H-2)                          | By communication with M/L                                                         |                                            |                     | G             | D              | A               |
|          | 3                           | M/L BYPASS (W-21)                               | -                                                                                 | 1                                          | O                   | G             | O              | A               |
| B        | 4                           | ENGAGE THE DRUM LOCK (W-31)                     | -                                                                                 | 1                                          | O                   | G             | -              | G               |
|          | 5                           | ENGINE PREHEAT (W-1)                            | -                                                                                 | 1                                          | O                   | G             | -              | -               |
| C        | 6                           | FINISH PREHEAT (W-2)                            | -                                                                                 | 1                                          | O                   | G             | -              | -               |
|          | 7                           | Fault log display                               |                                                                                   |                                            |                     |               |                |                 |
| 6        | 8                           | Mechatronic adjustment                          |                                                                                   |                                            |                     |               |                |                 |
|          | 9                           | Status display                                  |                                                                                   |                                            |                     |               |                |                 |
| 10       | ENGINE OIL PRESS (W-5)      | -                                               | 0                                                                                 |                                            | G                   |               | ⊗              | ⊗               |
|          |                             |                                                 | 0                                                                                 | -                                          | O                   |               | ⊗              | ⊗               |
| D        | 11                          | ENGINE WATER TEMP (W-6)                         | Water temperature is less than 115°C (221°F)                                      | Water temperature is 135°C or more (271°F) | O                   | G             | D              | G               |
|          | 12                          | FR-SAFETY ESM ON (W-16)                         | When the machine is in the neutral brake mode, clutch pressure is 570 psi or less |                                            | O                   | G             | D              | G               |
|          | 13                          | RF-SAFETY ESM ON (W-17)                         |                                                                                   |                                            | O                   | G             | D              | G               |
|          | 14                          | 3RD WINCH ESM ON (W-18)                         |                                                                                   |                                            | O                   | G             | D              | G               |
|          | 15                          | ENGINE OIL FL. LTR (W-9)                        | -                                                                                 | 0                                          | O                   | G             | D              | -               |
|          | 16                          | ENGINE AIR CLEANER (W-10)                       | -                                                                                 | 0                                          | O                   | G             | -              | -               |
| F        | 17                          | Self check function                             |                                                                                   |                                            |                     |               |                |                 |
| 18       | CHARGING PROBLEM (W-3)      | 1                                               | -                                                                                 |                                            | G                   |               | ⊗              |                 |
|          |                             |                                                 | 1                                                                                 | O                                          |                     |               | ⊗              |                 |
| 19       | LOW FUEL LEVEL (W-11)       | Fuel gauge communication exceeds 05 lx          | Fuel gauge communication is 05 lx or less                                         | O                                          | G                   |               | ⊗              |                 |
| 20       | RADIATOR WATER LV. (W-8)    | -                                               | 0                                                                                 | O                                          | G                   | O             | -              |                 |
| 21       | CONTROL MAIN PRESS (W-4)    | -                                               | 0                                                                                 |                                            | G                   |               | O              |                 |
|          |                             | 0                                               | -                                                                                 | O                                          |                     |               | O              |                 |
| 22       | HYD OIL TEMP (W-12)         | -                                               | 0                                                                                 | O                                          | O                   | O             |                |                 |
| 23       | FR-WINCH OIL TEMP (W-13)    | -                                               | 0                                                                                 | O                                          | O                   | O             | O              |                 |
| 24       | RE-WINCH OIL TEMP (W-14)    | -                                               | 0                                                                                 | O                                          | O                   | O             | O              |                 |
| 25       | WINCH FILTER (W-15)         | -                                               | 0                                                                                 |                                            | O                   |               | O              | O               |
| 26       | HOOK RAISE STOP REL. (W-19) | By communication with M/L                       |                                                                                   |                                            | O                   |               | O              | A               |
|          |                             | By communication with M/L                       |                                                                                   |                                            | O                   |               | O              | A               |
| 27       | BOOM RAISE STOP REL. (W-20) |                                                 |                                                                                   |                                            | O                   |               | O              | A               |
| G        | 28                          | MOISTURE DETECTION OF THE FUEL FILTER (G-25) *4 | -                                                                                 | 1                                          | O                   | O             | -              | -               |
|          |                             |                                                 |                                                                                   |                                            |                     |               |                |                 |

\*1. Input signal 1: +24 V level 0: (S/N) level - : Open level

\*2. Input delay ⊗: 5.0 sec. O: 1.5 sec. -: No delay

### \*3. Buzzer alarm


- ⊗: Buzzer sounds; emission intermittently continues for 0.2 sec. with intervals of 0.3 sec. (it cannot be stopped with the buzzer stop switch).
- O: Buzzer sounds; emission intermittently continues for 0.5 sec. with intervals of 0.5 sec. (it can be stopped with the buzzer stop switch).
- Δ: Buzzer sounds; emission intermittently continues for 0.2 sec. with intervals of 0.3 sec., and is stopped 5 sec. later.

Blank: None

\*4. Normal display for other items except (G-25)


### 12.3 STATUS DISPLAY

The current machine statuses can be displayed on the liquid crystal display screen of the gauge cluster by using the data from the total controller. Fifty-two types of display screens are available (refer to CONTENTS OF STATUS DISPLAY).



**Procedures**

1. Start the engine.
2. Push both of the check switch and buzzer switch at the same time, and hold them for 5 seconds or longer.  
First, the No.1 items, parts code of the total controller and program version, are displayed.
  - While the items in the group A or B are displayed, the machine does not enter the status display mode. Correct the conditions that lead to the display of the items in group A or B.
3. Whenever the display screen selector switch ▽ is pushed, the screen is scrolled up once, while it is scrolled down once whenever the display screen selector switch △ is pushed. When the display screen selector switch ▽ or △ is left pushed, the screen is scrolled continuously.
4. To end the status display mode, push the setting switch. Then, the screen returns to the normal display.
5. If the key switch is not set to the "ON" position and the status display mode is actuated again, the screen which had been displayed just before the normal screen was returned appears. If the key switch is set to the "OFF" position, the No.1 screen appears.



## CONTENTS OF STATUS DISPLAY

| Display category                                                               | Job                                                                                    | Operation instruction                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Range of indicated values                                | Remarks                                                                                                                                                                         |
|--------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| No. 1<br>MAIN CONT. FN<br>BATTERY CHG<br>PROGRAMMER<br>VFR (10)                |                                                                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                                                          | The pointer number of screen rate by model and specification                                                                                                                    |
| No. 2<br>ENGINE SET 2000<br>MEAS 2001                                          |                                                                                        | The string value is changed depending on the position of the main handle or lock handle                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | Low High<br>700 to 720 rpm 2000 to 2100 rpm              |                                                                                                                                                                                 |
| ENGINEERS LIVE                                                                 |                                                                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | At H.E.G. of pressure LIVE<br>At H.E.G. of pressure DEAD |                                                                                                                                                                                 |
| No.3<br>4-2<br>GRIP SWIT 4.2V<br>POS 100%<br>MOTOR STOP 200<br>POS 100%        |                                                                                        | The values are changed depending on the main handle command, low or high                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Low High<br>0.2V 0.3V<br>0% 100%                         | The components are shown. The values of the POS are changed between 0 and 100% when the E.G. sensor is changed between low and high. If they are not changed to 100%, it is 0%. |
| No.4<br>STOP MOTOR<br>1-1 COM-A 1.2V<br>1-2 COM-B 1.1A<br>LIM 1 0X1            | NO USE<br>COMMAND TO ECU<br>NO USE                                                     | The set values are changed depending on the position of the handle                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Low High<br>1.0V 4.0V                                    | Although the indicator needle displays "OK", the actual status is "OFF".                                                                                                        |
| No.5<br>DIGITAL OUTPUT<br>0-1 COMB 0X1<br>MEAS 0X1<br>0-2 COMB -<br>MEAS -     | BATTERY RELAY<br>BRAKE                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | 1: Turns on in the "ON" while the power is supplied      | 1: 0.0MP<br>2: 0.0MP and value<br>3: 0.0MP                                                                                                                                      |
| No.6<br>DIGITAL OUTPUT<br>0-3 COMB OFF<br>MEAS OFF<br>0-4 COMB OFF<br>MEAS OFF | HYD. OIL HEATER RELAY<br>HYD. PUMP INCLUDING SOL                                       | Get up the main switch and stop the operation of heating oil and ON/OFF is displayed<br>All the control levers are set to the neutral positions.<br>Any of the control levers is being operated<br>The boom counter is set to the neutral position of the making switch is turned on<br>When the conditions other than the above are not satisfied                                                                                                                                                                                                        | ON<br>ON<br>ON<br>ON                                     | 1: MEAS<br>2: feed back value                                                                                                                                                   |
| No.7<br>DIGITAL OUTPUT<br>0-5 COMB OFF<br>MEAS OFF<br>0-6 COMB -<br>MEAS -     | MAIN PUMP INCLUDING SOL                                                                | When the main switch and stop switch control levers are set to the neutral positions and the making switch is turned on<br>Conditions other than the above or in the first fall mode                                                                                                                                                                                                                                                                                                                                                                      | ON<br>ON                                                 | The fault diagnosis is performed by displaying the following codes<br>COMB OFF<br>MEAS ON<br>Connect a plug<br>ON 20V<br>OFF 6 or 8V<br>disconnect                              |
| No.8<br>DIGITAL OUTPUT<br>0-7 COMB OFF<br>MEAS ON<br>0-8 COMB ON<br>MEAS ON    | MAIN WINCH (FRONT DRUM)<br>CLUTCH CLM SOL<br>MAIN WINCH (FRONT DRUM)<br>CLUTCH BSM SOL | Get up of the main switch (from down) and/or clutch switch and make (SOL 22) is displayed<br>When the main switch is in the first fall mode and the lever is at the neutral position<br>Conditions other than the above<br>Status of the main winch (of drum) and/or clutch emergency release (color (SF1 - 15)) is displayed<br>The clutch pressure decreases although the main switch is in the brake mode<br>The clutch pressure decreases when the main switch is in the first fall mode and the lever is operated<br>Conditions other than the above | ON<br>ON<br>ON<br>ON<br>ON<br>ON<br>ON<br>ON             | Check procedures<br>1) Measure the voltage at the connector.<br>2) Measure the resistance of the solenoid valves.<br>3) Replace with newly solenoid valves and connectors.      |

## 12. GAUGE CLUSTER

| Display example          | Pin                                        | Operation explanation                                                                                                                                                                                                                                                                                                      | Range of indicated values | Remarks                                                                                                                                                                     |
|--------------------------|--------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NO. 9<br>DIGITAL OUTPUT  |                                            |                                                                                                                                                                                                                                                                                                                            |                           |                                                                                                                                                                             |
| C-9 COMP OFF             |                                            |                                                                                                                                                                                                                                                                                                                            |                           |                                                                                                                                                                             |
| WEAS                     |                                            |                                                                                                                                                                                                                                                                                                                            |                           |                                                                                                                                                                             |
| C-10 COMP OFF            | AUX. WINCH (REAR<br>DRUM) CLUTCH<br>SOLE   | Status of the auxiliary winch (rear drum) clutch release valve (SOL-21) is displayed.<br>When the auxiliary winch is in the free fall mode and lever is in the neutral position.<br>Comes ON other than the above.                                                                                                         | ON<br>OFF                 |                                                                                                                                                                             |
| NO. 10<br>DIGITAL OUTPUT |                                            |                                                                                                                                                                                                                                                                                                                            |                           |                                                                                                                                                                             |
| C-11 COMP OFF            | AUX. WINCH (FRONT<br>DRUM) CLUTCH<br>SOLE  | Status of the auxiliary winch (front drum) clutch release valve (SOL-20) is displayed.<br>The clutch pressure decreases through the auxiliary winch in the free fall mode.<br>The clutch pressure decreases when the auxiliary winch is in the free fall mode and the lever is operated.<br>Comes ON other than the above. | ON<br>ON<br>OFF           | COMP<br>command code<br>from remote                                                                                                                                         |
| C-12 COMP                |                                            |                                                                                                                                                                                                                                                                                                                            |                           |                                                                                                                                                                             |
| WEAS                     |                                            |                                                                                                                                                                                                                                                                                                                            |                           |                                                                                                                                                                             |
| NO. 11<br>DIGITAL OUTPUT |                                            |                                                                                                                                                                                                                                                                                                                            |                           |                                                                                                                                                                             |
| C-13 COMP OFF            | THIRD WINCH (THIRD<br>DRUM) CLUTCH<br>SOLE | Status of the third winch (third drum) clutch release valve (SOL-24) is displayed.<br>When the third winch is in the free fall mode and the lever is at the neutral position.<br>Comes ON other than the above.                                                                                                            | ON<br>OFF                 | MEAS<br>feed back value                                                                                                                                                     |
| C-14 COMP OFF            | THIRD WINCH (THIRD<br>DRUM) CLUTCH<br>SOLE | Status of the third winch (third drum) clutch release valve (SOL-21) is displayed.<br>The clutch pressure decreases through the third winch in the free fall mode.<br>The clutch pressure decreases when the third winch is in the free fall mode and the lever is operated.<br>Comes ON other than the above.             | ON<br>ON<br>OFF           | The output connection is broken by displaying the following codes:<br>COMP OFF<br>WEAS ON<br>Connection code<br>ON: 24 V<br>OFF: Error to<br>ground                         |
| C-15 COMP OFF            | MAIN WINCH (FRONT<br>DRUM) CLUTCH<br>SOLE  | Status of the main winch (front drum) clutch release valve (SOL-17) is displayed.<br>The main winch lever is in the neutral position.<br>When the main winch lever is returned to the neutral position.                                                                                                                    | ON<br>OFF                 | Check procedure:<br>1) Measure the voltage at the connector.<br>2) Measure the resistance of the selected cables.<br>3) Replace with nearby selected cables and connectors. |
| C-16 COMP OFF            | AUX. WINCH (REAR<br>DRUM) CLUTCH<br>SOLE   | Status of the auxiliary winch (rear drum) clutch release valve (SOL-16) is displayed.<br>The auxiliary winch lever is in the neutral position.<br>When the auxiliary winch lever is returned to the neutral position.                                                                                                      | ON<br>ON<br>OFF           | The code is changed to the "ON" code when the lever is not at the neutral position with 1 sec. The "OFF" code remains displayed.                                            |
| NO. 13<br>DIGITAL OUTPUT |                                            |                                                                                                                                                                                                                                                                                                                            |                           |                                                                                                                                                                             |
| C-17 COMP OFF            | THIRD WINCH (THIRD<br>DRUM) CLUTCH<br>SOLE | Status of the third winch (third drum) clutch release valve (SOL-17) is displayed.<br>The third winch lever is in the neutral position.<br>When the third winch lever is returned to the neutral position.                                                                                                                 | ON<br>OFF                 | The code is changed to the "ON" code when 1) the lever is not at the neutral position with 1 sec. the "OFF" code remains displayed.                                         |
| C-18 COMP OFF            | MAIN WINCH (FRONT<br>DRUM) CLUTCH<br>SOLE  | Major of the main winch drum rotation detector (rpm) is displayed.<br>Turn on the drum rotation switch, and show or lower the main winch.                                                                                                                                                                                  | ON<br>OFF                 | Display of the "ON" and "OFF" is mistake with the drum rotation. The repeating speed of the "ON" and "OFF" codes display is proportional to the drum rotation speed.        |

| Display example         | Job                                | Operation instruction                                                                                                                                                                                                                                                                                                                                                                           | Range of indicated values                                                                                                                                                             | Remarks                                                                                                                                                                                    |
|-------------------------|------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NO.14<br>DIGITAL OUTPUT |                                    |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       |                                                                                                                                                                                            |
| C.17 LOWP OFF           | AUX WINCH TURN<br>DRUM             | Status of the aux. winch drum turn direction lamp is displayed.<br>Turn on the main winch switch and raise or lower the aux.<br>winch.                                                                                                                                                                                                                                                          | Display of the "LOW" and "HIGH" is repeated with<br>the drum rotation. The repeating speed of the<br>"HIGH" and "LOW" codes of display is proportional to<br>the drum rotation speed. |                                                                                                                                                                                            |
| MEAS OFF                |                                    |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       |                                                                                                                                                                                            |
| C.21 LOWP OFF           | MAIN WINCH C/W SOL                 | Status of the main winch drum C/W solenoid valve (C/W) is<br>displayed.<br>Set the main winch lever to full speed switch in the "HIGH" posi-<br>tion when the main winch is in the free fall mode, the lever is<br>at the neutral position, and the foot pedal is released.<br>In the status shown above, set the switch to the "LOW" posi-<br>tion, depress the pedal, or operate the lever.   | ON<br>OFF                                                                                                                                                                             |                                                                                                                                                                                            |
| MEAS OFF                |                                    |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       |                                                                                                                                                                                            |
| NO.15<br>DIGITAL OUTPUT |                                    |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       |                                                                                                                                                                                            |
| C.21 LOWP OFF           | AUX WINCH C/W SOL                  | Status of the aux. winch drum C/W solenoid valve (C/W) is<br>displayed.<br>Set the aux. winch lever full speed switch to the "HIGH" posi-<br>tion when the aux. winch is in the free fall mode, the lever is<br>at the neutral position, and the foot pedal is released.<br>In the status shown above, set the switch to the "LOW" posi-<br>tion, depress the pedal, or operate the lever.      | ON<br>OFF                                                                                                                                                                             |                                                                                                                                                                                            |
| MEAS OFF                |                                    |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       |                                                                                                                                                                                            |
| C.22 LOWP OFF           | THIRD WINCH C/W SOL                | Status of the third drum C/W solenoid valve (C/W) is<br>displayed.<br>Set the third winch lever full speed switch to the "HIGH" po-<br>sition when the third winch is in the free fall mode, the lever is<br>at the neutral position, and the foot pedal is released.<br>In the status shown above, set the switch to the "LOW" posi-<br>tion, depress the pedal, or operate the lever.         | ON<br>OFF                                                                                                                                                                             | "LOWP"<br>command value<br>from controller<br>"MEAS"<br>lever bank value                                                                                                                   |
| MEAS OFF                |                                    |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       |                                                                                                                                                                                            |
| NO.16<br>DIGITAL OUTPUT |                                    |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       |                                                                                                                                                                                            |
| C.23 COMP               | WIND SPEED ALARM<br>OUTPUT         | The wind speed is not less than the set speed that the warn-<br>ing is issued with the alarm indicator, a siren, etc. set up.<br>When the wind speed other than the above are not satisfied.                                                                                                                                                                                                    |                                                                                                                                                                                       | "COMP"OFF<br>"MEAS"ON                                                                                                                                                                      |
| MEAS                    |                                    |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       |                                                                                                                                                                                            |
| C.24 COMP               | SPARE                              |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       | On-hook voltage<br>ON: 24 V<br>OFF: 0 to 8V<br>less fluctuation                                                                                                                            |
| NO.17<br>DIGITAL OUTPUT |                                    |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       |                                                                                                                                                                                            |
| C.25 COMP               | SPARE                              |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       | Check error code<br>1) Measure the voltage<br>of the solenoid<br>2) Measure the test<br>trace of the solenoid<br>valves.<br>3) Proceed with repair<br>solenoid valves and con-<br>troller. |
| MEAS                    |                                    |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       |                                                                                                                                                                                            |
| C.26 COMP OFF           | MAIN WINCH D/DM<br>FREE FALL LAMP  | Lower the intercouple lever for getting ON and OFF, and set<br>the free fall lock switch to the release position. Then, depress<br>the main winch foot pedal while pressing the right winch free<br>fall switch.<br>In the status shown above, repeat the same operation. Or,<br>raise the intercouple lever for getting ON and OFF, or set the<br>free fall lock switch to the lock position.  | ON<br>OFF                                                                                                                                                                             |                                                                                                                                                                                            |
| MEAS OFF                |                                    |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       |                                                                                                                                                                                            |
| NO.18<br>DIGITAL OUTPUT |                                    |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       |                                                                                                                                                                                            |
| C.27 COMP OFF           | AUX WINCH D/DM<br>FREE FALL LAMP   | Lower the intercouple lever for getting ON and OFF, and set<br>the free fall lock switch to the release position. Then, depress<br>the aux. winch foot pedal while pressing the aux. winch free<br>fall switch.<br>In the status shown above, repeat the same operation. Or,<br>raise the intercouple lever for getting ON and OFF, or set the<br>free fall lock switch to the lock position.   | ON<br>OFF                                                                                                                                                                             |                                                                                                                                                                                            |
| MEAS OFF                |                                    |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       |                                                                                                                                                                                            |
| C.28 COMP               | THIRD WINCH D/DM<br>FREE FALL LAMP | Lower the intercouple lever for getting ON and OFF, and set<br>the free fall lock switch to the release position. Then, depress<br>the third winch foot pedal while pressing the third winch free<br>fall switch.<br>In the status shown above, repeat the same operation. Or,<br>raise the intercouple lever for getting ON and OFF, or set the<br>free fall lock switch to the lock position. | ON<br>OFF                                                                                                                                                                             |                                                                                                                                                                                            |
| MEAS                    |                                    |                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                       |                                                                                                                                                                                            |

## 12. GAUGE CLUSTER

| Model example                                                         | Unit                           | Operation condition                                                                                 | Range of indicated values                                                                  |                            | Remarks                                                                                                                                                                                                                                                               |
|-----------------------------------------------------------------------|--------------------------------|-----------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NO.18<br>PROPO VALVE<br>D.1<br>COMP. 60mA 4.5MP<br>MEAS. 60mA 4.5MP   | BOOM RAISE SPEED CONTROL       | The value is changed according to the speed adjusting armmer value.                                 | Initial max. value                                                                         | Terminal max. value        |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | BO Low                                                                                     | 625mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | BO High                                                                                    | 625mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | The current of the proportional value is determined to 200 mA depending on the boom angle. |                            |                                                                                                                                                                                                                                                                       |
| NO.20<br>PROPO VALVE<br>O.2<br>COMP. 60mA 4.5MP<br>MEAS. 60mA 4.5MP   | BOOM LOWER SPEED CONTROL       | The value is changed according to the speed adjusting armmer value.                                 | Terminal max. value                                                                        | Terminal max. value        |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom lowering is slowly stopped (due to locked and boom lower limit). | LO Low                                                                                     | 625mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom lowering is slowly stopped (due to locked and boom lower limit). | LO High                                                                                    | 625mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom lowering is slowly stopped (due to locked and boom lower limit). | The current of the proportional value is determined to 200 mA in approximately 1.5 sec.    |                            |                                                                                                                                                                                                                                                                       |
| NO.21<br>PROPO VALVE<br>D.3<br>COMP. 6.0mA 4.5MP<br>MEAS. 6.0mA 4.5MP | FRONT DRUM HOIST SPEED CONTROL | The value is changed according to the speed adjusting armmer value.                                 | Terminal voltage                                                                           | Proportional value current |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | 0V                                                                                         | 145mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | 1.5V                                                                                       | 145mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | 4.5V                                                                                       | 170mA                      |                                                                                                                                                                                                                                                                       |
| NO.22<br>PROPO VALVE<br>D.4<br>COMP. 6.0mA 4.5MP<br>MEAS. 6.0mA 4.5MP | FRONT DRUM LOWER SPEED CONTROL | The value is changed according to the speed adjusting armmer value.                                 | Terminal voltage                                                                           | Proportional value current | -COMP<br>-MEAS<br>-BOOM LOWER<br>The adjustments are stopped. The values of the "MEAS" pin in "FUNCTION" change to the values of the "COMP".                                                                                                                          |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | 0V                                                                                         | 145mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | 1.5V                                                                                       | 145mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | 4.5V                                                                                       | 170mA                      |                                                                                                                                                                                                                                                                       |
| NO.23<br>PROPO VALVE<br>D.5<br>COMP. 300mA 4.5MP<br>MEAS. 300mA 4.5MP | REAR DRUM HOIST SPEED CONTROL  | The value is changed according to the speed adjusting armmer value.                                 | Terminal voltage                                                                           | Proportional value current | Check placement<br>1) Move to the correct value at the connector clamp with a screw.<br>2) Move to the voltage of the terminals to ensure accurate measurement.<br>3) Move to the proportional value reference.<br>4) Replace with neatly folded wire and connectors. |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | 0V                                                                                         | 145mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | 1.5V                                                                                       | 145mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | 4.5V                                                                                       | 170mA                      |                                                                                                                                                                                                                                                                       |
| NO.24<br>PROPO VALVE<br>O.3<br>COMP. 60mA 4.5MP<br>MEAS. 60mA 4.5MP   | REAR DRUM LOWER SPEED CONTROL  | The value is changed according to the speed adjusting armmer value.                                 | Terminal voltage                                                                           | Proportional value current |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom lowering is slowly stopped (due to locked and boom lower limit). | 0V                                                                                         | 145mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom lowering is slowly stopped (due to locked and boom lower limit). | 1.5V                                                                                       | 145mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom lowering is slowly stopped (due to locked and boom lower limit). | 4.5V                                                                                       | 170mA                      |                                                                                                                                                                                                                                                                       |
| NO.25<br>PROPO VALVE<br>D.7<br>COMP. 60mA 4.5MP<br>MEAS. 60mA 4.5MP   | THIRD DRUM HOIST SPEED CONTROL | The value is changed according to the speed adjusting armmer value.                                 | Terminal voltage                                                                           | Proportional value current |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | 0V                                                                                         | 145mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | 1.5V                                                                                       | 145mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom raising is stopped (due to down operation).                      | 4.5V                                                                                       | 170mA                      |                                                                                                                                                                                                                                                                       |
| NO.26<br>PROPO VALVE<br>D.8<br>COMP. 60mA 4.5MP<br>MEAS. 60mA 4.5MP   | THIRD DRUM LOWER SPEED CONTROL | The value is changed according to the speed adjusting armmer value.                                 | Terminal voltage                                                                           | Proportional value current |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom lowering is slowly stopped (due to locked and boom lower limit). | 0V                                                                                         | 145mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom lowering is slowly stopped (due to locked and boom lower limit). | 1.5V                                                                                       | 145mA                      |                                                                                                                                                                                                                                                                       |
|                                                                       |                                | The value is changed when the boom lowering is slowly stopped (due to locked and boom lower limit). | 4.5V                                                                                       | 170mA                      |                                                                                                                                                                                                                                                                       |



| Display number                                                       | Job                 | Operation instruction                                                                                                                                                                                                                                             | Range of indicated values |                            | Remarks                                                               |       |
|----------------------------------------------------------------------|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|----------------------------|-----------------------------------------------------------------------|-------|
| NO.27<br>PROPO VALVE<br>D-3<br>CCMP 60mA 4.5MP<br>MFAS 60mA 4.5MP    | TRUCK MOTOR CONTROL | Lifting switch in the "OFF" status.<br>When the conditions shown below are satisfied, the output is activated depending on the status of the speed adjustment (forward, reverse, running) and the operation of lever.                                             | Forward voltage           | Proportional valve current |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | 0V                        | 250mA                      |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | 1.5V                      | 250 to 750mA               |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | 4.5V                      | 250 to 750mA               |                                                                       |       |
| Free fall acceleration                                               |                     |                                                                                                                                                                                                                                                                   | 700mA per start           |                            |                                                                       |       |
| NO.28<br>PROPO VALVE<br>D-3<br>CCMP 60mA 4.5MP<br>MFAS 60mA 4.5MP    | TRAIL MOTOR CONTROL | Lifting switch in the "OFF" status.<br>When the conditions shown below are satisfied, the output is activated depending on the status of the speed adjustment (forward, reverse, running) and the operation of lever.                                             | Forward voltage           | Proportional valve current |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | 0V                        | 250mA                      |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | 1.5V                      | 250 to 750mA               |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | 4.5V                      | 250 to 750mA               |                                                                       |       |
| Free fall acceleration                                               |                     |                                                                                                                                                                                                                                                                   | 750mA per start           |                            |                                                                       |       |
| NO.29<br>PROPO VALVE<br>D-11<br>CCMP 100mA 4.5MP<br>MFAS 100mA 4.5MP | SWING REEF CONTROL  | The voltage of the proportional valve is changed by the swing reefer switch.<br>Low E/G speed<br>High E/G speed<br>When the boom is not swung for 10 sec. after stop.                                                                                             | Free fall up              | Free fall at low speed up  | Control valve shown in Part 10 of the operation manual is to be used. |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | 5.00V                     | 250mA                      |                                                                       | 250mA |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | 250mA                     | 250mA                      |                                                                       | 250mA |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | 250mA                     | 250mA                      |                                                                       | 250mA |
| NO.10<br>PROPO VALVE<br>D-14<br>CCMP 100mA 4.5MP<br>MFAS 100mA 4.5MP | MAIN PUMP CONTROL   | The control lever is at the neutral position, and the E/G speed is low.<br>The same conditions as the above, but the E/G speed is high.<br>From the port hook switch on and the E/G speed is low.<br>The same conditions as the above, but the E/G speed is high. | Approx. 70mA              |                            |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | Approx. 100mA             |                            |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | Approx. 100mA             |                            |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | Approx. 100mA             |                            |                                                                       |       |
| NO.31<br>PROPO VALVE<br>D-11<br>CCMP 100mA 4.5MP<br>MFAS 100mA 4.5MP | THIRD MOTOR CONTROL | The main pump current is fluctuated according to the E/G speed, hoisting and lower pin.<br>Lifting switch in the "ON" status.<br>Free fall emergency                                                                                                              | Forward voltage           | Proportional valve current |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | 0V                        | 10mA                       |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | 4.5V                      | 120 to 140mA               |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | 5.0V                      | 120 to 140mA               |                                                                       |       |
| Free fall emergency                                                  |                     |                                                                                                                                                                                                                                                                   | 750mA                     |                            |                                                                       |       |
| NO.12<br>PROPO VALVE<br>D-14<br>CCMP 100mA 4.5MP<br>MFAS 100mA 4.5MP | SWING REACTION      | The swing lever is at the neutral position.<br>The swing lever is fully operation.<br>When operations include the same cable and main the swing reaction.                                                                                                         | Free                      | Brake                      |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | 150mA                     | 100mA                      |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | 510mA                     | 250mA                      |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   |                           |                            |                                                                       |       |
| NO.33<br>PROPO VALVE<br>D-15<br>CCMP 100mA 4.5MP<br>MFAS 100mA 4.5MP | FOURTH PUMP CONTROL | Control lever is neutral position, low E/G speed.<br>Control lever is neutral position, high E/G speed.<br>From: rear and boom switch (low E/G speed)<br>From: rear and boom switch (high E/G speed)                                                              | Approx. 100mA             |                            |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | Approx. 100mA             |                            |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | Approx. 100mA             |                            |                                                                       |       |
|                                                                      |                     |                                                                                                                                                                                                                                                                   | Approx. 100mA             |                            |                                                                       |       |

## 12. GAUGE CLUSTER

| Display example                     | Use                                               | Operation / instruction                                                                                                                            | Range / Indicated value    |                          | Remarks                                                |
|-------------------------------------|---------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|--------------------------|--------------------------------------------------------|
| <b>NO.04</b><br><b>ANALOG INPUT</b> |                                                   |                                                                                                                                                    |                            |                          |                                                        |
| A-1 0.0V                            | FRONT DRUM SPEED                                  | The value is changed according to the drum which drum speed adjusting trimmer value.                                                               | Trimmed min. value<br>0.0V | Trimmed max. value<br>5V | Voltage gain increases (trimmer).                      |
| A-2 0.0V                            | REAR DRUM SPEED                                   | The value is changed according to the drum which drum speed adjusting trimmer value.                                                               | Trimmed min. value<br>0.0V | Trimmed max. value<br>5V |                                                        |
| A-3 0.0V                            | BUSH DRUM SPEED                                   | The value is changed according to the drum which drum speed adjusting trimmer value.                                                               | Trimmed min. value<br>0.0V | Trimmed max. value<br>5V |                                                        |
| A-4 0.0V                            | SPARE                                             |                                                                                                                                                    |                            |                          |                                                        |
| <b>NO.05</b><br><b>ANALOG INPUT</b> |                                                   |                                                                                                                                                    |                            |                          |                                                        |
| A-5 0.0V                            | SPARE                                             |                                                                                                                                                    |                            |                          | Check procedure (Measure the voltage of the DC motor). |
| A-6 0.0V                            |                                                   |                                                                                                                                                    |                            |                          |                                                        |
| A-7 0.0V                            | CRUISE THROTTLE                                   | The value is changed according to the cruise throttle status.                                                                                      | Low<br>0.4 to 0.6V         | High<br>4.5 to 5V        |                                                        |
| A-8 0.0V                            | LOCK THROTTLE                                     | The value is changed according to the lock throttle status (Unavailable when the optional component is not equipped.)                              | Low<br>1V                  | High<br>3 to 4.5V        |                                                        |
| <b>NO.06</b><br><b>ANALOG INPUT</b> |                                                   |                                                                                                                                                    |                            |                          |                                                        |
| A-9 0.0V                            | REAR DRUM POSITION<br>CONTROL POSITION<br>SENSOR  |                                                                                                                                                    | 0.2 to 4.9V 0.5 to 5V      |                          |                                                        |
| A-10 0.0V                           | FRONT DRUM POSITION<br>CONTROL POSITION<br>SENSOR |                                                                                                                                                    | 0.2 to 4.9V 0.5 to 5V      |                          |                                                        |
| A-11 0.0V                           | SWING PUMP PRESSURE SENSOR                        | The swing level is at the neutral position.<br>(Not full swing mode)                                                                               | 0.5V<br>0.5V               |                          | Similar to A-10 to A-12                                |
| A-12 0.0V                           | FRONT DRUM SPEED                                  | The value is changed according to the drum which drum speed adjusting trimmer value.<br>(Unavailable when the optional component is not equipped.) | Trimmed min. value<br>0.0V | Trimmed max. value<br>5V | Similar to A-10 to A-12                                |

| Display example        | Use                            | Operation instruction                                                                                                                                   | Range of indicated values      | Remarks                                                                                                                                                    |
|------------------------|--------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NO.37<br>ANALOG INPUT  |                                |                                                                                                                                                         |                                |                                                                                                                                                            |
| A-13 0.5V              | FRONT DRUM HOIST PRESS. SENSOR | The lever is at the neutral position.<br>The lever is fully operated                                                                                    | 0.5V<br>4.5V                   |                                                                                                                                                            |
| A-14 0.5V              | FRONT DRUM LOWER PRESS. SENSOR | The lever is at the neutral position.<br>The lever is fully operated                                                                                    | 0.5V<br>4.5V                   |                                                                                                                                                            |
| A-15 0.5V              | REAR DRUM HOIST PRESS. SENSOR  | The lever is at the neutral position.<br>The lever is fully operated                                                                                    | 0.5V<br>4.5V                   |                                                                                                                                                            |
| A-16 0.5V              | REAR DRUM LOWER PRESS. SENSOR  | The lever is at the neutral position.<br>The lever is fully operated                                                                                    | 0.5V<br>4.5V                   |                                                                                                                                                            |
| NO.38<br>ANALOG INPUT  |                                |                                                                                                                                                         |                                |                                                                                                                                                            |
| A-17 0.5V              | HIGH DRUM HOIST PRESS. SENSOR  | The lever is at the neutral position.<br>The lever is fully operated                                                                                    | 0.5V<br>4.5V                   | * The components are normal if the value is not changed when the operation continues are completed.                                                        |
| A-18 0.5V              | HIGH DRUM LOWER PRESS. SENSOR  | The lever is at the neutral position.<br>The lever is fully operated                                                                                    | 0.5V<br>4.5V                   |                                                                                                                                                            |
| A-19 1.5V              | FRONT CLUTCH PRESS. SENSOR     | When the lever is operated while the machine is in the brake to free fall mode<br>When the machine is in the free fall mode and the foot pedal released | 1.5V<br>0.5V                   | Check procedure: Replace with another sensor.                                                                                                              |
| A-20 1.5V              | REAR CLUTCH PRESS. SENSOR      | When the lever is operated while the machine is in the brake to free fall mode<br>When the machine is in the free fall mode and the foot pedal released | 1.5V<br>0.5V                   |                                                                                                                                                            |
| NO.39<br>ANALOG INPUT  |                                |                                                                                                                                                         |                                |                                                                                                                                                            |
| A-21 1.5V              | THIRD CLUTCH PRESS. SENSOR     | When the lever is operated while the machine is in the brake to free fall mode<br>When the machine is in the free fall mode and the foot pedal released | 1.5V<br>0.5V                   | After the replacement: All 4 the sensors value is changed when the sensor is faulty. All 4 the sensors value is not changed when the sensor is not faulty. |
| A-22 1.5V              | WIND SPEED SENSOR              | 0m<br>32m                                                                                                                                               | 0V<br>1.6-10V                  |                                                                                                                                                            |
| A-23 1.5V              |                                |                                                                                                                                                         |                                |                                                                                                                                                            |
| A-24 1.5V              | BOOM RAISE PRESS. SENSOR       | The lever is at the neutral position.<br>The lever is fully operated                                                                                    | 0.5V<br>4.5V                   |                                                                                                                                                            |
| NO.40<br>ANALOG INPUT  |                                |                                                                                                                                                         |                                |                                                                                                                                                            |
| A-25 1.5V              | BOOM LOWER PRESS. SENSOR       | The lever is at the neutral position.<br>The lever is fully operated                                                                                    | 0.5V<br>4.5V                   |                                                                                                                                                            |
| A-26 1.5V              | SIGNAL                         |                                                                                                                                                         |                                |                                                                                                                                                            |
| NO.41<br>DIGITAL INPUT |                                |                                                                                                                                                         |                                |                                                                                                                                                            |
| H-1 OFF                | FRONT DRUM HOIST LIFT SIGNAL   | When the lift button switch is set to the "ON" position and the foot pedal is depressed                                                                 | Wiring: ON<br>WDT input: OFF   | * The components are normal if the value is not changed when the respective conditions are satisfied.                                                      |
| H-2 OFF                | REAR DRUM HOIST LIFT SIGNAL    | When the lift button switch is set to the "ON" position and the foot pedal is depressed                                                                 | Wiring: ON<br>WDT input: OFF   |                                                                                                                                                            |
| H-3 OFF                | THIRD DRUM HOIST LIFT SIGNAL   | When the lift button switch is set to the "ON" position and the foot pedal is depressed                                                                 | Wiring: ON<br>WDT input: OFF   |                                                                                                                                                            |
| H-4 OFF                | BLU ON SIGNAL                  | BLU condition is engaged                                                                                                                                | FCU: ON / ON<br>FCU: OFF / OFF |                                                                                                                                                            |

## 12. GAUGE CLUSTER

| Display Name           | Use | Operation indication                     | Range of indicator values                                                                     |                              | Remarks                              |
|------------------------|-----|------------------------------------------|-----------------------------------------------------------------------------------------------|------------------------------|--------------------------------------|
| NO 42<br>DIGITAL INPUT |     |                                          |                                                                                               |                              |                                      |
| B 5                    | OFF |                                          |                                                                                               |                              |                                      |
| B 7                    | OFF | SWING BRAKE MODE<br>ON                   | Position of the swing brake mode selector switch is displayed                                 | Free to fall low speed<br>ON | Free to fall high speed<br>OFF       |
| B 7                    | OFF | LIFTING JIB BRAKE<br>DECELERATION        | With deceleration signal ON                                                                   | Deceleration ON              | Normal OFF                           |
| B 5                    | OFF | DRUM THRU GRIP<br>SWITCH                 | When drum deceleration (DRUM) switch                                                          | ON ON                        | OFF OFF                              |
| NO 43<br>DIGITAL INPUT |     |                                          |                                                                                               |                              |                                      |
| B 9                    | OFF | FRONT DRUM BRAKE<br>PEAK LIMIT SWITCH    | Front brake operating status display                                                          | Operation ON                 | Not operation OFF                    |
| B 10                   | OFF | IGN. SWITCH                              | The displayed code is changed depending on the position of the ignition switch                | IGNITION ON ON               | IGNITION OFF OFF                     |
| B 11                   | OFF | HOISTING SPEED                           | Speed change according to the position of the hoisting speed switch                           | Hoisting ON                  | Normal OFF                           |
| B 12                   | OFF | SPARE                                    |                                                                                               |                              |                                      |
| NO 44<br>DIGITAL INPUT |     |                                          |                                                                                               |                              |                                      |
| B 12                   | OFF | ENGINE OIL PRES<br>SURE SWITCH           | The displayed code is changed depending on the status of the engine                           | Engine stop ON               | Engine running OFF                   |
| B 14                   | OFF | MOISTURE DETECTION<br>OF THE FUEL FILTER | Misture in the fuel filter is detected                                                        | Detection ON                 | Normally OFF                         |
| B 15                   | OFF | BOOM RAISE STOP<br>SIGNAL                | When the boom is raised up to the top limit height                                            | Stop ON                      | Normally OFF                         |
| B 15                   | OFF | BOOM LOWER STOP<br>SIGNAL                | When the maximum of the overload or APU status, or the boom reaches to the landing gear limit | Stop ON                      | Normally OFF                         |
| NO 45<br>DIGITAL INPUT |     |                                          |                                                                                               |                              |                                      |
| B 17                   | OFF | REAR LOWER STOP<br>SIGNAL                | When the rear wheel drum was open over maximum of the rotation for the hoist                  | Stop ON                      | Usually OFF                          |
| B 16                   | OFF | BOOM RAISE SLOW<br>DOWN SIGNAL           | 10 degrees to the boom upper limit                                                            | Deceleration ON              | Normal OFF                           |
| B 19                   | OFF | REAR RAFF SLOW<br>DOWN SIGNAL            | In the CK1200 normally the code "OFF" is displayed                                            |                              |                                      |
| B 20                   | OFF | FRONT LOWER STOP<br>SIGNAL               | When the main wheel drum was open over maximum of the rotation for the hoist                  | Stop ON                      | Usually OFF                          |
| NO 46<br>DIGITAL INPUT |     |                                          |                                                                                               |                              |                                      |
| B 21                   | OFF | FRONT DRUM HOIST<br>STOP SIGNAL          | When the main drum is in the overload or APU status                                           | Stop ON                      | Usually OFF                          |
| B 22                   | OFF | REAR DRUM HOIST<br>STOP SIGNAL           | When the main drum is in the overload or APU status                                           | Stop ON                      | Usually OFF                          |
| B 23                   | OFF | TOATR PAUSE MODE                         | In the CK1200 normally the code "OFF" is displayed                                            |                              |                                      |
| B 24                   | OFF | SWING BRAKE MODE<br>OFF                  | Position of the swing brake mode selector switch is displayed                                 | Swing brake mode selected ON | Swing free mode low speed select OFF |
| NO 47<br>DIGITAL INPUT |     |                                          |                                                                                               |                              |                                      |
| B 25                   | OFF | TURP (L) LOWTR<br>STOP SIGNAL            | In the CK1200 normally the code "OFF" is displayed                                            | Stop ON                      | Usually OFF                          |
| B 26                   | OFF | TRAVEL SIGNAL                            | The displayed code is changed depending on the operation of the travel lever                  | Operation ON                 | Normal OFF                           |
| B 27                   | OFF | SAVING SIGNAL                            | The displayed code is changed depending on the operation of the saving lever                  | Operation ON                 | Normal OFF                           |
| B 28                   | OFF | LIMIT PASS                               | The LIM bypass switch is effective                                                            | Limiter ON                   | Increase OFF                         |

The components are normal if the values are changed when the respective conditions are satisfied.

| Display example        | Job                                      | Operation/condition                                                                                     | Range of indicated values    |                               | Remarks                                                                                               |
|------------------------|------------------------------------------|---------------------------------------------------------------------------------------------------------|------------------------------|-------------------------------|-------------------------------------------------------------------------------------------------------|
| ND 18<br>DIGITAL INPUT |                                          |                                                                                                         |                              |                               |                                                                                                       |
| B 29 OFF               | THIRD DRUM BRAKE STOP SIGNAL             | When the third drum brake overload or ATE status is used as the stop signal, the light is extinguished. | Stop ON                      | Usually OFF                   |                                                                                                       |
| B 30 OFF               | FUNCTION LOCK                            | The value is changed when the function lock lever is operated.                                          | Release ON                   | Lock OFF                      |                                                                                                       |
| B 31 OFF               | CLOGGING OF END AIR CLEANER              | Clogging of the END air cleaner is detected.                                                            | Detection ON                 | Usually OFF                   |                                                                                                       |
| B 32 OFF               | REAR DRUM BRAKE PEDAL LIMIT SWITCH       | Foot brake operating status display                                                                     | Operation ON                 | Not operated OFF              |                                                                                                       |
| ND 19<br>DIGITAL INPUT |                                          |                                                                                                         |                              |                               |                                                                                                       |
| B 33 OFF               | RADIATOR LEVEL SENSOR                    | The displayed value is changed depending on the level of the cooling water.                             | Specified level or higher ON | Specified level or higher OFF |                                                                                                       |
| B 34 OFF               | GENERATION SIGNAL                        | The displayed value is changed depending on the generation signal of the alternator.                    | EG ON ON                     | EG OFF OFF                    |                                                                                                       |
| B 35 OFF               | ENGINE OIL FILTER                        | The displayed code is changed according to the type of the engine oil filter.                           | Stop ON                      | Normal OFF                    |                                                                                                       |
| B 36 OFF               | THIRD DRUM BRAKE PEDAL LIMIT SWITCH      | Foot brake operating status display                                                                     | Operation ON                 | Not operated OFF              |                                                                                                       |
| ND 50<br>DIGITAL INPUT |                                          |                                                                                                         |                              |                               |                                                                                                       |
| B 37 OFF               | HYD. OIL TEMP.                           | The displayed code is changed according to the hydraulic temperature.                                   | Specified level or higher ON | Specified level or lower OFF  | * The components are normal if the values are changed when the respective condition is not satisfied. |
| B 38 OFF               | CONTROL PRIMARY PRESSURE                 | The displayed code is changed according to the primary pressure.                                        | Specified level or higher ON | Specified level or lower OFF  |                                                                                                       |
| B 39 OFF               | FRONT DRUM BRAKE FAULT POSITION          | The displayed code is changed according to the position of the front drum brake adjustment switch.      | High ON                      | Normal OFF                    |                                                                                                       |
| B 40 OFF               | REAR DRUM BRAKE FAULT POSITION           | The displayed code is changed according to the position of the rear drum brake adjustment switch.       | High ON                      | Normal OFF                    |                                                                                                       |
| ND 51<br>DIGITAL INPUT |                                          |                                                                                                         |                              |                               |                                                                                                       |
| B 41 OFF               | FRONT DRUM BRAKE FAULT POSITION          | The displayed code is changed according to the position of the front drum brake adjustment switch.      | High ON                      | Normal OFF                    |                                                                                                       |
| B 42 OFF               | ENGINE POSITION                          | The displayed code is changed according to the position of the ignition switch.                         | Gear position ON             | Other positions OFF           |                                                                                                       |
| B 43 OFF               | FRONT DRUM BRAKE COOLING OIL TEMPERATURE | The displayed code is changed according to the oil temperature in the front drum brake cooling line.    | Specified level or higher ON | Specified level or lower OFF  |                                                                                                       |
| B 44 OFF               | REAR DRUM BRAKE COOLING OIL TEMPERATURE  | The displayed code is changed according to the oil temperature in the rear drum brake cooling line.     | Specified level or higher ON | Specified level or lower OFF  |                                                                                                       |
| ND 52<br>DIGITAL INPUT |                                          |                                                                                                         |                              |                               |                                                                                                       |
| B 45 OFF               | COOLING OIL TEMPERATURE                  | The displayed code is changed according to the oil temperature in the cooling line filter.              | Clear ON                     | Normal OFF                    |                                                                                                       |
| B 46 OFF               | TRAILER POSITION                         | The displayed code is changed according to the position of the trailer lock switch.                     | Release ON                   | Lock OFF                      |                                                                                                       |

\* The LMF bypass switch is effective (ON is displayed) only when the set of the "Bypass" position and the LMF is malfunctioned, and if it is ineffective even if it is set to the "ON" position when the LMF operates normally.

### 12.4 FAULT LOG DISPLAY

The logs of faults which have been found by the self check of the total controller are stored in the controller, and can be displayed on the display screen of the gauge cluster.

If faults do not re-appear on job sites, first, check the fault log display for the convenience of troubleshooting.

#### 1. Display procedures


- (1) Set the key switch to the "ON" position.
- (2) Enter the fault finding mode.  
(Push both of the check switch and buzzer switch at the same time and hold them for 5 sec. or longer.)
- (3) Push the check switch and hold it for 5 sec. or longer while the machine is in the status display mode.  
Then, the fault logs are displayed.

(Example)

If no fault has occurred in the past:



If faults have occurred in the past:



- (4) The displayed fault logs remain displayed on the screen for an hour. If there are four or more fault logs to be displayed at a time, the displayed fault logs are changed automatically.

(Example) (a)

|               |
|---------------|
| 5000 Hr       |
| A-2 AJ ERROR  |
| C-7 D/O ERROR |
| F-1 S/M ERROR |



Displayed alternately

(b)

|             |
|-------------|
| 5000 Hr     |
| D-2 PV ERR  |
| D-3 PV ERR. |

- (5) To display the logs of faults occurred at other time (for example, logs of faults occurred at the time other than 5000 Hr), switch the display with the display screen selector switch  $\Delta$  or  $\nabla$ .  
Former fault logs can be displayed by pushing the display screen selector switch  $\Delta$ , and later logs can be displayed by pushing the display screen selector switch  $\nabla$ .
- (6) To end the fault log display push the setting switch. Then, the status display mode returns.


## 2. Deletion of fault logs

- (1) Display the fault logs occurred.
- (2) Push the zero switch and hold it for 5 sec. or longer.  
All the fault logs occurred are deleted.
- (3) After the deletion is completed, the message "NO ERROR" appears on the display screen.

## 12. GAUGE CLUSTER

### 3. Notes on fault logs

- Even when a fault occurs, if the same type fault already occurred in the past, and the log of the fault has already been stored, a new log of the fault is not stored.
- The hour indicated in the hourmeter on the display is a reference (for the replacement of the controller), and indicates the total period of the controller operation. It is not related to the hourmeter on the carrier.



Owing to the facts above, be sure to delete fault logs after faults are corrected.

It is recommended to record the hourmeter value of the controller together with that of the hourmeter of the carrier.



## 4. Contents of fault log display

| CONTENTS OF DISPLAY | SELF CHECK         | USE                                                   |
|---------------------|--------------------|-------------------------------------------------------|
| A-1 A/I ERROR       | (SELF CHECK 7) D1  | Main winch (front drum) motor speed adjusting trimmer |
| A-2 A/I ERROR       | (SELF CHECK 7) D2  | Aux. winch (rear drum) motor speed adjusting trimmer  |
| A-3 A/I ERROR       | (SELF CHECK 7) D3  | Boom winch motor speed adjusting trimmer              |
| A-6 A/I ERROR       | (SELF CHECK 7) D8  | Tugline trimmer                                       |
| A-7 A/I ERROR       | (SELF CHECK 8) D0  | Hand throttle                                         |
| A-8 A/I ERROR       | (SELF CHECK 8) D1  | Fool throttle                                         |
| A-9 A/I ERROR       |                    | Aux. winch (rear drum) motor pressure sensor          |
| A-10 A/I ERROR      |                    | Third winch motor pressure sensor                     |
| A-11 A/I ERROR      | (SELF CHECK 8) D4  | Swing pump pressure sensor                            |
| A-12 A/I ERROR      | (SELF CHECK 8) D5  | Third (jib) motor speed adjusting trimmer             |
| A-13 A/I ERROR      | (SELF CHECK 8) D8  | Main winch raising pressure sensor                    |
| A-14 A/I ERROR      | (SELF CHECK 8) D7  | Main winch lowering pressure sensor                   |
| A-15 A/I ERROR      | (SELF CHECK 8) D8  | Aux. winch raising pressure sensor                    |
| A-16 A/I ERROR      | (SELF CHECK 9) D2  | Aux. winch lowering pressure sensor                   |
| A-17 A/I ERROR      | (SELF CHECK 9) D3  | Third (jib) winch raising pressure sensor             |
| A-18 A/I ERROR      | (SELF CHECK 9) D4  | Third (jib) winch lowering pressure sensor            |
| A-19 A/I ERROR      | (SELF CHECK 9) D5  | Main winch clutch pressure sensor                     |
| A-20 A/I ERROR      | (SELF CHECK 9) D6  | Aux. winch clutch pressure sensor                     |
| A-21 A/I ERROR      | (SELF CHECK 10) D0 | Third winch clutch pressure sensor                    |
| A-24 A/I ERROR      | (SELF CHECK 10) D3 | Boom raising pressure sensor                          |
| A-25 A/I ERROR      | (SELF CHECK 10) D4 | Boom lowering pressure sensor                         |
| A-26 A/I ERROR      |                    | Jib tension                                           |
| C-1 D/O ERR         |                    | Battery relay                                         |
| C-3 D/O ERR         |                    | Hyd. oil heat relay                                   |
| C-4 D/O ERR         |                    | Boom pump inching solenoid                            |
| C-6 D/O ERR         | (SELF CHECK 3) D4  | Main pump inching solenoid                            |
| C-7 D/O ERR         | (SELF CHECK 4) D0  | Main winch (front drum) clutch CLM solenoid           |
| C-8 D/O ERR         | (SELF CHECK 4) D1  | Main winch (front drum) clutch ESM solenoid           |
| C-10 D/O ERR        | (SELF CHECK 4) D3  | Aux. winch (rear drum) clutch CLA solenoid            |
| C-11 D/O ERR        | (SELF CHECK 4) D4  | Aux. winch (rear drum) clutch ESA solenoid            |
| C-13 D/O ERR        | (SELF CHECK 4) D6  | Third winch (third drum) clutch CLT solenoid          |
| C-14 D/O ERR        | (SELF CHECK 5) D0  | Third winch (third drum) clutch EST solenoid          |
| C-15 D/O ERR        | (SELF CHECK 5) D1  | Main winch (front drum) motor boost solenoid          |
| C-16 D/O ERR        | (SELF CHECK 5) D2  | Aux. winch (rear drum) motor boost solenoid           |
| C-17 D/O ERR        | (SELF CHECK 5) D3  | Third winch (third drum) motor boost solenoid         |
| C-18 D/O ERR        | (SELF CHECK 5) D4  | Main winch drum turn detection gnp                    |
| C-19 D/O ERR        | (SELF CHECK 5) D6  | Aux. winch drum turn detection grip                   |
| C-20 D/O ERR        | (SELF CHECK 5) D6  | Main winch C/V solenoid                               |
| C-21 D/O ERR        | (SELF CHECK 6) D0  | Aux. winch C/V solenoid                               |
| C-22 D/O ERR        | (SELF CHECK 6) D1  | Third winch C/V solenoid                              |
| C-23 D/O ERR        |                    | Wind alarm output                                     |
| C-26 D/O ERR        | (SELF CHECK 6) D5  | Main winch free fall lamp                             |
| C-27 D/O ERR        | (SELF CHECK 6) D6  | Aux. winch free fall lamp                             |
| C-28 D/O ERR        | (SELF CHECK 7) D0  | Third winch free fall lamp                            |

## 12. GAUGE CLUSTER




| CONTENTS OF DISPLAY |             | SELF CHECK         | USE                                                                      |
|---------------------|-------------|--------------------|--------------------------------------------------------------------------|
| D-1                 | P/V ERR     | (SELF CHECK 1) D0  | Boom remote control raising pressure reducing proportional valve         |
| D-2                 | P/V ERR     | (SELF CHECK 1) D1  | Boom remote control lowering pressure reducing proportional valve        |
| D-3                 | P/V ERR     | (SELF CHECK 1) D2  | Main winch remote control raising pressure reducing proportional valve   |
| D-4                 | P/V ERR     | (SELF CHECK 1) D3  | Main winch remote control lowering pressure reducing proportional valve  |
| D-5                 | P/V ERR     | (SELF CHECK 1) D4  | Aux. winch remote control raising pressure reducing proportional valve   |
| D-6                 | P/V ERR     | (SELF CHECK 1) D5  | Aux. winch remote control lowering pressure reducing proportional valve  |
| D-7                 | P/V ERR     | (SELF CHECK 1) D6  | Third winch remote control raising pressure reducing proportional valve  |
| D-8                 | P/V ERR     | (SELF CHECK 2) D0  | Third winch remote control lowering pressure reducing proportional valve |
| D-9                 | P/V ERR     | (SELF CHECK 2) D1  | Main winch (front drum) motor tilting angle proportional valve           |
| D-10                | P/V ERR     | (SELF CHECK 2) D2  | Aux. winch (rear drum) motor tilting angle proportional valve            |
| D-11                | P/V ERR     | (SELF CHECK 2) D3  | Swing constant speed proportional valve                                  |
| D-12                | P/V ERR     | (SELF CHECK 2) D4  | Main pump reducing horsepower proportional valve                         |
| D-13                | P/V ERR     | (SELF CHECK 2) D5  | Third winch motor tilting angle proportional valve                       |
| D-14                | P/V ERR     | (SELF CHECK 2) D6  | Swing reaction proportional valve                                        |
| D-15                | P/V ERR     | (SELF CHECK 3) D0  | Boom pump reducing horsepower proportional valve                         |
| H-3                 | ROM DATA    | (SELF CHECK *1) D2 | Abnormal total controller adjustment value                               |
| H-4                 | MFG. SET    | (SELF CHECK *1) D3 | Wrong total controller adjustment                                        |
| H-5                 | M/L RECEIVE | (SELF CHECK *1) D4 | Faulty communication with LMI                                            |
| H-6                 | M/C RECEIVE | (SELF CHECK *1) D5 | Faulty communication with total controller                               |
| NO ERROR            |             |                    |                                                                          |

---


## **13. TOTAL CONTROLLER**



13.1 ARRANGEMENT OF TOTAL CONTROLLER



13.2 COMPOSITION OF SYSTEM



## 13.2.1 OUTPUT RELATION TO CONTROLLER

| Items                         | Input/Output | Signal types                         | Outline                                                                                                                                                                                                                                                                                            |
|-------------------------------|--------------|--------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Indicator (GAUGE CLUSTER)     | Input/Output | Serial communication                 | The SW setting data are received from the indicator. The indication signals of the OK monitor, engine speed, lifting height, wind speed, faults, etc. are transmitted depending on the SW setting conditions.                                                                                      |
| M/L (LMI)                     | Input/Output | Serial communication + Digital input | The changes in lifting height during boom and jib hoisting, faults signals, and number of part lines are transmitted from the M/L. The operating direction of the winch operation lever is transmitted to the M/L. The signals referring to automatic stop are input from the M/L in digital form. |
| Maintenance personal computer | Input/Output | Serial communication                 | This PC is used for down-loading of programs.                                                                                                                                                                                                                                                      |
| Hand throttle                 | Input        | Analogue 0 to 5 V                    | The grip signals from the engine throttle are input.                                                                                                                                                                                                                                               |
| Sensor                        | Input        |                                      | The values from the pressure sensor, engine turn sensor, wind speed sensor, etc. are input.                                                                                                                                                                                                        |
| Cab inside switch/trimmer     | Input        |                                      | The values from the switches and trimmers in the cab are input.                                                                                                                                                                                                                                    |
| Proportional valve            | Output       | 24 V<br>100 to 700 mA                | PWM output<br>Constant current circuit (Max 1 A)<br>Disconnection detection<br>With short-circuit protection                                                                                                                                                                                       |
| Solenoid valve                | Output       | 24 V<br>1 A                          | Disconnection detection<br>With short-circuit protection                                                                                                                                                                                                                                           |

## 13. TOTAL CONTROLLER

### 13.3 FUNCTION OF TOTAL CONTROLLER

The total controller features the following main three functions:

(1) Control of main body, (2) Cluster control, and (3) Adjustment

The function items and outline are shown below

#### (1) Control of main body

| No. | Function items                                                |
|-----|---------------------------------------------------------------|
| 1   | Accelerator control & power off                               |
| 2   | Power control                                                 |
| 3   | Speed control of front and rear, third, boom drums            |
| 4   | Swing reaction                                                |
| 5   | Boom raising deceleration                                     |
| 6   | Boom raising stop                                             |
| 7   | Boom lowering slow stop                                       |
| 8   | Jib raising deceleration / Jib raising stop                   |
| 9   |                                                               |
| 10  | Jib lowering slow stop                                        |
| 11  | Front drum hoisting stop                                      |
| 12  | Rear drum hoisting stop                                       |
| 13  |                                                               |
| 14  | Lifting height gauge (option)                                 |
| 15  | Winch control                                                 |
| 16  | Boost control                                                 |
| 17  | Motor control                                                 |
| 18  | Main pump control / Boom pump control                         |
| 19  | Drum turn detection grip control (option)                     |
| 20  | Tagline control (Not used)                                    |
| 21  | Wind sensor (option)                                          |
| 22  | Lever interlock control                                       |
| 23  | Control of hoist deceleration when overhoist stop is canceled |
| 24  | Control of communication with LMI                             |
| 25  | Swing speed select, swing pump control                        |
| 26  | Hyd. oil heat                                                 |

#### (2) Cluster control

| No. | Function items                                                  |
|-----|-----------------------------------------------------------------|
| 1   | Indication control (refer to the pages relating to the cluster) |
| 2   | Communication control                                           |

#### (3) Adjustment function

| No. | Function items                                                      |
|-----|---------------------------------------------------------------------|
| 1   | Adjustment 3 Memory of high and low idle position and no-load speed |
| 2   | Adjustment 1 option setting                                         |
| 3   | Adjustment 3 Throttle range setting                                 |




## 1. ACCELERATOR CONTROL & POWER OFF

### (1) Accelerator control

Commands are sent to the ECU (Engine control unit) according to the input from the hand throttle or foot throttle. If the machine is equipped with both the throttles, priority is given to the throttle issuing more commands.

### (2) Measures against engine stop

- Four seconds after the key switch is set to the OFF position, the battery relay is de-energized.




If wiring of both the hand throttle and foot throttle is disconnected, output voltage to the ECU is 0 V. Low speed rotation and middle speed rotation can be switched by turning "ON" the auxiliary accelerator switch after turning "ON" the by-pass switch.

### 13. TOTAL CONTROLLER


#### 2. POWER CONTROL

The target speed is calculated by the hand throttle. Then, the tilting angle of the pump is controlled when the actual engine speed is slower than the target engine speed.

As the actual rotating speed is lower than the target rotating speed, the output current becomes greater. Note that the output current is great while the rotating speed is low, even when the speed difference is slight (for prevention of engine stall).




3. SPEED CONTROL OF FRONT, REAR, THIRD AND BOOM DRUMS



### 13. TOTAL CONTROLLER

#### (1) FR, RE, 3RD DRUM SPEED VARIABLE



The maximum current values at the remote control proportional valve and motor control proportional valve are controlled as shown in the graph above.

The orders of operation priority are shown below


- Remote control proportional valve

Stop of front or rear drum > Deceleration of front or rear drum > Free fall > Trimmer control  
Lever inter lock

- Motor control proportional valve

Drum stop > Free fall acceleration > Main pump inching speed > Trimmer control (control during power lowering) > Lifting mode speed control  
Lever inter lock > Motor control

#### (2) Boom Drum Speed Control





- If the engine speed is increased from low to high under the characteristic status (1), the current value is close to that of the characteristic status (2)

When the trimmer is set to the maximum position, the proportional valve is fully opened, and the status becomes identical to that of no trimmer.




4. SWING REACTION

A reaction is applied to the lever depending on swing loads.



### 13. TOTAL CONTROLLER




5. BOOM RAISING DECELERATION
6. BOOM RAISING STOP
7. BOOM LOWERING SLOW STOP



- When boom raise deceleration signals are input (input when the boom reaches the angle smaller than the boom upper limit angle by 10°), the boom raise remote control proportional valve is controlled and the boom raising speed is decelerated according to the boom angle.
- \*1 If the communication with the M/L is faulty, the deceleration is performed by decreasing the current at the proportional valve (to 400 mA in 5 sec.) regardless of fluctuations in the boom angle depending on the elapsed time after the raising deceleration signal is input.
- When the boom lower stop signals are input, the current value at the boom lower proportional valve is minimized within 1.5 seconds, and the boom is slowly stopped.
- \*2 (If current at the proportional valve is 625 mA or less at the startup of control (when the stop signal is input), control is started from the current value. [The period required for minimization of current at the proportional valve is shorter than 1.5 sec.]

**IF THE JIB IS RAISED BY THIRD DRUM**

- 8. JIB RAISING DECELERATION / JIB RAISING STOP
- 10. JIB LOWERING SLOW STOP




- When jib raise deceleration signals are input (input when the jib reaches the angle smaller than the jib upper limit angle by 10°), the jib raise remote control proportional valve is controlled and the jib raising speed is decelerated according to the jib angle.
- \*1 If the communication with the ML is faulty, the deceleration is performed by decreasing the current at the proportional valve (to 400 mA in 4 sec.) regardless of fluctuations in the boom angle depending on the elapsed time after the raising deceleration signal is input.
- When the jib lower stop signals are input, the current value at the jib lower proportional valve is minimized within 1.7 seconds, and the jib is slowly stopped.
- \*2 (If current at the proportional valve is 591 mA or less at the startup of control (when the stop signal is input), control is started from the current value. [The period required for minimization of current at the proportional valve is shorter than 1.7 sec.]


### 13. TOTAL CONTROLLER

11. FR. DRUM HOISTING STOP


12. RE. DRUM HOISTING STOP



FR. DRUM HOIST PROPORTIONAL VALVE CURRENT




RE. DRUM HOIST PROPORTIONAL VALVE CURRENT





## 14. LIFTING HEIGHT GAUGE (option)




- (1) The number of drum rotation is detected with the drum turn sensor as the pulse count
  - (2) When there is any winch pressure sensor input, the changes are regarded to occur to the hoisting side and the pulse count is increased. When in other cases, they are regarded to occur to the lowering side and the pulse count is decreased.
  - (3) The number of wire rope wraps on the rotating drum is calculated on the basis of the wire rope wraps adjusted with the cluster as a standard.
  - (4) The length of unwound wire rope is calculated from the coefficients and pulse numbers of the wire rope wraps.
  - (5) The lifting height by the winch is calculated by dividing by the number of part line.
  - (6) The boom point height data are received from the LMI.
  - (7) The difference between the height at the zero reset and current height is calculated to find the height lifted by the boom.
  - (8) Both of them are added to find the changes in actual lifting height, and the changes are indicated on the display screen of the cluster.
- Option setup is required to enable this control function (refer to 13.5.2.1 OPTION SETTING).

### 13. TOTAL CONTROLLER

#### 15. WINCH CONTROL (Valid only when the wet type free fall winch is optionally set up.)

- (1) Control Over Neutral Mode Selection
- (2) Winch Operation Solenoid Valve Control



- 1) When power is supplied  
The machine always starts running in the neutral brake mode.
- 2) Switching from the brake mode to the free fall mode

| Condition                                                                                                                                     |                             | Output                                                                                                                                                                |
|-----------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A. The free fall lock switch is set released.<br>And function lock lever is neutral position.                                                 | } ..... → Free release "ON" | <ul style="list-style-type: none"> <li>• Select the free mode.</li> <li>• Light up the free fall indicator lamp.</li> <li>• Release the main pump control.</li> </ul> |
| B. The foot brake is depressed (the pressure switch is set to the "ON" position).<br>C. The free selector switch is set to the "ON" position. |                             |                                                                                                                                                                       |


- 3) Change from free fall mode to brake mode  
Depress the foot brake again, and set the free fall mode selector switch to the ON position. Or, when the free fall permission signal is in the "OFF" status
- 4) Control of second valve in free fall/brake mode  
The front drum CLM (SOL 22) is controlled as shown in the table below.

| Lever control | Mode         |               |
|---------------|--------------|---------------|
|               | Neutral free | Neutral brake |
| Hoisting      | X            | X             |
| Lowering      | X            | X             |
| Neutral       | O            | X             |

O : Energized    X : De-energized

- The ON/OFF status of the lever operation is judged by the value from the pressure sensor. (Lever operation is judged to be ON if the pressure is 0.343 MPa or more. It is judged to be OFF if the pressure is not more than 0.196 MPa or less.)

The rear drum CLA (SOL-23) and the third drum CLT (SOL-24) are controlled in a similar manner. When the lever is at the neutral position while the free fall mode is selected, output from the front drum (rear drum and third drum) down remote control proportional valve should depend on the clutch pressure.



### 13. TOTAL CONTROLLER

---

#### 5) Emergency solenoid valve control

For the front drum, when either of the conditions below is satisfied, ESM (Sol-19) is energized to prevent a drop of a lifted load.

- (A) The clutch pressure is reduced although the brake mode is selected.
- (B) The clutch pressure is reduced although the lever is operated during the free fall mode.  
For the rear drum and the third drum, the LSA (Sol-20) and EST (Sol-21) are controlled, respectively.


---

#### Note

Once the emergency solenoid valve is actuated, the current operation mode cannot be altered to the free fall mode unless power to the controller is shut down. Even after the main power supply is shut down while the emergency solenoid valve is being actuated, power supply to the controller remains alive for ninety seconds after the engine is stopped. In this period, the residual clutch pressure is removed.

---

(3) FREE FALL ACCELERATION




The falling speed can be increased by idling the motor during the free fall.  
 The speed is controlled as shown in the table below.

| Conditions                                                                                                                                                                                                                                                    | Procedures                                                                                                                                                                                            |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. Free fall mode is selected<br>2. The control lever is at the neutral position<br>3. The "FREE FALL SPEED SWITCH" on the left panel is in the "High" status<br>4. The foot brake is not depressed.<br>(Clutch pressure $\geq 1.06$ MPa when free fall mode) | <ul style="list-style-type: none"> <li>C/V solenoid is energized</li> <li>Current at the drum control proportional valve is maintained at 750 mA (The motor keeps running at a high speed)</li> </ul> |
| Any of conditions shown above is not satisfied                                                                                                                                                                                                                | <ul style="list-style-type: none"> <li>L/V Solenoid is de-energized</li> <li>Other conditions are restored to those of the normal control</li> </ul>                                                  |


### 13. TOTAL CONTROLLER

The drum motor control proportional valve is controlled according to the depression of the foot pedal (clutch pressure)

PROPORTIONAL VALVE CURRENT (mA)



### 16. BOOST CONTROL



To prevent a momentary drop of a lifted load, apply a constant boost to the motor while the lever is in the neutral position.


The boost solenoid valve is controlled as shown in the table below.

| Lever                        | Boost solenoid valve                                                                                                                                                                         |
|------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Neutral                      | Energized                                                                                                                                                                                    |
| Neutral → Hoisting, lowering | Immediately de-energized                                                                                                                                                                     |
| Hoisting, lowering → Neutral | Energized a second after the lever is returned to the neutral position<br>Remained de-energized if the lever is operated within a second after the lever is returned to the neutral position |

When the front drum or rear drum is stopped, the boost solenoid valve is controlled as shown in the table below.

| Stop signal              | Boost solenoid valve                                  |
|--------------------------|-------------------------------------------------------|
| Front drum hoisting stop | Front drum boost solenoid is immediately de-energized |
| Rear drum hoisting stop  | Rear drum boost solenoid is immediately de-energized  |
| Third drum hoisting stop | Third drum boost solenoid is immediately de-energized |


17. MOTOR CONTROL




(1) When hoisting or lowering the drums during the brake mode or free fall mode, current at the drum control proportional valve is controlled as shown in the graph below.

### 13. TOTAL CONTROLLER

(A) Current at the drum control proportional valve is fluctuated according to the operation of the lever.



(B) Maximum current value at the drum control proportional valve is controlled according to the E/G speed with no-load.





(2) If the winches are in the automatic stop statuses and the control lever is not being operated toward the safe side, output to the corresponding motor control proportional valve shall be the minimum (350mA).

(3) Luffing mode speed control

While the luffing mode is selected with the ML (to be selected by communication from the ML), speed of the third drum motor is limited to the certain level by control of the output from the third drum motor control proportional valve.

Current at the proportional valve should be limited to the certain level so that the third drum motor control pressure is 2.11 MPa (=3.37 V) or less.

(4) Clamshell mode

While the working mode switch is turned on (– low speed is selected (heavy load clamshell)), control of the front drum motor and the rear drum motor should be fixed to a low speed (current at the proportional valve should be fixed to 300 mA).


(As for the tower type, this step can be ignored.)

(5) The order of operation priority is shown below

Motor control (2) / Lever inter lock > Free fall acceleration > Main pump inching speed > Motor control (1) A , (1) B . (Whichever smaller one between the value controlled by A, controlled by B is selected as the maximum value) > Luffing mode speed control (3)

### 13. TOTAL CONTROLLER

#### \*8 MAJN PUMP CONTROL / BOOM PUMP CONTROL



The pump control solenoid valve is controlled under the conditions shown in the table below.

| Conditions                                                                                                                                                          | Pump control solenoid                                                                                                                | Statuses                                                                 |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------|
| 1. The inching switch is turned off. No input from the front, rear, and the third pressure sensors is detected, and the travel signal is in the "OFF" status.       | Pump control solenoid<br>Main pump inching solenoid<br>Energized                                                                     | Main pump at the minimum flow rate                                       |
| 2. The inching switch is turned off, and no input from the boom pressure sensor is detected.                                                                        | Boom pump inching solenoid<br>Energized                                                                                              | Boom pump at the minimum flow rate                                       |
| 3. The inching switch is turned off, and input from any of the front, rear, and the third pressure sensors is detected, or the travel signal is in the "ON" status. | Main pump inching solenoid<br>De-energized                                                                                           | Main pump at a normal flow rate                                          |
| 4. The inching switch is turned off, and input from the boom pressure sensors is detected.                                                                          | Boom pump inching solenoid<br>De-energized                                                                                           | Boom pump at a normal flow rate                                          |
| 5. The inching switch is turned on (inching).                                                                                                                       | Main pump inching solenoid<br>Boom pump inching solenoid<br>Energized<br>Motor control is fixed to a low speed.<br>{Current: 350 mA} | Main pump at the minimum flow rate<br>Boom pump at the minimum flow rate |



Priority is given as shown below.

Free fall control > Inching control [5 in the table above] > Inching control (feathering) [from 1. to 4.]

## 19. DRUM TURN DETECTION GRIP CONTROL

(option)

The grip solenoid valve is controlled according to the input to the drum turn sensor.




- The grip solenoid output is turned to "OFF" when the drum speed is faster than the specified speed. Specified speed = Drum rotating speed approx. 61.5 m/min = 4 pulses or more per 50 msec
- Option setup is required in order to enable this control.

### 13. TOTAL CONTROLLER

#### 20. TAGLINE CONTROL (option)

In this machine, tagline output is carried out by the separate proportional valve AMP, and no output from the total controller is detected.


#### 21. WIND SENSOR (option)



Wind velocity is calculated with the input voltage from the wind velocity sensor, and displayed on the cluster gauge.

- Option setup is required to enable the display function.

## 22. LEVER INTERLOCK CONTROL



The machine is stopped when the engine is started or the function lock lever is set to the working position with the lever set to the detent.

- (1) Before the engine is started  
Current value at the proportional valves is regarded as the minimum value (150 mA).
- (2) After the engine is started  
Function lock signals are checked after electricity generation signals are input.

### 13. TOTAL CONTROLLER

- (3) When the function lock signals are in the "ON" status  
 Input at the pressure sensors is checked, and the minimum value when the lever is set to the "ON" position is maintained. Once the lever is set to the neutral position, the proportional valve is normally controlled. When the lever is at the neutral position, the proportional valve is normally controlled.
- (4) When the function lock signals are in the "OFF" status  
 When the function lock signals are set to the "ON" status, the procedures shown in the 3) above are performed.
- (5) This interlock is actuated whenever electricly generation signals or function lock signals are set to the "OFF" status.

### 23. CONTROL OF HOIST DECELERATION WHEN OVERHOIST STOP IS CANCELED

When overhoist is canceled (judged by M/L communication data), current at the remote control proportional valves for hoisting the front drum and rear drum is adjusted to that of the inching speed control (375 mA : constant).



Output current at the drum motor control proportional valve should be adjusted to 350 mA (constant)(only when the lever is being operated).

### 24. CONTROL OF COMMUNICATION WITH M/L

#### Communications

| M/L → TC                              |                                         | TC → M/L                    |
|---------------------------------------|-----------------------------------------|-----------------------------|
| Main/jib                              | Number of part lines on main winch      | Main winch raising ON/OFF   |
| Crane/luffing                         | Number of part lines on aux. winch      | Aux. winch raising ON/OFF   |
|                                       | Boom point height                       | Aux. winch lowering ON/OFF  |
|                                       | Jib point height                        | Third winch raising ON/OFF  |
| Hook overhoist release ON/OFF         | Boom angle                              | Boom raising ON/OFF         |
| Boom overhoist release ON/OFF         | Jib angle                               | Boom lowering ON/OFF        |
| Overload and overhoist release ON/OFF | Boom length                             |                             |
| Main hook overhoist ON/OFF            | Jib length                              |                             |
| Aux. hook overhoist ON/OFF            |                                         | Third winch lowering ON/OFF |
| Crane boom overhoist ON/OFF           | Working mode/working range outside mode | Main winch lowering ON/OFF  |
|                                       | Working mode/set up mode                |                             |
| Luffing jib overhoist ON/OFF          |                                         |                             |
| Luffing boom overhoist ON/OFF         |                                         |                             |
| Crane jib overhoist ON/OFF            | English / Japanese                      |                             |


25. SWING SPEED SELECT • SWING PUMP CONTROL



- When the swing control signal in the "OFF" status for ten seconds or longer, current value is maximized (700 mA)  
(Characteristics shown above can be controlled as soon as the swing control signal is set to the "ON" status.)

### 13. TOTAL CONTROLLER

#### 26. HYD. OIL HEAT






|                                                 |
|-------------------------------------------------|
| Control                                         |
| All the levers are set to the neutral positions |
| Any of the levers is operated                   |

|              |
|--------------|
| Relay        |
| Energized    |
| De-energized |



### 13.4 TOTAL CONTROLLER (HARDWARE)

#### 13.4.1 OUTLINE



### 13. TOTAL CONTROLLER

#### 13.4.2 SPECIFICATIONS OF TOTAL CONTROLLER OUTPUT

##### 1. ANALOGUE INPUT [A]

| Item | Name                                               | Range                            | Input voltage   | Trouble judgment                                                                                | Note                                                      |
|------|----------------------------------------------------|----------------------------------|-----------------|-------------------------------------------------------------------------------------------------|-----------------------------------------------------------|
| 1    | Fr. drum motor speed adjusting trimmer             | 0 to FULL                        | 0.43 to 5 V     | Less than 0.2 V                                                                                 | Broken down wire resistance 470 Ω<br>All resistance 5 K Ω |
| 2    | Re. drum motor speed adjusting trimmer             | ↑                                | ↑               | ↑                                                                                               | ↑                                                         |
| 3    | Boom motor speed adjusting trimmer                 | ↑                                | ↑               | ↑                                                                                               | ↑                                                         |
| 4    | Spinn. A/D                                         | -                                | -               | -                                                                                               | -                                                         |
| 5    | Spinn. A/D                                         | -                                | -               | -                                                                                               | -                                                         |
| 6    | Tagline trimmer (Not used)                         | -                                | -               | -                                                                                               | -                                                         |
| 7    | Hand throttle potentiometer                        | LOW to HIGH                      | 0.7 to 5V       | ↑                                                                                               | Broken down wire resistance 470 Ω<br>All resistance 5k Ω  |
| 8    | Foot throttle potentiometer (option)               | ↑                                | 1.0V to 4.4V    | ↑                                                                                               | Broken down wire resistance 220 Ω<br>All resistance 2 K Ω |
| 9    | Rear drum control pressure Sensor (Not used)       | 0 to 427 psi<br>(0 to 2.94 MPa)  | 0 to 4.5 V      | 0.1V or less or 4.9V or more. Or, 3V or more remains input for 3 sec. or longer after power ON. |                                                           |
| 10   | Third drum control pressure sensor                 | ↑                                | ↑               | ↑                                                                                               |                                                           |
| 11   | Swing pump pressure sensor                         | 0 to 7110 psi<br>(0 to 49 MPa)   | ↑               | ↑                                                                                               |                                                           |
| 12   | Jib (third) motor speed adjusting trimmer (option) | 0 to FULL                        | 0.43 to 5V      | Less than 0.2 V                                                                                 | Broken down wire resistance 470 Ω<br>All resistance 5 K Ω |
| 13   | Fr. drum hoisting pressure sensor                  | 0 to 427 psi<br>(0 to 2.94 MPa)  | 0.5V to 4.5V    | 0.1V or less or 4.9V or more. Or, 3V or more remains input for 3 sec. or longer after power ON. |                                                           |
| 14   | Fr. drum lowering pressure sensor                  | ↑                                | ↑               | ↑                                                                                               |                                                           |
| 15   | Re. drum hoisting pressure sensor                  | ↑                                | ↑               | ↑                                                                                               |                                                           |
| 16   | Re. drum lowering pressure sensor                  | ↑                                | ↑               | ↑                                                                                               |                                                           |
| 17   | 3rd. drum hoisting pressure sensor (option)        | ↑                                | ↑               | ↑                                                                                               |                                                           |
| 18   | 3rd. drum lowering pressure sensor (option)        | ↑                                | ↑               | ↑                                                                                               |                                                           |
| 19   | Fr. drum clutch pressure sensor                    | 0 to 2844psi<br>(0 to 19.8 MPa)  | ↑               | ↑                                                                                               |                                                           |
| 20   | Re. drum clutch pressure sensor                    | ↑                                | ↑               | ↑                                                                                               |                                                           |
| 21   | 3rd. drum clutch pressure sensor (option)          | ↑                                | ↑               | ↑                                                                                               |                                                           |
| 22   | Wind velocity sensor (option)                      | 2mi/s to 90m/s                   | AC0.67 to 44.3V | -                                                                                               | AC Input                                                  |
| 23   | Vacancy                                            | -                                | -               | -                                                                                               |                                                           |
| 24   | Boom raise pressure sensor                         | 0 to 427 psi<br>(0 to 2.94 MPa)  | 0.5 to 4.5 V    | 0.1V or less or 4.9V or more. Or, 3V or more remains input for 3 sec. or longer after power ON. |                                                           |
| 25   | Boom lower pressure sensor                         | ↑                                | ↑               | ↑                                                                                               |                                                           |
| 26   | Tension signal (Not used)                          | 0 to 254,550 lbs<br>(0 to 120 t) | 0 to 5V         | -                                                                                               |                                                           |

## 2. PULSE INPUT (INTERRUPT)(E)

| Item | Name                  | Status                      | Signal level     | Trouble judgment | Note                                              |
|------|-----------------------|-----------------------------|------------------|------------------|---------------------------------------------------|
| 1    | Eng. return sensor    | 0 to 2500 min <sup>-1</sup> | Vp (0.3 to 45 V) | NO               | Electromagnetic pick-up:<br>137pulses/min : 5 kHz |
| 2    | Fr. drum turn sensor  | 0 to 500 min <sup>-1</sup>  | GND/OPEN         | ↑                | Proximity sensor<br>78 pulses/min : 650 Hz        |
| 3    | Re. drum turn sensor  | -                           | ↑                | ↑                | ↑                                                 |
| 4    | Interrupt input spare | -                           | ↑                | ↑                | Proximity sensor                                  |

## 3. Digital Input (B)

| Item | Name                                           | Status                                         | Signal level | Note |
|------|------------------------------------------------|------------------------------------------------|--------------|------|
| 1    | Fr. drum free fall                             | Free/Brake                                     | GND/OPEN     | No   |
| 2    | Re. drum free fall                             | Free/Brake                                     | GND/OPEN     | ↑    |
| 3    | 3rd. drum free fall (option)                   | Free/Brake                                     | GND/OPEN     | ↑    |
| 4    | ECU on signal                                  | ON/OFF                                         | GND/OPEN     | ↑    |
| 5    | Vacancy                                        | -                                              | -            | ↑    |
| 6    | Swing neutral mode selection (Free high speed) | Free high mode/Not free high mode              | +24V/OPEN    | ↑    |
| 7    | Jib (third) raising deceleration               | Deceleration/Normal                            | +24V/OPEN    | ↑    |
| 8    | Drum turn selection (option)                   | ON/OFF                                         | GND/OPEN     | ↑    |
| 9    | Fr. drum brake detect sensor (CEN)             | Brake ON/OFF                                   | GND/OPEN     | ↑    |
| 10   | Key switch "ON"                                | Key switch ON/OFF                              | +24V/OPEN    | ↑    |
| 11   | Inching selection switch                       | Inching/Normal                                 | GND/OPEN     | ↑    |
| 12   | Mode section                                   | Low/high                                       | GND/OPEN     | ↑    |
| 13   | E/G PSW                                        | E/G Stop/Work                                  | GND/OPEN     | ↑    |
| 14   | Moisture detection of the fuel filter          | Detection/Usually                              | +24V/OPEN    | ↑    |
| 15   | Boom raise stop                                | Stop/Normal                                    | OPEN/+24V    | ↑    |
| 16   | Boom lowering stop                             | Stop/Normal                                    | OPEN/-24V    | ↑    |
| 17   | Re. drum lower stop                            | Stop/Normal                                    | +24V/OPEN    | ↑    |
| 18   | Boom raise deceleration                        | Deceleration/Normal                            | +24V/OPEN    | ↑    |
| 19   | Re. drum hoist deceleration (Not used)         | Deceleration/Normal                            | +24V/OPEN    | ↑    |
| 20   | Fr. drum lowering stop                         | Normal/stop                                    | +24V/OPEN    | ↑    |
| 21   | Fr. drum hoisting stop                         | Stop/Normal                                    | OPEN/-24V    | ↑    |
| 22   | Re. drum hoisting stop                         | Stop/Normal                                    | OPEN/+24V    | ↑    |
| 23   | Tower raise signal (Not used)                  | Raise/Normal                                   | +24V/OPEN    | ↑    |
| 24   | Swing neutral mode selection (Brake)           | Brake mode/Not Brake mode                      | +24V/OPEN    | ↑    |
| 25   | Jib (3rd) drum lowering stop                   | Normal/stop                                    | +24V/OPEN    | ↑    |
| 26   | Propel control                                 | Control/Neutral                                | +24V/OPEN    | ↑    |
| 27   | Swing control                                  | Control/Neutral                                | +24V/OPEN    | ↑    |
| 28   | M/L redundancy                                 | Redundancy/Normal                              | +24V/OPEN    | ↑    |
| 29   | 3rd (Jib) drum hoisting stop                   | Normal/stop                                    | +24V/OPEN    | ↑    |
| 30   | Function lock                                  | Work/stop                                      | +24V/OPEN    | ↑    |
| 31   | Clogging of E/G air cleaner                    | Clogging/Normal                                | GND/OPEN     | ↑    |
| 32   | Re. drum brake detect sensor (CEN)             | Brake ON/OFF                                   | GND/OPEN     | ↑    |
| 33   | Water level                                    | Low level/Normal                               | GND/OPEN     | ↑    |
| 34   | Charge signal                                  | With power generation/Without power generation | +24V/OPEN    | ↑    |
| 35   | E/G oil filter clog                            | Clog/Normal                                    | GND/OPEN     | ↑    |
| 36   | 3rd. drum brake detect sensor (CEN)            | Brake ON/OFF                                   | GND/OPEN     | ↑    |
| 37   | Hydraulic oil temperature switch               | Higher temperature/Normal                      | GND/OPEN     | ↑    |
| 38   | Control primary pressure                       | Lower pressure/Normal                          | GND/OPEN     | ↑    |

### 13. TOTAL CONTROLLER

| Item | Name                                   | Status                    | Signal level | Note |
|------|----------------------------------------|---------------------------|--------------|------|
| 39   | Fr. drum free fall speed switch        | High/Normal               | GND/OPEN     | No   |
| 40   | Re. drum free fall speed switch        | High/Normal               | GND/OPEN     | ↑    |
| 41   | 3rd. drum free fall speed switch       | High/Normal               | GND/OPEN     | ↑    |
| 42   | E/G preheat                            | Preheat/Normal            | +24V/OPEN    | ↑    |
| 43   | Fr. drum brake cooling oil temperature | Higher temperature/Normal | GND/OPEN     | ↑    |
| 44   | Re. drum brake cooling oil temperature | Higher temperature/Normal | GND/OPEN     | ↑    |
| 45   | Cooling line filter                    | Clog/Normal               | GND/OPEN     | ↑    |
| 46   | Free fall release                      | Release/Lock              | +24V Pull Up | ↑    |

### 4. ANALOGUE OUTPUT [H]

| Item | Name                 | Status      | Signal level | Trouble judgment |
|------|----------------------|-------------|--------------|------------------|
| 1    | Accelerator signal 1 | Low to High | 1.0 to 4.0V  | NO               |
| 2    | Accelerator signal 2 | Low to High | 1.0 to 4.0V  | ↑                |

- Provide the external protection against short-circuit (resistance insertion).

### 5. PROPORTIONAL VALVE OUTPUT [D]

| Item | Name                             | Output current | Dither        | Trouble judgment                                                           |
|------|----------------------------------|----------------|---------------|----------------------------------------------------------------------------|
| 1    | Boom raising speed control       | 200 to 625mA   | 200mA-p 100Hz | The indicated value is 100 mA or lower and the feed back is 50 mA or lower |
| 2    | Boom lowering speed control      | ↑              | ↑             | ↑                                                                          |
| 3    | Fr. drum hoisting speed control  | 150 to 625mA   | ↑             | ↑                                                                          |
| 4    | Fr. drum lowering speed control  | ↑              | ↑             | ↑                                                                          |
| 5    | Re. drum hoisting speed control  | ↑              | ↑             | ↑                                                                          |
| 6    | Re. drum lowering speed control  | ↑              | ↑             | ↑                                                                          |
| 7    | 3rd. drum hoisting speed control | ↑              | ↑             | ↑                                                                          |
| 8    | 3rd drum lowering speed control  | ↑              | ↑             | ↑                                                                          |
| 9    | Fr. drum motor control           | 300 to 750mA   | ↑             | ↑                                                                          |
| 10   | Re. drum motor control           | ↑              | ↑             | ↑                                                                          |
| 11   | Swing speed control              | 250 to 700mA   | ↑             | ↑                                                                          |
| 12   | Main pump power reduction        | 200 to 700mA   | ↑             | ↑                                                                          |
| 13   | 3rd drum motor control           | 300 to 750mA   | ↑             | ↑                                                                          |
| 14   | Swing reaction                   | 150 to 510mA   | ↑             | ↑                                                                          |
| 15   | Boom pump power reduction        | 200 to 700mA   | ↑             | ↑                                                                          |

## 6. DIGITAL OUTPUT [C]

| Item | Name                                         | Status                   | Signal level | Troubleshooting judgment |
|------|----------------------------------------------|--------------------------|--------------|--------------------------|
| 1    | Battery relay energizing                     | Energized/De-energized   | +24V/OPEN    | Broken down wire         |
| 2    | Spare                                        | -                        | +24V/OPEN    | ↑                        |
| 3    | Hyd. oil heat                                | Energized/De-energized   | +24V/OPEN    | ↑                        |
| 4    | Boom pump inching speed                      | Inching/Normal           | +24V/OPEN    | ↑                        |
| 5    | Main pump inching speed                      | Inching/Normal           | +24V/OPEN    | ↑                        |
| 6    | -                                            | -                        | -            | -                        |
| 7    | Fr. drum clutch CIM                          | Energized/De-energized   | +24V/OPEN    | ↑                        |
| 8    | Fr. drum clutch FSM                          | Energized/De-energized   | +24V/OPEN    | ↑                        |
| 9    | -                                            | -                        | -            | -                        |
| 10   | Re. drum clutch CIA                          | Energized/De-energized   | +24V/OPEN    | ↑                        |
| 11   | Re. drum clutch FSA                          | Energized/De-energized   | +24V/OPEN    | ↑                        |
| 12   | -                                            | -                        | -            | -                        |
| 13   | 3rd. drum clutch CIT (option)                | Energized/De-energized   | +24V/OPEN    | ↑                        |
| 14   | 3rd. drum clutch EST (option)                | Energized/De-energized   | +24V/OPEN    | ↑                        |
| 15   | Fr. drum motor boost                         | Boost/Normal             | +24V/OPEN    | ↑                        |
| 16   | Re. drum motor boost                         | Boost/Normal             | +24V/OPEN    | ↑                        |
| 17   | 3rd. drum motor boost (option)               | Boost/Normal             | +24V/OPEN    | ↑                        |
| 18   | Fr. drum turn detecting gnp (option)         | △, □                     | +24V/OPEN    | ↑                        |
| 19   | Re. drum turn detection grip (option)        | △, □                     | +24V/OPEN    | ↑                        |
| 20   | Fr. drum C/V                                 | Energized / De-energized | +24V/OPEN    | ↑                        |
| 21   | Re. drum C/V                                 | Energized / De-energized | +24V/OPEN    | ↑                        |
| 22   | 3rd. drum C/V (option)                       | Energized / De-energized | +24V/OPEN    | ↑                        |
| 23   | Wind alarm output (custom)                   | Energized / De-energized | +24V/OPEN    | ↑                        |
| 24   | Free fall voice alarm (not use)              | Free fall/Normal         | GND/OPEN     | ↑                        |
| 25   | Spare                                        | -                        | GND/OPEN     | ↑                        |
| 26   | Fr. drum free fall indication lamp           | Lit up/Unlit             | +24V/OPEN    | ↑                        |
| 27   | Re. drum motor free fall indication lamp     | Lit up/Unlit             | +24V/OPEN    | ↑                        |
| 28   | 3rd. drum free fall indication lamp (option) | Lit up/Unlit             | +24V/OPEN    | ↑                        |


## 7. COMMUNICATION

| Item | Communication counterpart | Communication system | Communication speed |
|------|---------------------------|----------------------|---------------------|
| 1    | Indicator                 | TTL                  | 4800 bps            |
| 2    | MTL                       | RS232C               | 9600 bps            |
| 3    | PC (or handy checker)     | RS232C               | 4800 bps            |

The channel can be used for No 2 and 3 by switching operation.


### 13. TOTAL CONTROLLER

#### 13.4.3 DETAILS OF TOTAL CONTROLLER CONNECTOR




CN101      CN102      CN103      CN104

AMP 1-178203-6 (100P)




CN105      CN106      CN107      CN108

AMP 3-178780-6 (76P)




CN111

D-SUB9P CONNECTOR



CN100

AMP172040-1 (5P)



CN110

CN109

AMP 2-173866-1 (30P)

## 13.4.4 ARRANGEMENT OF TOTAL CONTROLLER CONNECTOR PIN

| Connector No. | Pin No. | Port name | Specifications |
|---------------|---------|-----------|----------------|
| CN100         | 1       | +24V      | Power supply   |
|               | 2       | +24V      |                |
|               | 3       | GND       | Grounding      |
|               | 4       | GND       |                |
|               | 5       |           | Vacancy        |

| Connector No. | Pin No. | Port name | Specifications                                               |
|---------------|---------|-----------|--------------------------------------------------------------|
| CN101         | 1       | D1+       | Boom raising speed control proportional valve                |
|               | 2       | D1-       |                                                              |
|               | 3       | D2+       | Boom lowering speed control proportional valve               |
|               | 4       | D2-       |                                                              |
|               | 5       | D3+       | Fr. drum hoisting speed control proportional valve           |
|               | 6       | D3-       |                                                              |
|               | 7       | D4+       | Fr. drum lowering speed control proportional valve           |
|               | 8       | D4-       |                                                              |
|               | 9       | D5+       | Re. drum hoisting speed control proportional valve           |
|               | 10      | D5-       |                                                              |
|               | 11      | D6+       | Re. drum lowering speed control proportional valve           |
|               | 12      | D6-       |                                                              |
|               | 13      | D7+       | 3rd. drum hoisting speed control proportional valve (option) |
|               | 14      | D7-       |                                                              |
|               | 15      | D8+       | 3rd. drum lowering speed control proportional valve (option) |
|               | 16      | D8-       |                                                              |
|               | 17      | D9+       | Fr. drum motor control proportional valve                    |
|               | 18      | D9-       |                                                              |
|               | 19      | D10+      | Re. drum motor control proportional valve                    |
|               | 20      | D10-      |                                                              |
|               | 21      | D11+      | Swing speed control                                          |
|               | 22      | D11-      |                                                              |
|               | 23      | D12+      | Main pump control proportional valve                         |
|               | 24      | D12-      |                                                              |
|               | 25      | D13+      | 3rd. drum motor control proportional valve (option)          |
|               | 26      | D13-      |                                                              |
|               | 27      | D14+      | Swing reaction proportional valve                            |
|               | 28      | D14-      |                                                              |
|               | 29      | D15+      | Boom pump control proportional valve                         |
|               | 30      | D15-      |                                                              |
|               | 31      | E1+       | Engine turn sensor                                           |
|               | 32      | E1-       |                                                              |
|               | 33      | E2        | Fr. drum turn sensor                                         |
|               | 34      | E3        | Re. drum turn sensor                                         |

### 13. TOTAL CONTROLLER

| Connector No. | Pin No. | Port name | Specifications                 |
|---------------|---------|-----------|--------------------------------|
| CN102         | 1       | B15       | Boom raising stop              |
|               | 2       | B16       | Boom lowering stop             |
|               | 3       | B17       | Re. drum lowering stop         |
|               | 4       | B18       | Boom raise deceleration        |
|               | 5       | B19       | Re. drum hoisting deceleration |
|               | 6       | B20       | Fr. drum lowering stop         |
|               | 7       | B21       | Fr. drum hoisting stop         |
|               | 8       | B22       | Re. drum hoisting stop         |
|               | 9       | B23       | Tower raise signal (Not used)  |
|               | 10      | B28       | M/I. redundancy                |
|               | 11      | B29       | 3rd. (lib) drum hoisting stop  |
|               | 12      | B34       | Charge signal                  |
|               | 13      | +5V       |                                |
|               | 14      | A6        | Tagline trimmer (Not used)     |
|               | 15      | G         |                                |
|               | 16      | +5V       |                                |
|               | 17      | A7        | Hand throttle POT              |
|               | 18      | G         |                                |
|               | 19      | +5V       |                                |
|               | 20      | A26       | Tension signal (Not used)      |
|               | 21      | G         |                                |
|               | 22      | E4        | Spare interrupt                |

| Connector No. | Pin No. | Port name | Specifications                       |
|---------------|---------|-----------|--------------------------------------|
| CN103         | 1       | +5V       |                                      |
|               | 2       | A19       | Fr. clutch pressure sensor           |
|               | 3       | G         |                                      |
|               | 4       | +5V       |                                      |
|               | 5       | A20       | Re. clutch pressure sensor           |
|               | 6       | G         |                                      |
|               | 7       | +5V       |                                      |
|               | 8       | A21       | 3rd. clutch pressure sensor (option) |
|               | 9       | G         |                                      |
|               | 10      | +5V       |                                      |
|               | 11      | A24       | Boom raise pressure sensor           |
|               | 12      | G         |                                      |
|               | 13      | +5V       |                                      |
|               | 14      | A25       | Boom lower pressure sensor           |
|               | 15      | G         |                                      |
|               | 16      | B24       | Swing neutral mode selection (Brake) |



| Connector No. | Pin No. | Part name | Specifications                                  |
|---------------|---------|-----------|-------------------------------------------------|
| CN104         | 1       | +5V       |                                                 |
|               | 2       | A1        | Fr. drum speed adjusting trimmer                |
|               | 3       | G         |                                                 |
|               | 4       | +5V       |                                                 |
|               | 5       | A2        | Re. drum speed adjusting trimmer                |
|               | 6       | G         |                                                 |
|               | 7       | +5V       |                                                 |
|               | 8       | A3        | Boom drum speed adjusting trimmer               |
|               | 9       | G         |                                                 |
|               | 10      | +5V       |                                                 |
|               | 11      | A4        | Spare A/D                                       |
|               | 12      | G         |                                                 |
|               | 13      | +5V       |                                                 |
|               | 14      | A5        | Spare A/D                                       |
|               | 15      | G         |                                                 |
|               | 16      | +5V       |                                                 |
|               | 17      | A8        | Foot throttle POT (option)                      |
|               | 18      | G         |                                                 |
|               | 19      | +5V       |                                                 |
|               | 20      | A9        | Rear drum control pressure sensor<br>(Not used) |
|               | 21      | G         |                                                 |
|               | 22      | +5V       |                                                 |
|               | 23      | A10       | Third drum control pressure sensor              |
|               | 24      | G         |                                                 |
|               | 25      | B26       | Propel control                                  |
|               | 26      | B27       | Swing control                                   |
|               | 27      | B30       | Function lock                                   |
|               | 28      | B31       | Clogging of E/G air cleaner                     |

### 13. TOTAL CONTROLLER

| Connector No. | Pin No. | Port name | Specifications                          |
|---------------|---------|-----------|-----------------------------------------|
| CN105         | 1       | C22       | 3rd. ClV solenoid valve                 |
|               | 2*      | C7        | Fr. clutch CLM solenoid valve           |
|               | 3       | +5V       |                                         |
|               | 4       | A11       | Swing pump pressure sensor              |
|               | 5       | G         |                                         |
|               | 6       | +5V       |                                         |
|               | 7       | A12       | 3rd. motor speed adjusting trimmer      |
|               | 8       | G         |                                         |
|               | 9       | +5V       |                                         |
|               | 10      | A13       | Fr. drum hoisting pressure sensor       |
|               | 11*     | C8        | Fr. clutch ESM solenoid valve           |
|               | 12*     | C23       | Wind alarm output (Custom)              |
|               | 13*     | C10       | Re. clutch CLA solenoid valve           |
|               | 14*     | C11       | Re. clutch ESA solenoid valve           |
|               | 15*     |           | Vacancy                                 |
|               | 16      | +5V       |                                         |
|               | 17      | A14       | Fr. drum lowering pressure sensor       |
|               | 18      | G         |                                         |
|               | 19      | H1+       | ECU command (1)                         |
|               | 20      | H1-       |                                         |
|               | 21      | H2+       | ECU command (2)                         |
|               | 22      | H2-       |                                         |
|               | 23      | G         | Fr. drum hoisting pressure sensor       |
|               | 24*     | C13       | 3rd. clutch CLT solenoid valve (option) |
|               | 25*     | C14       | 3rd. clutch EST solenoid valve (option) |
|               | 26*     | C15       | Fr. drum motor boost solenoid valve     |

| Connector No. | Pin No. | Port name | Specifications                                 |
|---------------|---------|-----------|------------------------------------------------|
| CN106         | 1       | B1        | Fr. drum free fall select                      |
|               | 2       | B2        | Re. drum free fall select                      |
|               | 3       | B3        | 3rd. drum free fall select (option)            |
|               | 4       | B6        | Swing neutral mode selection (free high speed) |
|               | 5       | B7        | Jib (third) raising deceleration               |
|               | 6       | B8        | Drum turn selection                            |
|               | 7       | B9        | Fr. drum brake detect sensor (for CEN)         |
|               | 8       | B10       | Key switch "ON"                                |
|               | 9       | B14       | Moisture detection of the fuel filter          |
|               | 10      | B25       | Third drum lowering stop                       |
|               | 11      | B42       | E/G preheat signal                             |
|               | 12      | C1        | Battery relay energizing                       |
|               | 13      | C26       | Fr. drum free fall indication lamp             |
|               | 14      | C27       | Re. drum free fall indication lamp             |
|               | 15      | C28       | 3rd. drum free fall indication lamp (option)   |
|               | 16      |           | Vacancy                                        |

| Connector No. | Pin No. | Port name | Specifications              |
|---------------|---------|-----------|-----------------------------|
| CN107         | 1       | TxD1      | M/L communication (RS232C)  |
|               | 2       | RxD1      |                             |
|               | 3       | GND1      |                             |
|               | 4       | SHG1      |                             |
|               | 5       | TxD2      | Monitor communication (TTL) |
|               | 6       | RxD2      |                             |
|               | 7       | GND2      |                             |
|               | 8       | SHG2      |                             |
|               | 9       |           | Vacancy                     |
|               | 10      |           |                             |
|               | 11      | B4        | ECU ON signal               |
|               | 12      | B11       | Inching selection           |

| Connector No. | Pin No. | Port name | Specifications                              |
|---------------|---------|-----------|---------------------------------------------|
| CN108         | 1*      | F1+       | Spare                                       |
|               | 2*      | F1-       |                                             |
|               | 3       | SMG       | Spare                                       |
|               | 4       | +5V       | Re. drum hoisting pressure sensor           |
|               | 5       | A15       |                                             |
|               | 6       | G         |                                             |
|               | 7       | +5V       | Re. drum lowering pressure sensor           |
|               | 8       | A16       |                                             |
|               | 9       | G         |                                             |
|               | 10      | +5V       | Vacancy                                     |
|               | 11*     | C16       | Re. drum motor boost                        |
|               | 12*     | F2+       | Spare                                       |
|               | 13*     | F2-       |                                             |
|               | 14      | +5V       | 3rd. drum hoisting pressure sensor (option) |
|               | 15      | A17       |                                             |
|               | 16      | G         |                                             |
|               | 17      | +5V       | 3rd. drum lowering pressure sensor (option) |
|               | 18      | A18       |                                             |
|               | 19      | G         |                                             |
|               | 20      | A22       | Wind sensor (option)                        |
|               | 21      | G         |                                             |
|               | 22*     | C17       | 3rd. motor boost solenoid valve (option)    |

### 13. TOTAL CONTROLLER

| Connector No. | Pin No. | Port name | Specifications                   |
|---------------|---------|-----------|----------------------------------|
| CN109         | 1       | C2        | Spare D/O                        |
|               | 2       | C3        | Hyd. oil heat relay              |
|               | 3       | C4        | Boom pump control solenoid valve |
|               | 4       | C5        | Main pump control solenoid valve |
|               | 5       | C18       | Fr. drum turn detection grip     |
|               | 6       | C19       | Re. drum turn detection grip     |
|               | 7       | C20       | Fr. drum C/V solenoid valve      |
|               | 8       | C21       | Re. drum C/V solenoid valve      |
|               | 9       |           | Vacancy                          |
|               | 10      |           | Vacancy                          |
|               | 11      | C24       | Free fall voice alarm (Not use)  |
|               | 12      | C25       | Spare (D/O)                      |


| Connector No. | Pin No. | Port name | Specifications                          |
|---------------|---------|-----------|-----------------------------------------|
| CN110         | 1       | B12       | Mode select                             |
|               | 2       | B13       | E/G PSW                                 |
|               | 3       | B32       | Re. drum brake detect sensor (for GEN)  |
|               | 4       | B33       | Water level                             |
|               | 5       | B35       | Engine oil filter clog                  |
|               | 6       | B36       | 3rd. drum brake detect sensor (for GEN) |
|               | 7       | B37       | Hydraulic oil temperature               |
|               | 8       | B38       | Control primary pressure                |
|               | 9       | B39       | 1st. drum free fall speed S/W           |
|               | 10      | B40       | Re. drum free fall speed S/W            |
|               | 11      | B41       | 3rd. drum free fall speed S/W           |
|               | 12      | B43       | Fr. drum brake cooling oil temperature  |
|               | 13      | B44       | Re. drum brake cooling oil temperature  |
|               | 14      | B45       | Cooling line filter clog                |
|               | 15      | B46       | Free fall release                       |
|               | 16      |           | Vacancy                                 |
|               | 17      | A23       | Spare A/D                               |
|               | 18      | G         |                                         |

| Connector No. | Pin No. | Port name | Specifications                           |                                |
|---------------|---------|-----------|------------------------------------------|--------------------------------|
| CN111         | 1       | Vacancy   | Maintenance PC communication<br>(RS232C) |                                |
|               | 2       | RxD       |                                          |                                |
|               | 3       | TxD       |                                          |                                |
|               | 4       | Vacancy   |                                          |                                |
|               | 5       | GND       |                                          |                                |
|               | 6       | Vacancy   |                                          |                                |
|               | 7       | Vacancy   |                                          |                                |
|               | 8       | CHK2      |                                          | For checking connection status |
|               | 9       | CHK2      |                                          |                                |

The pins in \* shall be assigned to the port 070.

## 13. TOTAL CONTROLLER

### 13.4.5 PROPORTIONAL SOLENOID VALVE MEASURING POSITION



Proportional valve detection resistance

| Item | Name                             | Output current | Dither                     | Detected resistance |
|------|----------------------------------|----------------|----------------------------|---------------------|
| 1    | Boom raising speed control       | 200 to 625mA   | 200mA <sub>p-p</sub> 100Hz | 723                 |
| 2    | Boom lowering speed control      | ↑              | ↑                          | 739                 |
| 3    | Fr. drum hoisting speed control  | 150 to 625 mA  | ↑                          | 755                 |
| 4    | Fr. drum lowering speed control  | ↑              | ↑                          | 769                 |
| 5    | Re. drum hoisting speed control  | ↑              | ↑                          | 767                 |
| 6    | Re. drum lowering speed control  | ↑              | ↑                          | 801                 |
| 7    | 3rd. drum hoisting speed control | ↑              | ↑                          | 819                 |
| 8    | 3rd. drum lowering speed control | ↑              | ↑                          | 834                 |
| 9    | Fr. drum motor control           | 300 to 750mA   | ↑                          | 851                 |
| 10   | Re. drum motor control           | ↑              | ↑                          | 865                 |
| 11   | Swing speed control              | 250 to 700 mA  | ↑                          | 883                 |
| 12   | Main pump power reduction        | 200 to 700mA   | ↑                          | 898                 |
| 13   | 3rd. drum motor control          | 300 to 750mA   | ↑                          | 915                 |
| 14   | Swing reaction                   | 150 to 510mA   | ↑                          | 931                 |
| 15   | Boom pump power reduction        | 200 to 700mA   | ↑                          | 1045                |

## 13.5 ADJUSTMENT OF TOTAL CONTROLLER

### 13.5.1 NECESSITY OF ADJUSTMENT


| Repair contents                               |                       | Adjusted items |                           |                         |
|-----------------------------------------------|-----------------------|----------------|---------------------------|-------------------------|
|                                               |                       | option setting | Throttle range adjustment | Engine speed adjustment |
| Replacement of hand throttle or foot throttle |                       | X              | ○                         | X                       |
| Replacement of stepping motor                 |                       | X              | X                         | ○                       |
| Governor link                                 |                       | X              | X                         | ○                       |
| Installation/removal of optional equipment    | 3rd. drum             | ○              | X                         | X                       |
|                                               | Foot throttle         | ○              | X                         | X                       |
|                                               | Drum turn sensor      | ○              | X                         | X                       |
|                                               | Lifting height sensor | ○              | X                         | X                       |
|                                               | Wind sensor           | ○              | X                         | X                       |
|                                               | Fr. Drum free fall    | ○              | X                         | X                       |
|                                               | Re. Drum free fall    | ○              | X                         | X                       |
|                                               | 3rd. Drum free fall   | ○              | X                         | X                       |
| Replacement of total controller assembly      |                       | ○              | ○                         | ○                       |
| Downloading of program                        |                       | X              | X                         | X                       |
| Replacement of ECU                            |                       | X              | X                         | ○                       |

○: Necessary X: Unnecessary


### 13.5.2 ADJUSTMENT PROCEDURES OF TOTAL CONTROLLER

#### 13.5.2.1 OPTION SETTING

1. Set the engine key to the "ON" position (the engine is not started).
2. Set the adjustment switch to the "TEST" position





3. The option setting items are displayed on the display screen of the cluster



### 13. TOTAL CONTROLLER

4. Select any intended option item with the adjuster "▲" and "▼" switches on the cluster.
5. If the option setting is necessary, input "O" with the adjuster "+" or "-" switch.  
If the option setting is unnecessary, input "X" with the "+" or "-" switch.



6. After the completion of input of "O" or "X" against all the items, push the "Setting switch" on the cluster.
  - Adjustment values can be input into the controller by pushing the "Setting switch".  
Remember that the adjustment becomes ineffective unless the "Setting switch" is pushed.
7. Return the adjustment switch to the "RUN" position.

| Option setting procedure           |                 |
|------------------------------------|-----------------|
| A. Adjustment switch:              | "1LSI" position |
| B. Operation mode selector switch: | "▼" and "▲"     |
| C. "O" and "X"                     |                 |
| D. Setting switch:                 | Press           |
| E. Adjustment switch:              | "RUN" position  |



### 13.5.2.2 ADJUSTMENT OF HAND THROTTLE AND FOOT THROTTLE


1. Set the engine key to the "ON" position (the engine is not started)
  2. Set the adjustment switch to the "TEST" position.
  3. Press the "CHECK" switch of the cluster gauge  
(The screen can be changed whenever this switch is pressed.)  
Then, the message "THROTTLE LOW ADJUST" is displayed on the display screen of the cluster
  4. Set the hand throttle and foot throttle to the low idling positions.
  5. Press the "Zero" switch of the cluster gauge.  
Then, the adjustment values are stored by the controller, and the message "THROTTLE HI- ADJUST" is displayed on the display screen of the cluster.
  6. Set the hand throttle and foot throttle to the high idling positions.
  7. Press the "Zero" switch of the cluster gauge.  
Then, the adjustment values are stored by the controller, and the message "FINISH" is displayed on the display screen of the cluster.
- B. Return the "ADJUSTMENT" switch to the "RUN" position.

G-16  
CPU THROTTLE  
LOW ADJUST

G-17  
CPU THROTTLE  
HI-ADJUST

G-5  
CPU FINISH  
CRPM

| Adjustment of hand throttle & foot throttle |                           |
|---------------------------------------------|---------------------------|
| A. Adjustment switch:                       | "TEST" position           |
| B. "Check" switch:                          | THROTTLE<br>LOW ADJUST    |
| C. Hand and foot throttles:                 | "LOW IDLING"<br>position  |
| D. "Zero" switch:                           | Press                     |
| E. Hand and foot throttles:                 | "HIGH IDLING"<br>position |
| F. "Zero" switch:                           | Press                     |
| G. Adjustment switch:                       | "RUN" position            |



## 13. TOTAL CONTROLLER

### 13.5.2.3 ENGINE SPEED ADJUSTMENT

- Prior to the adjustment, sufficiently warm up the machine.
- 1. Set the engine key to the "ON" position (the engine is not started)
- 2. Set the adjustment switch to the "TEST" position.
- 3. Press the "CHECK" switch of the cluster gauge.  
(The screen can be changed whenever this switch is pressed.)  
Then, the message "STEP3" is displayed on the display screen of the cluster.
- 4. Start the engine, and press the "ZERO" switch of the cluster gauge. Then, the engine speed reaches at a high idling
- 5. When the engine speed reaches the high idling, it is decreased gradually.  
A controller assigns engine speed and accelerator signal at this time.
- 6. When the engine speed reaches the low idling, the message "STEP5" is displayed on the display screen of the cluster.  
Then, adjustment is finished.
- 7. Return the "ADJUSTMENT" switch to the "RUN" position.

```
G-3
CPU  STEP3
      ENG. START
```


```
G-4
CPU  STEP 4
MEMORY 500 RPM
```

```
G-5
CPU  STEP 5
      740 RPM
```

| Adjustment of engine speed     |                        |
|--------------------------------|------------------------|
| A. Adjustment switch:          | "TEST" position        |
| B. Inching switch:             | "STEP 3" ENG.<br>START |
| C. "Zero" switch:              | Press                  |
| D. Engine automatic adjustment |                        |
| E. Adjustment switch:          | "RUN" position         |

### 13.5.2.4 WHEN ADJUSTMENT OF TOTAL CONTROLLER IS IMPOSSIBLE

- 1 After the zero switch is pushed while the message "STEP3 Engine start is possible." is displayed on the display screen of the cluster, the message "CPU adjustment is impossible." appears, and the adjustment is impossible.



#### [CASE 1]

- Condition : when the engine speed is 1500 min<sup>-1</sup> or slower.
- Cause : the reading by the engine turn sensor is incorrect.
- Remedy : after the measurement and adjustment of the turn sensor voltage, perform the adjustment A.  
High idling 3 V (AC) or more

#### [CASE 2]

- Condition : when the engine speed does not reach 2.000 min<sup>-1</sup>.
- Cause : the reading by the engine turn sensor is incorrect.
- Remedy : after the measurement and adjustment of the turn sensor voltage, perform the adjustment A.  
High idling 3 V (AC) or more

2. The message "CPU ROM data" is displayed.

- (1) Noises are input. Completely perform all the total controller adjustment procedures.
- (2) This message is also displayed on the display screen of a new controller (adjustment). Completely perform all the total controller adjustment procedures.

## 13. TOTAL CONTROLLER

---

### 13.5.2.5 INITIAL ADJUSTMENT OF LIFTING HEIGHT GAUGE

If the drum is rotated without a wire rope wrap during the wire rope replacement, or the drum is rotated with the wire rope caught in during the disassembly and the assembly of the boom, the wire rope layers on the drum must be adjusted. If the adjustment is not performed correctly, the lifting height may not be changed, or the displayed value may be incorrect. Be sure to adjust it correctly.


The initial adjustment of the lifting height gauge must be performed for both of the main winch and the aux. winch.

The adjustment steps are identical to the front drum and the rear drum.

The adjustment steps for the front drum are described below.

1. Winch up and down the main hook block, and stop it at the position where the wire rope layers on the drum changes.

(1) Display the "Front drum layers display screen".



- 1) Push the flash switch for more than 5 seconds. Then, the displayed value of the wire rope wraps on the drum flashes.






---

## **14. AIR CONDITIONER**





## 14.1 OPERATION ITEMS

**(1) FAN SWITCH**

The switches control the air conditioner ON/OFF function and the blower speed.

position Low  
 position Medium  
 position High

**(2) AIR VENT SELECTION SWITCH**

These switches control the open/close position of each air vent. Select the desired air flow mode from the three mode position. The selected position is always shown by a lamp. Select if the front glass is misted.

**(3) AIR INLET SELECTION SWITCH**

This switch selects the open or close position of air inlet.



Selector switch for selection between internal air circulation and open intake.



When this position is selected, the air inlet is closed which causes the air to recirculate inside the cab.



When this position is selected, the air inlet is opened which allows fresh air to be introduced into the cab.


**(4) TEMPERATURE CONTROL SWITCH**

These switches control the temperature of air coming out of the air vents to any of five levels during heating (red label) and cooling (green label).

1. Push the left switch (←), and the range of the GREEN lights decrease and the air temperature goes down.

2. Push the right switch (→), and the range of the LED lights increase and the air temperature goes up.

Green indicator ← → Red indicator

**(5) AIR CONDITIONER SWITCH**

This is used to turn ON and OFF the cooling function during cooling or dehumidification heating.

Push once to change over from ON/OFF to OFF/ON.

When the switch is turned ON, the lamp on the upper part of the switch lights up.



AIR CONDITIONER INDICATOR LAMP




AIR CONDITIONER SWITCH

## 14.2 SAFETY MONITOR FUNCTIONS

This control panel displays the following self-monitoring functions.


(1) Thermostat Cutoff and short Monitor.

When a cutoff or short occurs on the thermostat circuit, this function detects it and the A/C display LED flashes while the air conditioner remains ON.




(2) Temperature Motor Actuator Lock and Circuit Monitor.

When there is insufficient motion after the motor actuator starts, it detects this as a short and the appropriate LED based on the set temperature flashes.




(3) Thermostat Cutoff/Short and Temperature Motor Actuator Lock/Cutoff/Short Monitor.

When thermostat or motor circuit malfunctions occur, the appropriate LED and the A/C switch LED flash (while the air conditioner is on).




## (4) Mode Actuator Lock / Circuit Cutoff Monitor

When a malfunction in the mode actuator lock / circuit occurs, the VENT or VENT & FOOT LED on the set mode flashes




## (5) Defogger Motor Actuator Lock or Circuit Cutoff / Short Monitor.

When malfunctions on the monitor actuator lock or circuit occur, the defroster LED flashes



## (6) Mode Actuator lock or Circuit Cutoff / Short and Defogger Motor Actuator Lock or Circuit Cutoff / Short Monitor.

When malfunctions on the mode or defroster motor actuator lock or circuit occur, one of the mode LED flashes.




## 14. AIR CONDITIONER

---

(7) In / Out Motor Actuator Lock or Circuit Cutoff or Short Monitor.

When malfunctions on the in / out air motor actuator lock or circuit occur, the inside air or outside air LED flashes.



## 14.3 DISASSEMBLY AND ASSEMBLY PROCEDURE

### 14.3.1 SPECIAL CONSIDERATIONS DURING REPLACEMENT

#### 1. Special maintenance locations

After assessing the malfunctioning situation, refer to the Trouble Shooting section to learn about remedy procedures.

#### 2. After completing the work, make very sure the malfunction is indeed repaired completely by starting the air conditioner and checking for proper function.

#### 3. Special Instructions

##### (1) Pipe joints

When connecting pipe joints, apply freezer oil (PAG oil: SP20) to the O rings, and tighten with a double spanner to the following torque values

| Joint parts          | Torque (kg-cm) | Joint parts                          | Torque (kg-cm) |
|----------------------|----------------|--------------------------------------|----------------|
| Compressor M8×25     | 200 to 250     | S hose and AC unit                   | 300 to 350     |
| D hose and condenser | 200 to 250     | S hose and compressor                | 300 to 350     |
| L pipe and condenser | 120 to 150     | Evaporator inlet and expansion valve | 120 to 150     |
| Receiver dryer M8×28 | 120 to 150     | Expansion valve and evaporator       | 200 to 250     |
| L hose and AC unit   | 80 to 120      |                                      |                |

##### (2) Screw and Bolt Tightening torques

Screws and bolts should be tightened to these designated torque values.

| Diameter (mm)                           | Torque (kg-cm) |                |
|-----------------------------------------|----------------|----------------|
|                                         | Metric screws  | Tapping screws |
| 4                                       | 10 to 15       | 8 to 10        |
| 5                                       | 20 to 25       | 10 to 20       |
| 6<br>(Condenser installation and resin) | 40 to 55       | -              |
| 6                                       | 40 to 65       | -              |
| 8                                       | 120 to 160     | -              |
| 10 (Inside unit installation)           | 200 to 250     | -              |
| 10                                      | 400 to 550     | -              |

## 14. AIR CONDITIONER

### 4. Compressor oil capacity

The compressor contains 240 cc of oil. If the oil is insufficient, the compressor may overheat and/or burn under high RPM, thereby lowering its own durability. If the oil amount is too much, it decreases cooling capacity.

Once the air conditioner is turned on, the oil somewhat disperses into the freezing cycle. The amount of oil may need adjusting when the following parts are replaced.

| Replaced part  | Joint parts                                                                                                                                                                                                           |
|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Compressor     | (1) Measure the oil amount remaining in the removed compressor.<br>(2) 240 cc (oil amount (1) + 30 cc) = remaining oil in circuit.<br>(3) Remove the amount of the remaining oil from the new compressor and install. |
| AC unit        | Add 15 cc                                                                                                                                                                                                             |
| Receiver dryer | Add 20 cc                                                                                                                                                                                                             |
| Condenser      | Add 20 cc                                                                                                                                                                                                             |


\* Refill oil should be SP-20

- Work should start only after the engine is shut off and the air conditioning power has been turned off.
- Under rainy conditions, do not remove or install any pipes.
- Be careful not to let any water get into the cooling circuit. Do not leave the pipes disconnected.

**14.3.2 INTERIOR UNIT****14.3.2.1 CASE DISASSEMBLY**

## 1. Removing the amplifier

- (1) Take off the 3 connectors (a). [See Figure-1;
- (2) Take off the 3 lapping screws (3) and remove the amplifier (2).



View from front

Figure-1




Figure-2

## 14. AIR CONDITIONER

### 2. Removing the register

- (1) Take off 1 tapping screw (45), 2 semi screw (46) and remove the piping cover (44).
- (2) Remove the connector (b).
- (3) Take off 2 tapping screws (5) and remove the register.

### **CAUTION**

Be careful not to bend the coil (P)




Figure-3

### 3. Releasing the valve rod

Open the rod clamp (7) to release the valve rod.




Figure-4



## 4. Removing the upper case

- (1) Take off the connector (4). [See Figure-2]
- (2) Take off 3 semi screws (50).

**CAUTION**

Do not lose the clamp (51).

- (3) Take off 7 semi screws (46) and the small screw (47).
- (4) Take off 11 clamps (9) with a regular screwdriver.
- (5) Lift up the upper case (8) to remove.




Figure-5-1




Figure-5-2




Figure-5-3

## 14. AIR CONDITIONER

### 14.3.2.2 THERMOSTAT REPLACEMENT

#### 1. Removal

- (1) Remove the upper case (8) as shown in Section 14.3.2.1.
- (2) Lift up the evaporator assembly (10) to remove.

#### **CAUTION**

Be careful not to bend the pipes.

- (3) Remove the holder (12).
- (4) Take out the thermostat (11) from the holder (12).
- (5) Pull out the thermostat (11) with the grommet (13) from the hole on the lower case (14).




Figure-6

#### 2. Installation

Reassemble in the reverse order from disassembly, with the following special notations.

- (1) When installing the thermostat, only the sensor part (e) should protrude from the bottom.
- (2) Refer to the Figure-6 for an installation location.

## 14.3.2.3 EVAPORATOR OR EXPANSION VALVE REPLACEMENT

**CAUTION**

1. Remove all the coolant in the cooling circuit in advance.
2. Replace with new O-rings at this time.
3. Plug or cover the removed port to prevent dust from getting in.

## 1. Removal

- (1) Remove the upper case (8) as shown in Section 14.3.2.1.
- (2) Lift up the evaporator Assy (10) to remove. [See Figure-6]
- (3) Remove the insulation (15) and take out the stay (16).
- (4) Loosen the nuts (f), (g), and take off each pipe.




Figure-7

## 2. Installation

Proceed with reassembly in the reverse order of disassembly, with the following special notations.

- (1) Install the temperature sensing tube (h) as shown on Figure-8.
- (2) Roll an extra length of the capillary tube (i) to approx. 20.
- (3) The insulation (15) can not be reused, so replace it.
- (4) Apply the insulation carefully so that the temperature sensing tube (h) is completely insulated from outside air.  
As when it was removed, the seam in the insulation should not touch the in/out air dumper.
- (5) After installing the upper case (8), be sure to check the following.




Figure-8

## 14. AIR CONDITIONER

- Turn the linkage bushing (17) toward the arrow, and remove the rod (18).

### **CAUTION**

Do not release the rod clamp (19) if it has been removed, reassemble it again as explained in Section to follow

- Turn the intake dumper shaft (20) to be sure that the dumper (21) does not interfere with the capillary tube (i). There must be more than 5 mm clearance.
- Install the rod (18) to the linkage bushing (17).




Figure-9

### 14.3.2.4 HEATER CORE REPLACEMENT

### **CAUTION**

- Make sure the water temperature is low.
- Be careful not to drain the cooling water.

#### 1. Removal

- (1) Remove the upper case (8) as explained in Section 14.3.2.1.
- (2) Take off the lapping screw (30) to remove the retainer (31).
- (3) Loosen 2 hose clamps (22) to remove the heater hose (23), and lift the heater core to remove (2).

#### 2. Installation

Proceed with reassembly in the reverse order from disassembly, with the following special notations.

- (1) Replace the heater hose (23) and the insulator (32).




Figure-10

### 14.3.2.5 INTAKE DUMPER ACTUATOR REPLACEMENT

#### 1. Removal

- (1) Open the rod clamp (19) to release the rod (18)
- (2) Take off the connector (1) and 4 tapping screws (25) to remove the actuator (26).

#### 2. Installation

- (1) Install the actuator (26) with 4 tapping screws (25) and connect the connector (1).
- (2) Turn the dumper lever (20) toward the arrow until it stops and then press lightly. Press the actuator lever (m) toward the arrow lightly and fix the rod (18) to the rod clamp (19).




Figure-11

### **CAUTION**

Do not release the rod clamp (19) and remove the rod (18) other than when replacing the actuator. If it has been removed, check to see the lever (m) is at location indicated in Figure-11. If it is not at that location, proceed as follows.

- Turn the power on and set to the AglInside Air Circulation mode. (beware that the lever (m) rotates) wait for 10 seconds, and then check to see if the lever (m) is at the location shown in Figure-11.
- Turn off the power and fix the rod (18) as explained in w of the previous section.

## 14. AIR CONDITIONER

### 14.3.2.5 WATER VALVE ACTUATOR OR WATER VALVE REPLACEMENT

#### 1. Removing the actuator

- (1) Open the rod clamp (27) to release the rod (6)
- (2) Take off the connector (n) [see Figure 5-2] and 4 tapping screws (28) to remove the actuator (29).

#### 2. Installing the actuator

- (1) Install the actuator with 4 tapping screws (28) and connect the connector (n).
- (2) Fix the valve rod (6) tight to the rod clamp (27) so that the spring (o) is bent 1 mm.




Figure-12

### **CAUTION**

Do not release the rod clamp (27) and remove the rod (6) other than when replacing the actuator. If it has been removed, check to see the lever (t) is at the location indicated in Figure-13.

- Turn the power On and set to the **AgAir Blow** mode, one green and one red Operation Panel LED will glow. (Beware that the lever (t) rotates.) Wait for 10 seconds, and then check to see if the lever (t) is at the location shown in Figure-12.
- Turn OFF the power and fix the rod (6) as explained in w of the previous section.

#### 3. Removing the water valve

- (1) Turn the power ON and set to the **AgAir Blow** mode, one green and one red Operation Panel LED will glow. Wait for 10 seconds, and then check to see if the lever (t) is at the location shown in Figure-13.

- (2) Turn OFF the power.

- (3) Open the rod clamp (7) to release the rod (6).
- (4) Take off the tapping screw (30) to remove the retainer (31).
- (5) Take off 3 tapping screws (35)
- (6) Loosen 2 hose clamps (22) and remove the heater hose (23) and remove the water valve (34)

#### 4. Installing the water valve

Proceed with reassembly in the reverse order from disassembly, with the following special notations.

- (1) Pay attention to the location of the spring (o) and washer (c).
- (2) Replace the heater hose (23).




Figure-13

### 14.3.2.7 MODE ACTUATOR REPLACEMENT

#### 1. Removal

- (1) Open the rod clamp (36) to release the rod (37).
- (2) Take off the connector (q) and 4 tapping screws (38) to remove the actuator (39).

#### 2. Installation

- (1) Install the actuator (39) with 4 tapping screws (38) and connect the connector (q).
- (2) Turn the dumper lever (40) toward the arrow until it stops and then press tightly. Press the actuator lever (r) forward the arrow lightly and fix the rod (37) to the rod clamp (36).




Figure-14

### CAUTION

Do not release the rod clamp (36) and remove the rod (37) other than when replacing the actuator. If it has been removed, check to see the lever (r) is at the location indicated in Figure-14.

If it is not at that location, proceed as follows.

- Turn the power ON and set to the "" mode. (beware that the lever (r) rotates) Wait for 10 seconds, and then check to see if the lever (r) is at the location shown in Figure-14
- Turn OFF the power and fix the rod (36) as explained in w of the previous section.

### 14.3.2.8 BLOWER MOTOR ASSEMBLY REPLACEMENT

#### 1. Removal

- (1) Take off coupler(s) and take off 3 semi screws (41).
- (2) Remove the blower motor assembly (42).

#### 2. Installation

Proceed in the reverse order of the installation process.

### CAUTION

Be careful not to put anything into the blower casing (43).

Foreign objects may damage the fan (u).




Figure-15

### 14.4 OPERATIONAL PRECAUTIONS

1. For the operators health and comfort

The purpose of air conditioning is to lower temperature and humidity. They say the cab temperature should be 5 to 6°C lower than the temperature outside. Do not set the temperature too low and do not direct cooled air to the body for extended periods. Use a sensible temperature setting.

2. Ventilating the room

When the air inside the cab gets dry due to the de-humidifying effects of the air conditioner, smoking may cause some eye irritation. Open the window a little or switch to the Outside Air Intake mode to ventilate when smoking.

3. When inside glass fogs up

When inside glass fogs up, turn the air conditioner ON for a little while (A/C display LED on). The fog will disappear.

4. When LED flashes

This indicates an abnormality. Perform inspection and maintenance immediately.



## 14.5 INSPECTION AND MAINTENANCE

### 14.5.1 INSPECTION/MAINTENANCE LIST

| Inspection frequency                 | Inspected part              | Inspection point             |                                                                                                          |
|--------------------------------------|-----------------------------|------------------------------|----------------------------------------------------------------------------------------------------------|
| At least monthly, or often as needed | Outside air filter          | Clogging                     | Airflow or wash w/water<br>When washed in water (may use a mild detergent), hang to dry for 5 to 7 days. |
|                                      | Inside air filter           | Clogging                     | Wash with water because airflow may damage the filter.                                                   |
|                                      | Condenser                   | Clogging                     |                                                                                                          |
| Every month                          | V belts                     | Damage and tension           |                                                                                                          |
| Every 6 months                       | Coolant                     | Refill as needed             |                                                                                                          |
|                                      | Assembled pipes             | Looseness, gas leaks, damage |                                                                                                          |
|                                      | Compressor                  | Working condition            |                                                                                                          |
| Every 12 months                      | A/C unit outside air filter | Working condition<br>Replace |                                                                                                          |

### 14.5.2 INSPECTION/MAINTENANCE PROCEDURES


- Cleaning and replacing the filters
  - When a filter is clogged, the air flow decreases and the air conditioner's performance is reduced.  
Clean or replace filters as indicated in the list above.
  - Removal and reinstallation
  - Inside air filter
 

**Removal** Lift the hook on the filter and pull it toward you.
  - Outside air filter
 

**Removal** Take off 2 nilatch plungers on top and bottom and pull the filter toward you.

**Installation** Install in the reverse order from removal.
- Inspection of the Coolant (gas)
 

Ask an air conditioner service person to inspect and top up the coolant as necessary.



## 14. AIR CONDITIONER

### (2) Checking the refrigerant (gas)

Cautions for filling the refrigerant

#### **WARNING**

Since the refrigerant filling operation may cause serious accident, take the following measures.

- Qualified and responsible personnel with full knowledge of work contents must perform the filling operation of refrigerant.
- If refrigerant gets into your eyes, it may cause vision loss. Be sure to wear the safety goggles.
- Liquid refrigerant is at a low temperature (about  $-30^{\circ}\text{C}$ ). If it splashes over skin, it may cause frostbite. Special care should be taken to handle the refrigerant.
- Refrigerant (R-134a) decomposes when it contacts with high temperature parts (at about  $400^{\circ}\text{C}$  or higher) and generates toxic substance (such as phosgene gas). Never release the refrigerant in the room with poor ventilation and where a heat source (such as a stove, etc.) is used.
- Care should be taken not to release the gases into the atmosphere in order to protect nature.



#### **CAUTION**

Since the filling operation may cause serious accident, take the following measures.

- When a service canister is to be warmed up in order to fill the refrigerant, be sure to open the low pressure valve at the service canister and gauge manifold and then heat it up in hot water lower than  $40^{\circ}\text{C}$  (the temperature that you do not feel hot when you dip your hand in it). DO NOT dip the canister in boiling hot water or heat it by direct flame because a service canister will burst.
- When you start engine and intend to fill the refrigerant, if the high pressure valve (H) is opened, the high pressure gas flows back and the service canister or the hose will burst. Never do this wrong procedure.



## Cautions for storage and transportation

**WARNING**

Since the storage and transportation may cause serious accident, take the following measures.

- Since the high pressure gas is contained in the condition of saturated liquid in a service canister, if the temperature rises, the pressure rapidly increases and the canister may burst. Be sure to keep the canister temperature lower than 40°C. Never place a canister close to fire sources.
- Avoid direct sunlight and store the canister in a cool and dark place.
- Inside a closed vehicle (including a trunk), the temperature may increase extremely high. Do not bring the canister in a vehicle because the temperature may reach the critical value where it is exposed to direct sunlight even in winter.
- The strength of service canister may drop if it received damages, dents or deformation. Do not strike or drop it. Do not throw or drop it while unloading the package sets.
- Store the canister where children cannot touch.

For check and replenishment, contact your air conditioner shop.



## 14. AIR CONDITIONER

### How to Inspect


Turn the air conditioner on and rev the engine slightly.  
Compare the bubbles seen through the site glass to the figures given below

| Amount            | Site glass condition (Switch turned on, after a minute) | Treatment                                                                                                                                      |
|-------------------|---------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| OK                |                                                         | <ul style="list-style-type: none"> <li>• Almost clear</li> <li>• Clear alternating with milky cloudiness</li> </ul>                            |
| X<br>Under fill   |                                                         | Clear since switch ON                                                                                                                          |
| X<br>Under filled |                                                         | <ul style="list-style-type: none"> <li>• Flow of bubbles seen continuously</li> <li>• Bubbles in white cloudiness seen continuously</li> </ul> |
| X<br>Almost empty |                                                         | Clear since switch ON                                                                                                                          |

Check and refill appropriate amount of agent at the installer.

### CAUTION

- Operating the air conditioner without sufficient coolant may damage the compressor.
- Too much coolant (overfill) will reduce the cooling power. It also causes dangerous overpressure in the circuit. Maintain the prescribed amount.
- During winter or when the air conditioner is not used for a long time, operating it for a few minutes a couple of times each month helps prevent gas from leaking from the compressor seals.



Caution :  
Some models have the site glass at the piping area.

14.6 ELECTRIC SYSTEM SCHEMATIC

